Motive Line Check Valve Filter – Maintenance Practices

1. Servicing

A. Service Filter

1) Ensure crossfeed valve is closed and wing fuel tank switches (if fitted) are OFF. Drain appropriate forward or aft fuselage fuel tank. (Refer to 12-10-10, Fuel System – General Data).

2) Remove access panel from underside of fuselage. (Refer to 12-00-00, Servicing – General Data).

3) Remove check valve from line.

4) Unscrew valve and cap assembly from check valve housing.

5) Remove retaining ring from housing and withdraw filter.

6) Check condition of filter element, clean with varsol and dry with filtered air.

7) Check condition of rubber seal in check valve. If damaged, complete valve and cap assembly must be replaced.

8) Install filter in housing and fit retaining ring. Ensure retaining ring is fully inserted in groove.

9) Install aluminum gasket, valve and cap assembly to check valve housing.

10) Tighten valve and cap assembly to a torque value of 600 pound–inches.

11) Install check valve in line.

12) Select fuel BOOST PUMP 1 to ON.

13) Check for fuel leaks.

14) Install access panel. (Refer to 12-00-00, Servicing – General Data).

This Page Intentionally Left Blank