Fuel Low Pressure Switch (Mod 6/2006) – Maintenance Practices

1. Removal/Installation

   A. Remove Wing Tank Fuel Low Pressure Switch

      1) Apply DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

      2) Drain applicable wing tank (refer to 12-10-10, Fuel System – General Data).

      3) Disconnect DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

      4) Remove wing tip.

      5) Electrically disconnect pressure switch.

      6) Unscrew pressure switch from mounting and cap opening.

   B. Install Wing Tank Fuel Low Pressure Switch

      1) Install pressure switch to mounting.

      2) Electrically connect pressure switch.

      3) Function test system (refer to 28-00-01, Fuel (With Mod S.O.O. 6247) – General Data) and check for leaks.

      4) Install wing tip.

This Page Intentionally Left Blank