Aileron Geared Tab – Maintenance Practices

1. Removal/Installation

A. Remove Geared Tab

1) Disconnect control rod at geared tab.

2) Cut and remove locking wire securing end of hinge pin to aileron.

3) Support tab and withdraw hinge pin.

B. Install Geared Tab

1) Lightly lubricate hinge pin. Refer to 12-20-10, Lubrication – General Data for lubricant specification.

2) Align hinge components on tab and aileron.

3) Insert hinge pin from inboard end of aileron and lockwire end of hinge to holes in adjacent aileron structure.

4) Connect control rod to tab with bolt, washer, nut and cotter pin.

5) Check geared tab control surface clearances (refer to 27-00-00, Flight Controls – General Data).

6) Operate ailerons and check geared tab for full and free range of movement.

Note If tab or aileron has been repaired, or has had additional paint applied, the aileron assembly must be balanced as detailed in Structural Repair Manual PSM 1–6–3.

This Page Intentionally Left Blank