Rudder Geared Tab – Maintenance Practices

1. Removal/Installation

A. Remove Geared Tab

1) Disconnect control rod at geared tab.

2) Disengage upper end of hinge pin from retaining clip on rudder.

3) Support tab and withdraw hinge pin.

B. Install Geared Tab

1) Lightly lubricate hinge pin. Refer to 12-20-10, Lubrication – General Data for lubricant specification.

2) Align hinge components on tab and rudder.

3) Insert hinge pin from upper end of tab and engage upper end of hinge pin in retaining clip on rudder.

4) Connect control rod to tab with bolt, washer, nut and cotter pin.

5) Check geared tab control surface clearances (refer to 27-00-00, Flight Controls – General Data).

6) Operate rudder and check for full and free range of movement.

Note If tab or rudder has been repaired, or has had additional paint applied. If the rudder assembly must be balanced as detailed in Structural Repair Manual PSM 1–6–3.

This Page Intentionally Left Blank