Cabin Temperature Sensor – Maintenance Practices

1. Adjustment/Test

A. Operational Test – Cabin Temperature Sensor

Note Cabin temperature is not essential and the following procedure need only be done to enable adequate passenger comfort.

1) Apply DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

2) Observe cabin temperature as displayed on CAS as compared to an available thermometer. Alternatively open cabin doors and compare to OAT reading.

3) Replace sensor as required.

4) Disconnect DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

This Page Intentionally Left Blank