Aileron – Maintenance Practices

1. Removal/Installation

CAUTION **IF REMOVING OR INSTALLING CONTROL CABLES, DISCONNECT MAIN BATTERY (REFER TO 24-30-31, MAIN BATTERY SYSTEM – MAINTENANCE PRACTICES, PARA 2.), AVIONICS START BATTERY (IF INSTALLED, REFER TO 24-30-32, AVIONICS START BATTERY (MOD 6/2315) – GENERAL DATA, PARA 4.) AND EMERGENCY BATTERY (IF INSTALLED, REFER TO 33-50-01, EMERGENCY LIGHTING BATTERY – GENERAL DATA, PARA 1.) AND DISCONNECT GROUND POWER.**

A. Remove Aileron

1) Disconnect push-pull rods at geared tab and aileron.

Note Do not alter push-pull rod adjustment as this will affect rigging.

2) On left aileron only, disconnect electrical wiring at aileron trim actuator, and sensor wiring at wing station 247.35.

3) Support aileron and remove four hinge bolts and bonding strips.

B. Install Aileron

CAUTION **ENSURE THAT AILERON IS OF THE CORRECT TYPE. AILERONS INSTALLED ON AIRCRAFT WITH WING FUEL TANKS (MOD S.O.O. 6247), ARE BALANCED IN ACCORDANCE WITH A SEPARATE STATIC BALANCE PROCEDURE.**

Note If the aileron to be installed is a replacement or repaired aileron, or if it has been painted or repainted, rebalancing must be carried out in accordance with the Structural Repair Manual PSM 1–6–3.

1) Examine replacement aileron for signs of damage (refer to Inspection Requirement Manual, Flight Controls, Ailerons and Tabs).

2) Support aileron and connect to aileron hinge brackets with four hinge bolts. Connect bonding strips on left aileron only, disconnect electrical wiring at aileron trim actuator, and sensor wiring at wing station 247.35 and secure hinge bolts with washers, nuts and cotter pins.

3) Connect push-pull rods at geared tab and aileron, install bolts and secure with nuts and cotter pins.

4) Check aileron rigging. (Refer to 27-10-00, Aileron Control System – General Data).

5) Check aileron gear tab rigging. (Refer to 27-16-00, Aileron Geared Tab System – General Data).

6) On left aileron only, check operation of aileron trim tab. (Refer to 27-13-00, Aileron Trim Tab System – General Data).

7) Check aileron control surface clearances are within limits. (Refer to 27-00-00, Flight Controls – General Data).

8) Operate ailerons and check for full and free range of movement.

9) Do operational test of the aileron angle position indicator as per 27-10-31, Aileron Angle Position Indicator – General Data, Para 3.B.

10) If adjustment is needed for the aileron angle position indicator adjust as per 27-10-31, Aileron Angle Position Indicator – General Data, Para 3.A.

This Page Intentionally Left Blank