Aileron Trim Tab – Maintenance Practices

1. Removal/Installation

A. Remove Trim Tab

1) Disconnect trim actuator rod end from trim tab.

2) Cut and remove locking wire securing end of hinge pin to aileron.

3) Support tab and withdraw hinge pin.

B. Install Trim Tab

1) Lightly lubricate hinge pin. Refer to 12-20-10, Lubrication – General Data for lubricant specification.

2) Align hinge components on tab and aileron.

3) Insert hinge pin from outboard end of aileron and lockwire end of hinge to holes in adjacent aileron structure.

4) Connect trim actuator rod end to tab with bolt, washer, nut and cotter pin.

5) Check trim tab control surface clearances (refer to 27-00-00, Flight Controls – General Data).

6) Operate trim tab and check for full and free range of movement.

Note If tab or aileron has been repaired, or has had additional paint applied, the aileron assembly must be balanced as detailed in Structural Repair Manual PSM 1–6–3.

This Page Intentionally Left Blank