Fuel Gallery Access Panel Seals (Mod 6/2408) – Maintenance Practices

1. Inspection/Check

   A. Access Panels and Seals

      1) Visually inspect the seals for disbond, tears or distortion, replace or repair, as required.

2. Removal/Installations

   A. Remove Access Panel Seal

      1) Remove quick release fasteners from the panel.

      2) Peel off seal completely. If present, remove remaining seal with a plastic scraper.

   B. Install Access Panel Seal

      1) Clean the access panel where the seal is to be bonded, with clean solvent DS108 or equivalent.

      2) Using a suitable bristle brush, apply a thin, even coat of EC–1357N adhesive to both bonding surfaces (on the panel and on the seal), making as few strokes as possible.

      3) If necessary, apply two or more coats of adhesive to the seal surface to ensure that sufficient adhesive remains on the surface. Allow each preceding coat to air dry before the next coat is applied.

      4) Allow the final coat of the adhesive to air dry until it is tacky.

      5) Press the seal to the panel and roll down with a rubber or stitch roller, to ensure equal contact to the full bonding surface.

      6) Create quick release holes on the seal.

      7) Install quick release fasteners on to the panel.

3. Approved Repairs

   A. Splice Seal Repair

      CAUTION DO NOT DAMAGE THE ACCESS PANEL.

      1) Cut through damaged section or defective seal with a sharp knife; cut line to be half inch beyond either side of damaged or defective section. A thin and clean stainless ruler or strap should be inserted between the seal and the panel under the cut line, to prevent potential cutting damage to the panel.

      2) Remove the damaged or defective section of the seal from the panel.

      3) Clean the access panel where the seal is removed with clean solvent DS108 or equivalent.

      4) Obtain a piece of the replacement seal section and cut the length to fit (slightly longer length is necessary to prevent any gap between the existing seal and the replacement seal).

      5) Using a suitable bristle brush, apply a thin, even coat of EC–1357N adhesive to both bonding surfaces (on the panel and on the seal), and the butt surfaces between the existing seal and the replacement seal, making as few strokes as possible.

      6) If necessary, apply two or more coats of adhesive to the seal surface to ensure that sufficient adhesive remains on the surface. Allow each preceding coat to air dry before the next coat is applied.

7) Allow the final coat of adhesive to air dry until it is tacky, but does not transfer to the finger when touched lightly.

8) Press the seal to the panel and roll down with a rubber or stitch roller to ensure equal contact to the full bonding surface.