Fuel Low Level Float Switch – Maintenance Practices

1. Removal/Installation

   A. Remove Low Level Float Switch

      1) Remove applicable fuel cell sump plate. (Refer to 28-10-21, Fuel Cell Sump Plate – Maintenance Practices).

      2) Loosen locking nut at base of float switch and unscrew float switch from supporting platform.

      3) Remove float switch, attached electrical leads, locking nut and O-ring from platform.

   B. Install Low Level Float Switch

      1) Insert new O-ring into platform recess.

      2) Screw locking nut on float switch base and insert electrical leads and switch into platform.

      3) Install fuel cell sump plate. (Refer to 28-10-21, Fuel Cell Sump Plate – Maintenance Practices).

This Page Intentionally Left Blank