PTF ALL

Cabin Temperature Control Problem (Flight Deck) - Fault Isolation

CORRECTIVE ACTION SUMMARY

Replace Applicable Cabin Temperature Sensor Filter
Replace Applicable Cabin Temperature Sensor Fan
Repair Flight Deck Air Distribution Ducts
Replace Flight Deck Duct Temp Primary Sensor [T478]
Replace Flight Deck Duct Temp Backup Sensor [T477]
Replace Control Cabin Temperature Sensor [M1718]
Replace CONT CAB Temperature Selector [P5-17S2]
Replace Trim Air Pressure Regulating Shutoff Valve [V146]

A. Description

(1) This task is for this observed fault:
   (a) The cabin temperature in the flight deck cabin is unable to be controlled.

B. Fault Isolation Procedure

(1) Do this inspection of the applicable cabin temperature sensor filter:
   (a) Get access to the applicable cabin temperature sensor filter. To get access, do the necessary steps in this task:
      • Cabin Temperature Sensor Assembly Filter Removal, AMM TASK 21-61-06-000-801.
   (b) Do a general visual inspection of the filter.
   (c) If the filter is dirty, then do these steps:
      1) Replace the applicable cabin temperature sensor filter. These are the tasks:
         • Cabin Temperature Sensor Assembly Filter Removal, AMM TASK 21-61-06-000-801,
         • Cabin Temperature Sensor Assembly Filter Installation, AMM TASK 21-61-06-400-801.
      2) Close the access that you made for the applicable cabin temperature sensor filter.
      3) If the observed fault symptom is gone, then you corrected the fault.
   (d) If the filter is not dirty, then continue.
   (e) Close the access that you made for the applicable cabin temperature sensor filter.
(2) Replace the applicable cabin temperature sensor fan. These are the tasks:
   • Cabin Temperature Sensor Fan Removal, AMM TASK 21-61-11-000-801,
   • Cabin Temperature Sensor Fan Installation, AMM TASK 21-61-11-400-801.
   (a) If the observed fault symptom is gone, then you corrected the fault.
   (b) If the observed fault symptom stays, then continue.
(3) Do this check of the flight deck air distribution ducts:
   (a) Inspect the duct for leaks.
   (b) If you find a leak, then do these steps:
      1) Repair the flight deck air distribution ducts.
      2) If the observed fault symptom is gone, then you corrected the fault.
   (c) If you do not find a leak, then continue.
(4) Replace the flight deck duct temp primary sensor, T478. These are the tasks:
   • Duct Temperature Limit Sensor Removal, AMM TASK 21-61-04-000-801,
   • Duct Temperature Limit Sensor Installation, AMM TASK 21-61-04-400-801.
   (a) If the observed fault symptom is gone, then you corrected the fault.
   (b) If the observed fault symptom stays, then continue.
(5) Replace the flight deck duct temp backup sensor, T477. These are the tasks:

EXPORT CONTROLLED:9E991
BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details

- Duct Temperature Limit Sensor Removal, AMM TASK 21-61-04-000-801,
- Duct Temperature Limit Sensor Installation, AMM TASK 21-61-04-400-801.

(a) If the observed fault symptom is gone, then you corrected the fault.

(b) If the observed fault symptom stays, then continue.

(6) Replace the control cabin temperature sensor, M1718. These are the tasks:

- Cabin Temperature Sensor Removal, AMM TASK 21-61-10-000-801,
- Cabin Temperature Sensor Installation, AMM TASK 21-61-10-400-801.

(a) If the observed fault symptom is gone, then you corrected the fault.

(b) If the observed fault symptom stays, then continue.

(7) Replace the CONT CAB temperature selector, P5-17S2. These are the tasks:

- Cabin Temperature Selector Removal, AMM TASK 21-61-07-000-801,
- Cabin Temperature Selector Installation, AMM TASK 21-61-07-400-801.

(a) If the observed fault symptom is gone, then you corrected the fault.

(b) If the observed fault symptom stays, then continue.

(8) Replace the trim air pressure regulating shutoff valve, V146. These are the tasks:

- Trim Air Pressure Regulating and Shutoff Valve Removal, AMM TASK 21-62-01-000-801,
- Trim Air Pressure Regulating and Shutoff Valve Installation, AMM TASK 21-62-01-400-801.

(a) If the observed fault symptom is gone, then you corrected the fault.

--------- END OF CONTENT ---------

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details