PTF ALL

Maintenance Message 21-30301 - Fault Isolation

LOW AIR SUPPLY OR HIGH FUSELAGE LEAKAGE

DETECTED BY: CABIN PRESSURE CONTROLLER (CPC)-2

CORRECTIVE ACTION SUMMARY

Correct Related Maintenance Messages
Clean/Repair Aft Cargo Door Seal
Clean/Repair Forward Cargo Door Seal
Replace Left Pack Flow Control and Shutoff Valve [V184]
Replace Right Pack Flow Control and Shutoff Valve [V185]
Replace Left Air Cycle Machine
Replace Right Air Cycle Machine
Do the applicable AMM Task(s)

A. Description

(1) This task is for this maintenance message:
  (a) LOW AIR SUPPLY OR HIGH FUSELAGE LEAKAGE

(2) This maintenance message does not indicate a fault with the digital cabin pressurization control system.

B. Initial Evaluation

(1) Do this task:
- Cabin Pressure Controller (CPC) BITE Procedure, AMM TASK 21-31-00-740-801.

(2) If the OMF shows ACTIVE for the maintenance message, then do the Fault Isolation Procedure below.

(3) If the OMF shows NOT ACTIVE for the maintenance message, then there was an intermittent fault.

C. Fault Isolation Procedure

(1) Look in OMF Existing Faults, 36 Pneumatics for related maintenance messages.
  (a) If you find any related maintenance messages, then do these steps:
    1) Do the fault isolation task for each related maintenance message.
    2) Do the AMM test that you did at the start of this task.
    3) If the OMF shows NOT ACTIVE for the maintenance message (or if the message does not show), then you corrected the fault.
  (b) If you do not find related maintenance messages, then continue.

(2) Do a general visual inspection of the aft cargo door seal. This is the task:
- Cargo Door Pressure Seal Check, AMM TASK 52-31-00-200-802.

  (a) If you find a problem during the inspection, then do these steps:
    1) Clean or repair the aft cargo door seal.
    2) Do the AMM test that you did at the start of this task.
    3) If the OMF shows NOT ACTIVE for the maintenance message (or if the message does not show), then you corrected the fault.
  (b) If you do not find a problem during the inspection, then continue.

(3) Do a general visual inspection of the forward cargo door seal. This is the task:
- Cargo Door Pressure Seal Check, AMM TASK 52-31-00-200-802.

  (a) If you find a problem during the inspection, then do these steps:
    1) Clean or repair the forward cargo door seal.
    2) Do the AMM test that you did at the start of this task.

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details

3) If the OMF shows NOT ACTIVE for the maintenance message (or if the message does not show), then you corrected the fault.

(b) If you do not find a problem during the inspection, then continue.

(4) Do a test of the left pack flow control and shutoff valve, V184. This is the task:
- Pack Flow Control Valve Operational Test, AMM TASK 21-51-00-700-802.

(a) If you find a problem during the test, then do these steps:
1) Replace the left pack flow control and shutoff valve, V184. These are the tasks:
- Left Flow Control and Shutoff Valve Removal, AMM TASK 21-51-01-000-801,
- Left Flow Control and Shutoff Valve Installation, AMM TASK 21-51-01-400-801.

2) Do the AMM test that you did at the start of this task.
3) If the OMF shows NOT ACTIVE for the maintenance message (or if the message does not show), then you corrected the fault.

(b) If you do not find a problem during the test, then continue.

(5) Do a test of the right pack flow control and shutoff valve, V185. This is the task:
- Pack Flow Control Valve Operational Test, AMM TASK 21-51-00-700-802.

(a) If you find a problem during the test, then do these steps:
1) Replace the right pack flow control and shutoff valve, V185. These are the tasks:
- Right Flow Control and Shutoff Valve Removal, AMM TASK 21-51-01-000-802,
- Right Flow Control and Shutoff Valve Installation, AMM TASK 21-51-01-400-802.

2) Do the AMM test that you did at the start of this task.
3) If the OMF shows NOT ACTIVE for the maintenance message (or if the message does not show), then you corrected the fault.

(b) If you do not find a problem during the test, then continue.

(6) Replace the left air cycle machine. These are the tasks:
- Air Cycle Machine Removal, AMM TASK 21-51-04-000-801,
- Air Cycle Machine Installation, AMM TASK 21-51-04-400-801.

(a) Do the AMM test that you did at the start of this task.

(b) If the OMF shows NOT ACTIVE for the maintenance message (or if the message does not show), then you corrected the fault.

(c) If the OMF shows ACTIVE for the maintenance message, then continue.

(7) Replace the right air cycle machine. These are the tasks:
- Air Cycle Machine Removal, AMM TASK 21-51-04-000-801,
- Air Cycle Machine Installation, AMM TASK 21-51-04-400-801.

(a) Do the AMM test that you did at the start of this task.

(b) If the OMF shows NOT ACTIVE for the maintenance message (or if the message does not show), then you corrected the fault.

(c) If the OMF shows ACTIVE for the maintenance message, then continue.

(8) Do this task:
- Cabin Pressure Leak Test, AMM TASK 05-51-91-790-801.

(a) Do the AMM test that you did at the start of this task.

(b) If the OMF shows NOT ACTIVE for the maintenance message (or if the message does not show), then you corrected the fault.

--------- END OF CONTENT ---------

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details