PTF ALL

Cabin Pressure Control Module Display Is Blank or Does Not Operate Correctly - Fault Isolation

CORRECTIVE ACTION SUMMARY

Cycle Circuit Breakers
Correct Related Maintenance Messages
Replace Cabin Pressure Control Module [P5-6]

A. Fault Isolation Procedure

(1) Open these circuit breakers:

(a) Circuit Breaker List

1) C1269, PRESSURIZATION CONTROL MANUAL [P6-4, F6].
2) C1270, PRESSURIZATION CONTROL AUTO 1 [P6-4, F3].
3) C1271, PRESSURIZATION CONTROL AUTO 2 [P6-4, F5].
4) C1272, PRESSURIZATION CONTROL IND [P6-4, F7].
5) C1273, PRESSURIZATION CONTROL LCD LTG [P6-4, F1].

(b) Wait a minimum of three seconds.

(c) Close the circuit breakers.

(d) If the observed fault symptom is gone, then you corrected the fault.

(e) If the observed fault symptom stays, then continue.

(2) Look in OMF Existing Faults, 21 Cabin Pressure for related maintenance messages.

(a) If you find any related maintenance messages, then do these steps:

1) Do the fault isolation task for each related maintenance message.
2) If the observed fault symptom is gone, then you corrected the fault.

(b) If you do not find related maintenance messages, then continue.

(3) Replace the cabin pressure control module, P5-6. These are the tasks:

- Cabin Pressure Control Module Removal, AMM TASK 21-31-02-000-801,
- Cabin Pressure Control Module Installation, AMM TASK 21-31-02-400-801.

(a) If the observed fault symptom is gone, then you corrected the fault.

--------- END OF CONTENT ---------

EXPORT CONTROLLED:9E991
BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details