Engine Model(s): PT6A

72-30-01

CENTER FIRESEAL MOUNT RING - DESCRIPTION AND OPERATION

1. Description and Operation

The center fireseal mount ring, which forms a bulkhead between the compressor air inlet zone and the front of the engine, consists of upper and lower halves with bolting flanges. Each half is manufactured from stainless steel sheet, with the outer circumference contoured to suit airframe fuselage and/or nacelle requirements. Clearance holes for external tubes, lines, and bolt holes for attaching parts are provided at appropriate locations in the upper and lower halves. An insulating strip is bonded to the inner circumference to provide a seal between the mount ring and the gas generator case. The upper and lower halves are bolted together to form a complete ring which is fastened to the gas generator case by mounting brackets Pre-SB1445 attached to the assembly, or by bolts Post-SB1445 which integrally mounts the center fireseal mount ring to the gas generator case.

The center fireseal provides a bulkhead between the compressor air inlet zone and the front of the engine.

Printed on 10/NOV/26 P&WC Proprietary – subject to restrictions in Technical Data Agreement