Engine Model(s): PT6A

72-40-00

COMBUSTION SECTION - DESCRIPTION AND OPERATION

1. Description and Operation

The combustion section of the engine is contained in the front section of the gas generator case and consists of the combustion chamber liner and the small and large exit ducts. The liner is retained within the gas generator case by the two glow plugs or spark igniters and the 14 fuel manifold adapters. Compressor discharge air is directed from the diffuser section and discharges into the combustion section; air enters the liner through straight and plunged holes, mixes with fuel from the manifold and is ignited. The expanding gases flow to the rear and into the exit duct zone where the gas flow is turned 180 degrees inward to flow forward through the compressor turbine inlet guide vanes to the compressor turbine.

Printed on 10/NOV/26 P&WC Proprietary – subject to restrictions in Technical Data Agreement