Cabin Air Control Valve – Maintenance Practices

1. Adjustment/Test

   A. Function Test Cabin Air Control Valve

      1) Open right-hand access panel on underside of nose section. (Refer to 12-00-00, Servicing – General Data).

      2) Close cabin cool air gaspers.

      3) Pull RAM AIR valve control handle to OPEN.

      4) Push CABIN AIR valve control handle to the valve open position. Check that cabin air control valve shaft handle contacts left-hand flange of stop plate, and that a distance of 3.5 inches exists between center of control cable fork end attachment pin and end of cable sleeve.

      5) Pull CABIN AIR valve control handle to CLOSE. Check that cabin air control valve shaft handle moves through a range of approximately 90°, and that control cable fork end butts against end of cable sleeve.

      6) Operate main duct fan. (Refer to 21-50-11, Main Duct Fan – Maintenance Practices).

      7) Check that no air flows through cabin baseboard heater outlets.

      8) Push CABIN AIR valve control handle to the valve open position. Check that air flows through cabin baseboard heater outlets.

      9) Switch off main duct fan.

      10) Close right-hand access panel. (Refer to 12-00-00, Servicing – General Data).

This Page Intentionally Left Blank