Ram Air Control Valve – Maintenance Practices

1. Adjustment/Test

   A. Function Test Ram Air Control Valve

      1) Open right-hand access panel on underside of nose section. (Refer to 12-00-00, Servicing – General Data).

      2) Close cabin cool air gaspers.

      3) Pull CABIN AIR valve control handle to CLOSED.

      4) Push RAM AIR valve control handle to CLOSED. Visually check that ram air valve shaft lever contacts left-hand flange of stop plate.

      5) Pull RAM AIR valve control handle to OPEN. Visually check that ram air valve shaft lever has moved through a range of approximately 90° and contacts right-hand flange of stop plate.

      6) Operate main duct fan. (Refer to 21-50-11, Main Duct Fan – Maintenance Practices).

      7) Check that air flows through pilot's and co-pilot's foot warmer, and windshield heater outlets.

      8) Push RAM AIR valve control handle to CLOSED.

      9) Check that air ceases to flow through flight compartment outlets.

      10) Switch off main duct fan.

      11) Close right-hand access panel. (Refer to 12-00-00, Servicing – General Data).

This Page Intentionally Left Blank