Life Vest Provisions – General Data

1. General

On aircraft with Mod 6/2281 and Mod 6/2282 installed, provisions have been made for the installation of life vest pouches to be attached to the bottom of the passenger seats.

For aircraft incorporating S.O.O. 6309, provisions have been made for the installation of English life vest pouches and placards.

For aircraft incorporating S.O.O. 6352, provisions have been made for the installation of Chinese/English life vest pouches and placards.

2. Description

Life vest pouches are attached to the bottom of the passenger seats with four (4) 'pull the dot snaps' and a hook-loop flap that attaches to the leading edge of the seat frame. The pouch and strap are designed for a maximum life vest size of 7 x 7 x 2 inches, and a maximum packaged weight of 2.0 pounds.

Only approved life vests, TSO–C13e or later Revision, are to be used with S.O.O. 6309 or S.O.O. 6352. If approved life vests are not stowed in life vest pouch, the 'LIFE VEST UNDER SEAT' placard must be removed.

3. Removal/Installation

A. Removal of Life Vest Pouch from Station 332 Seats

1) Ensure seat bottom is in the 'tip-up' position.

2) Pull on canvas of pouch surrounding the snap; pull from 'dot' side and away from seat bottom.

Note Use caution to ensure the seat bottom is not damaged.

3) Inspect condition of seat bottom, snaps and life vest pouch.

4) Replace any damaged components.

B. Installation of Life Vest Pouch on Station 332 Seats

1) Ensure seat bottom is in 'tip-up' position.

2) With pouch flap positioned toward the forward edge of the seat, engage four (4) pouch snap halves with seat bottom snap halves.

3) Mount life vest to the life vest harness/pull strap, and place into pouch with red pull strap protruding from the pouch.

4) Engage harness strap snap with seat snap halve on the forward edge of seat bottom.

5) Engage pouch hook fastener to seat loop on the forward edge of seat bottom.

C. Removal of Life Vest Pouch from Non-Bulkhead Seats

1) Locate life vest pouch on the bottom of seat.

2) Detach pouch by pulling on the canvas of pouch surrounding the snap; pull from 'dot' side of snap and away from seat bottom.

Note Use caution to ensure the seat bottom is not damaged.

3) Inspect condition of seat bottom, snaps and life vest pouch.

4) Replace any damaged components.

D. Installation of Life Vest Pouch on Non-Bulkhead Seats

1) Locate four (4) snap halves located on the bottom of each passenger seat.

2) With pouch flap positioned towards forward edge of the seat, engage four (4) pouch snap halves with seat bottom snap halves.

3) Mount life vest to the life vest harness/pull strap, and place into pouch with red pull strap protruding from the pouch.

4) Engage harness strap snap with seat snap halve on the forward edge of seat bottom.

5) Engage pouch hook fastener to seat loop on the forward edge of seat bottom.