DE HAVILLAND AIRCRAFT OF CANADA LIMITED

# TEMPORARY REVISION

**PSM: 1-64-2** **AIRCRAFT: DHC-6** **SERIES: 400**

**PUBLICATION: MAINTENANCE MANUAL** **TEMP. REVISION NO.: TR26-2**

---

Insert in 26-25-00 before Page 1

HAND-OPERATED FIRE EXTINGUISHERS

**REASON FOR ISSUE:**

To introduce S.O.O. 6533, Introduction of Halotron Portable Fire Extinguishers.

**ACTION:**

In Chapter 26, Section 26-25-00, ignore existing Page 1 and insert new page as shown on Page 2 of this Temporary Revision.

**-Continued overleaf-**

**RECORDING INSTRUCTIONS:**

Record this TEMPORARY REVISION NO. and the relevant information in the appropriate columns of the TEMPORARY REVISION INDEX provided at the front of the manual.

## Hand-operated Fire Extinguishers – General Data

1. General

The hand-operated extinguisher is located on the aisle floor beside the co-pilot's seat. The extinguisher contains a frangible disc which, when broken, allows HALON contents to discharge under pressure. Mod 6/2092 provides an additional HALON extinguisher is installed and located in the cabin, forward of the airstair door. Aircraft with S.O.O. 6533 incorporated have one Halotron handheld fire extinguisher affixed to the floor structure below and left of the co-pilot seat, and one Halotron fire extinguisher mounted just forward of the rear port side door in the cabin.

2. Servicing

A. Flag Halon 1211 Extinguisher Model HAL–035W

1) Inspect extinguisher monthly and ensure pressure gauge indicates correct operating range with needle in green sector. Check red disc at rear of operating head, and if disc is broken, extinguisher has been used. Replace extinguisher as follows:

a) Release safety catch, and squeeze lever to empty container.

b) Unscrew container, and discard container or return to F.P.S. International approved agency for recharge.

c) Reset safety catch.

d) Replace red (tamper) disc.

e) Fit properly charged container to operating head.

f) Ensure nozzle is unobstructed.

2) Weigh unit every six months. Ensure weight is within four ounces of weight indicated on extinguisher label. Replace extinguisher or renew container (refer to Para 2.A.1)) if weight falls below limit.

B. H3R Aviation 1211 Extinguisher Model A1600 (Mod 6/2060)

1) Inspect extinguisher monthly and ensure pressure gauge indicates correct operating range with needle in green sector. Check red disc at rear of operating head, and if disc is broken, extinguisher has been used. Replace extinguisher as follows:

a) Release safety catch, and squeeze lever to empty container.

b) Unscrew container, and discard container or return to F.P.S. International approved agency for recharge.

c) Reset safety catch.

d) Replace red (tamper) disc.

e) Fit properly charged container to operating head.

f) Ensure nozzle is unobstructed.

2) Weigh unit every six months. Ensure weight is within four ounces of weight indicated on extinguisher label. Replace extinguisher or renew container (refer to Para 2.B.1)) if weight falls below limit.

C. Halotron Extinguishers - Model 355N69953 (S.O.O. 6533)

1) Refer to CMM #368–MM2–BTP Rev 8 or later for inspection and maintenance instructions.

## Hand-operated Fire Extinguishers – General Data

1. General

The hand-operated extinguisher is located on the aisle floor beside the co-pilot's seat. The extinguisher contains a frangible disc which, when broken, allows HALON contents to discharge under pressure. Mod 6/2092 provides an additional HALON extinguisher is installed and located in the cabin, forward of the airstair door.

2. Servicing

A. Flag Halon 1211 Extinguisher Model HAL–035W

1) Inspect extinguisher monthly and ensure pressure gauge indicates correct operating range with needle in green sector. Check red disc at rear of operating head, and if disc is broken, extinguisher has been used. Replace extinguisher as follows:

a) Release safety catch, and squeeze lever to empty container.

b) Unscrew container, and discard container or return to F.P.S. International approved agency for recharge.

c) Reset safety catch.

d) Replace red (tamper) disc.

e) Fit properly charged container to operating head.

f) Ensure nozzle is unobstructed.

2) Weigh unit every six months. Ensure weight is within four ounces of weight indicated on extinguisher label. Replace extinguisher or renew container (refer to Para 2.A.1)) if weight falls below limit.

B. H3R Aviation 1211 Extinguisher Model A1600 (Mod 6/2060)

1) Inspect extinguisher monthly and ensure pressure gauge indicates correct operating range with needle in green sector. Check red disc at rear of operating head, and if disc is broken, extinguisher has been used. Replace extinguisher as follows:

a) Release safety catch, and squeeze lever to empty container.

b) Unscrew container, and discard container or return to F.P.S. International approved agency for recharge.

c) Reset safety catch.

d) Replace red (tamper) disc.

e) Fit properly charged container to operating head.

f) Ensure nozzle is unobstructed.

2) Weigh unit every six months. Ensure weight is within four ounces of weight indicated on extinguisher label. Replace extinguisher or renew container (refer to Para 2.B.1)) if weight falls below limit.

**This Page Intentionally Left Blank**