Indicating – General Data

1. General

The pneumatic indicating system is basically a low pressure warning displayed through CAS. The system consists of a Pneumatic Press Low caution message which is displayed when a low pressure switch actuates if regulated pressure drops to between 13 and 15 psi. On increasing pressure, the pressure switch actuates between 16 and 18 psi to extinguish the caution CAS message. The pressure switch is connected into the pressure line from the pressure regulator.

The Pneumatic Press Low caution message is driven by the following logic:

A. If the SURFACE DE-ICE switch is in the BOOTS AUTO–FAST or BOOTS AUTO–SLOW position (in other words, the switch is not in the OFF/MANUAL position), and;

B. If the airframe pressure sensing system indicates a low pneumatic pressure state, and;

C. If the aircraft is not on the ground, the Pneumatic Press Low caution message will activate. If the aircraft is on the ground, the Pneumatic Press Low advisory message will activate.

This Page Intentionally Left Blank