Rudder – General Data

1. General

The rudder is hinged to the vertical stabilizer and rear fuselage at three points. A lever attached to the rudder main spar is connected to the rudder control cables. Two tabs are hinged to the trailing spar, the upper being the trim tab and the lower tab being the geared tab.

The rudder comprises a main spar, rear spar, nose spar, ribs, and skin panels. Fluted skin panels are fitted aft of the rudder main spar.

Refer to 27-20-00, Rudder Control System – General Data and 27-20-11, Rudder – Maintenance Practices for removal, installation, and rigging of the rudder details.

This Page Intentionally Left Blank