Overspeed Governor – Maintenance Practices

1. Removal/Installation

   A. Remove Overspeed Governor

      1) Gain access to overspeed governor mounted on left side of engine reduction gearbox.

      2) Disconnect overspeed test and autofeather solenoid electrical connections.

      3) Remove nuts and washers securing overspeed governor to reduction gearbox, and withdraw overspeed governor from mounting studs. Discard mounting gasket.

      4) Remove overspeed governor drive, examine for damage and wear, if satisfactory retain for installation.

   B. Install Overspeed Governor

      1) Examine replacement governor for signs of external damage.

      2) Install new mounting gasket over studs on overspeed governor mounting pad.

      3) Install a serviceable overspeed governor drive shaft, and ensure engagement with engine drive.

      4) Install overspeed governor and secure with washers and self-locking nuts. Torque nuts to between 170 to 190 pound–inches.

      5) Connect overspeed test and autofeather solenoid electrical connections.

      6) Carry out engine run and complete propeller functional checks. (Refer to 71-00-00, Power Plant (Mod 6/2012) – General Data).

This Page Intentionally Left Blank