Airline Filters – Maintenance Practices

1. Servicing

A. Clean Air Line Filters

1) Lower engine bottom cowling.

2) Disconnect air lines from air valve AN fitting and remove filters.

3) Check condition of each filter mesh. If serviceable, clean with dry cleaning solvent (P–D–680) and dry with compressed air.

4) Install filters in air valve AN fitting.

5) Connect air lines to air valve AN fitting.

6) Raise and secure engine bottom cowling.

This Page Intentionally Left Blank