Ignition – General Data

1. General

The ignition system provides electrical power to each engine from the left DC bus. The ignition system consists of an ignition, selector switch, engine igniter switches and two circuit breakers, installed in the flight compartment. Ignition is initiated automatically through the starter system during ground starting of the engine. For air relights and ignition system ground testing only, the ignition may be operated manually through the ignition selector switch. Engine ignition is accomplished by spark igniters. For information regarding the items installed on the engine, refer to PT6A–34, Engine Maintenance Manual.

This Page Intentionally Left Blank