Emergency Lighting (Mod S.O.O. 6205) – General Data

1. General

Emergency Lighting (Mod S.O.O. 6205) is available as a customer order option.

Emergency lighting is provided by using an emergency battery to operate the six cabin lights in the event of failure of the 28 Volt DC power supply. The dedicated battery is on continuous charge whenever the main 28 Volt DC system is energized.

A single switch labelled EMERGENCY LIGHTING has three positions marked ARM, TEST, and OFF. The ARM position (lever locked) is normally selected for flight to both arm the lights for automatic operation should a power failure occur, and to trickle charge the battery. The TEST position (a momentary position) interrupts the aircraft input voltage, testing the monitoring circuit, battery power. Select switch to OFF before selecting the MASTER switch to OFF.

The emergency lights circuit is powered from the left 28 Volt DC bus and is protected by a circuit breaker labelled EMERGENCY LIGHTING BATTERY on the rear circuit breaker panel station 332.00.

2. Adjustment/Test

A. Operational Test Emergency Lights

1) Select the EMERGENCY LIGHTING switch to TEST.

2) Verify 6 cabin center lights come on.

3) Release switch from TEST to OFF.

4) Select the MASTER switch to ON (Pre Mod 6/2314); or select the EXTERNAL and BATTERY switches to ON (Post Mod 6/2314).

5) Move to ARM.

6) Check that the cabin lights are OFF. Confirm CABIN GENERAL light switch is OFF.

7) Select the MASTER switch to OFF (Pre Mod 6/2314); or select the EXTERNAL and BATTERY switches to OFF (Post Mod 6/2314).

8) Verify cabin lights come on.

9) Move EMERGENCY LIGHTING switch to OFF.

10) Verify lights are off.

This Page Intentionally Left Blank