Flap/Elevator Interconnect Trim Tab – Maintenance Practices

1. Removal/Installation

CAUTION **IF REMOVING OR INSTALLING CONTROL CABLES, DISCONNECT MAIN BATTERY (REFER TO 24-30-31, MAIN BATTERY SYSTEM – MAINTENANCE PRACTICES, PARA 2.), AVIONICS START BATTERY (IF INSTALLED, REFER TO 24-30-32, AVIONICS START BATTERY (MOD 6/2315) – GENERAL DATA, PARA 4.) AND EMERGENCY BATTERY (IF INSTALLED, REFER TO 33-50-01, EMERGENCY LIGHTING BATTERY – GENERAL DATA, PARA 1.) AND DISCONNECT GROUND POWER.**

A. Remove Trim Tab

1) Disconnect control rod at trim tab.

Note If replacement sleeve is available, existing sleeve may be cut and discarded.

2) Ease back plastic sleeve at junction of the two hinge pins to enable hinge pins to be withdrawn.

3) Support tab and withdraw inboard and outboard hinge pins.

B. Install Trim Tab

1) Ensure that ends of hinge pins are free from burrs or sharp edges and lightly lubricate with lubricant specified in 12-20-10, Lubrication – General Data.

2) Align hinge components on trim tab and elevator.

3) Insert inboard hinge pin at hinge gap and install plastic sleeve.

4) Insert outboard hinge pin and locate inboard end in sleeve. Ensure that ends of pins are aligned.

5) Connect control rod to tab with bolt, washer, nut and cotter pin.

6) Check trim tab control surface clearances (refer to 27-00-00, Flight Controls – General Data).

7) Operate flaps up and down and check interconnect system for full and free range of movement.

Note If tab or elevator has been repaired, or has had additional paint applied, the elevator assembly must be balanced as detailed in Structural Repair Manual PSM 1-6-3.

This Page Intentionally Left Blank