Fuel Cell Sump Plate – Maintenance Practices

1. Removal/Installation

   A. Remove Fuel Cell Sump Plate

      1) Ensure POWER SOURCE switch is OFF (Pre Mod 6/2314); or BATTERY and EXTERNAL switches are OFF (Post Mod 6/2314), crossfeed valve is closed, and wing fuel tank switches (if fitted) are OFF.

      2) Drain fuel from forward tank if No. 1, 2, 3 and/or 4 cell sump plates are to be removed. Drain fuel from aft tanks 5,6,7,8, if cell sump plates are to be removed. Drain both tanks if No. 5 and/or 6 cell sump plates are to be removed. (Refer to 12-10-10, Fuel System – General Data).

      3) Remove access panel from underside of fuselage.

      4) Disconnect electrical leads from fuel capacitor unit, switches and pumps, where applicable.

      5) Disconnect external fuel lines. Remove fuel line from sump plate of No. 4 cell to sump plate of No. 6 cell, if No. 5 cell sump plate is to be removed.

      6) Remove bolts securing sump plate, then lift up sump plate, turn and lower from cell. If No. 6 cell sump plate is being removed, remove crossfeed valve (refer to 28-20-21, Crossfeed Valve – Maintenance Practices), lower sump plate sufficiently from cell to disconnect two internal engine feed lines and then remove.

      7) Cap open lines.

   B. Install Fuel Cell Sump Plate

      CAUTION **WHEN SERVICING EQUIPMENT ON SUMP PLATES REMOVED FROM FUEL CELLS NO. 4 AND 5, ENSURE CONNECTIONS TO SUMP PLATE OF THE LEVEL CONTROL VALVE AND OF FLEXIBLE HOSE FROM BOOST PUMPS ARE CORRECTLY LOCATED AND NOT INTERCHANGED. THE FLEXIBLE HOSE FROM BOOST PUMPS MUST MATE WITH THE MACHINED TEE FITTING MOUNTED ON SUMP PLATE LOWER SURFACE TO ENSURE UNINTERRUPTED FUEL SUPPLY TO ENGINES.**

      1) If No. 6 cell sump plate is to be installed, connect two internal engine feed lines, and install crossfeed valve. (Refer to 28-20-21, Crossfeed Valve – Maintenance Practices).

      2) Insert sump plate through cell aperture, position correctly and secure bolts. Determine run down torque of each bolt and record value at each location. Tighten each bolt to its recorded run down torque plus 45–50 pound inches. Tighten bolts in a crisscross pattern alternately torquing opposite fasteners.

      3) Connect external fuel lines.

      4) Connect electrical leads to fuel capacitor unit, switches and pumps, if applicable.

      5) Check for fuel leaks.

      6) Install access panel.

This Page Intentionally Left Blank