Aileron Trim Tab Actuator – Maintenance Practices

1. Removal/Installation

   A. Remove Aileron Trim Tab Actuator Assembly

      1) Apply DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

      2) Operate aileron trim tab switch to LW DN until trim tab actuator is fully retracted.

      3) Disconnect DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

      4) Disconnect actuator rod end from aileron trim tab.

      5) Supporting actuator, remove six screws securing actuator bracket assembly to aileron.

      6) Gently lower actuator and disconnect electrical wiring from actuator. Remove actuator.

   B. Install Aileron Trim Tab Actuator Assembly

      1) Check replacement actuator for signs of damage and ensure actuator rod is fully retracted.

      2) Position actuator and connect electrical wiring.

      3) Secure actuator to aileron using six screws.

      4) Secure actuator rod end to trim tab using bolt, washer and nut. Secure nut with cotter pin.

      5) Rig aileron trim tab system (refer to 27-13-00, Aileron Trim Tab System – General Data).

      6) Do a function test for aileron trim tab position potentiometer as per section 27-13-21, Aileron Trim Tab Position Transmitter – Maintenance Practices, Para 3.A.

This Page Intentionally Left Blank