Rudder Trim Tab – Maintenance Practices

1. Removal/Installation

A. Remove Trim Tab

1) Disconnect control rod at trim tab and sensor wiring at WL 134.55.

2) Disengage lower end of hinge pin from retaining clip on rudder.

3) Support tab and withdraw hinge pin.

B. Install Trim Tab

1) Lightly lubricate hinge pin. Refer to 12-20-00, Lubrication – General Data for lubricant specification.

2) Align hinge components on tab and rudder.

3) Insert hinge pin from lower end of tab and engage lower end of pin in retaining clip on rudder.

4) Connect control rod to tab with bolt, washer, nut and cotter pin and sensor wiring at WL 134.55.

5) Check trim tab control surface clearances (refer to 27-10-00, Flight Controls – General Data).

6) Operate rudder and trim tab system and check for full and free range of movement.

7) Do function test for the rudder trim tab potentiometer indicator as per 27-23-31, Rudder Angle Position Indicator - General data, Para 3.A.12).

8) If adjustment is required for the rudder trim tab potentiometer adjust as per 27-23-31, Rudder Angle Position Indicator - General data, Para 3.A.

Note If tab or rudder has been repaired, or has had additional paint applied, the rudder assembly must be balanced as detailed in Structural Repair Manual PSM 1–6–3.

**This Page Intentionally Left Blank**