Fuel Filter (Mod 6/2006) – Maintenance Practices

1. Servicing

   A. Service Fuel Filter

      1) With electrical power on, close fuel emergency shut-off valve and ensure wing fuel tank switches (if fitted) are OFF.

      2) Switch on fuel booster pumps.

      3) Position container underneath filter and open drain valve.

      4) Ensure fuel filter is clear of water, switch off booster pumps and close drain valve.

      5) Disconnect flexible drain hose at elbow.

      6) Unscrew fuel filter element housing.

      7) Remove filter element.

      8) Inspect filter element and O-ring, discard if necessary.

      9) Clean housing with varsol.

      10) Dry components.

      11) Install O-ring to housing.

      12) Position housing, tighten and lockwire.

      13) Connect flexible drain hose at elbow.

      14) Switch on fuel booster pumps. Check for fuel leaks.

      15) Position container under filter and open drain valve.

      16) When fuel flow is free of air, close drain valve and switch off fuel booster pumps, and open fuel emergency shut-off valve.

This Page Intentionally Left Blank