Fuel Low Level Indicating System – General Data

1. General

Low fuel level in the fuselage tanks is indicated by CAS messages displayed on the flight display panel marked Fwd Fuel Qty Low and Aft Fuel Qty Low. Each caution message is operated by a float switch mounted on the sump plate of No. 4 cell for the forward tank and No. 5 cell sump plate for aft tank or by the fuel quantity system total for each tank. The fuel low level indication is activated when either the float switch is triggered or the fuel quantity system for each tank reaches the applicable value. With the aircraft in a level flight position and booster pumps on, the applicable tank fuel low level caution message illuminates when 75 pounds of usable fuel remain in the forward tank collector cell, or 110 pounds of usable fuel remain in the aft tank collector cell. Refer to PSM 1-64-2W for electrical schematic.

2. Adjustment/Test

A. Function Test

Note To test the operation of the fuel low level indicating system, refer to 28-00-00, Fuel (Mod 6/2006) – General Data, Para 2.B.

This Page Intentionally Left Blank