Crossfeed Valve Position Indicating System (Mod 6/2006) – General Data

1. General

Indication of the position of the crossfeed valve is presented as a green fuel pane text block “Crossfeed” if the valve is open.

A “Fuel Crossfeed Fail” caution message will be displayed if the position of the crossfeed valve does not match the position of the FUEL SELECTOR switch. If the crossfeed valve caution message is active and the position of the FUEL SELECTOR switch is to BOTH ON (AFT or FWD), the text block “Crossfeed” will be displayed in amber text.

This Page Intentionally Left Blank