Hydraulic System Filter – Maintenance Practices

1. Servicing

   A. Replace Filter Element

      1) Discharge airframe system accumulator pressure by operating wing flaps.

      2) Open access panel on underside of nose section. (Refer to 12-00-00, Servicing – General Data).

      3) Cut lockwire, unscrew and remove filter bowl complete with element from underside of power package tray.

      4) Drain filter bowl, wash with a cleaning solvent, and dry with a filtered air supply.

      5) Check gasket and backup ring, and replace gasket if flattened or chipped.

      6) Fill filter bowl with clean hydraulic fluid, Specification MIL–H–5606, and install bowl complete with new element, serviceable gasket and backup ring.

      7) Wet the filter bowl threads with MIL-H-5606, and torque filter bowl to 75 in-lbs.

      8) Lockwire filter bowl to tray.

      9) Close access panel. (Refer to 12-00-00, Servicing – General Data).

This Page Intentionally Left Blank