Fire Extinguishing Bottle – Maintenance Practices

1. Servicing

   A. Servicing of Fire Extinguisher Bottle

      1) Ensure that no leakage or damage to bottle or attachments is evident.

      2) Remove bottle and weigh, check that weight of charged bottle is within 0.25 pounds of total weight stamped on data plate.

         Note Damaged or underweight bottles must be replaced.

      3) Install serviceable fire extinguisher bottle.

2. Removal/Installation

   A. Remove Fire Extinguisher Bottle

      WARNING FROSTBITE OR LOW TEMPERATURE BURNS WILL RESULT IF HALON 1301 (TRIFLUOROBROMOMETHANE CBRF3) IS ALLOWED TO CONTACT THE SKIN. STORE CBRF3 BOTTLES IN AN ISOLATED AND WELL VENTILATED AREA. EACH BOTTLE MUST BE STORED WITH NECK FACING UP AND PROTECTIVE CAPS INSTALLED TO NECK AND SAFETY OUTLETS.

      1) Switch OFF aircraft electrical power (refer to 24-00-00, Electrical Power – General Data).

      2) Lower the engine cowling.

      3) Disconnect electrical connector from extinguisher bottle valve.

      4) Disconnect discharge pipe to engine accessory compartment, and thermal pressure pipe to red disc, at fire extinguisher bottle.

      5) Support bottle, remove bolts securing clamps and remove bottle.

   B. Install Fire Extinguisher Bottle

      CAUTION CHARGED BOTTLES MUST BE HANDLED WITH CARE TO AVOID DAMAGING THE SEAL. BOTTLES MUST NOT BE DISCHARGED IN CONFINED AREAS. IF A BOTTLE IS ACCIDENTALLY DISCHARGED, THE AREA MUST BE WELL VENTILATED BEFORE PERSONS ARE ALLOWED TO ENTER.

      1) Check replacement fire extinguisher bottle for evidence of leaks and damage. Check that weight is within 0.25 pounds of total weight stated on data plate.

      2) Check that bottle pressure is acceptable in accordance with the manufacturers' data plate (450 psi at 70°F).

      3) Position fire extinguisher bottle in aircraft.

      4) Install the two bolts securing clamps.

      5) Connect and secure discharge pipe to engine accessory compartment, and thermal pressure pipe to red disc, at fire extinguisher bottle.

      6) Replace indicating discs as necessary (refer to 26-20-21, Indicating Discs – Maintenance Practices).

      7) Connect and secure electrical connector to extinguisher bottle valve.

      8) Secure engine cowlings.

This Page Intentionally Left Blank