Indicating Discs – Maintenance Practices

1. Servicing

   A. Replace Fire Extinguisher Bottle Indicating Discs

      1) Remove split ring from disc assembly.

      2) In the case of a red disc, replace disc only, but for a yellow disc, replace disc and retainer assembly.

      3) Reinstall split ring, ensuring that it is correctly seated in groove.

This Page Intentionally Left Blank