Engine Model(s): PT6A

73-10-06

FUEL DRAIN VALVES - DESCRIPTION AND OPERATION

1. Description and Operation

The drain valves installation comprises two valves and gaskets installed in the gas generator case at the 6 o'clock position, one to the rear of the engine mounts and the other adjacent to Flange C. The valves let all residual fuel accumulated in the bottom of the gas generator case to drain to an airframe collection point when the engine is shut down. The forward valve also accommodates any residual drainage from the bottom of the exhaust duct via a small hole in the bottom of the duct rear cone immediately in front of the valve. Both drains are closed during engine operation by the action of P3 air pressure against the spring-loaded valves.

Printed on 10/NOV/26 P&WC Proprietary – subject to restrictions in Technical Data Agreement