Engine Model(s): PT6A

76-10-00

PROPELLER REVERSING LINKAGE - DESCRIPTION AND OPERATION

1. Description and Operation

The propeller reversing linkage provides the mechanical link between the power control lever and the propeller reversing lever. The rear end of the push-pull wire rope linkage is secured to the propeller control cam (of the cam assembly at Flange G on the accessory gearbox) by the fork end of the rear casing terminal. The front end of the wire rope is secured to the propeller reversing lever by the fork end of the front casing terminal. Both casing terminals incorporate swivel joints to accommodate alignment. The push-pull wire rope is housed in a self-lubricated stainless steel casing assembly which passes through the engine front lifting bracket and center and rear fireseals. A removable plate is incorporated at the front lifting bracket to enable the front end of the linkage to be disconnected from the engine without disturbing any linkage adjustments during, for instance, engine power section removal.

Printed on 10/NOV/26 P&WC Proprietary – subject to restrictions in Technical Data Agreement