

# **BC66** Application Design Note

### **LPWA Module Series**

Rev. BC66\_Application\_Design\_Note\_V1.0

Date: 2019-06-23

Status: Released



Our aim is to provide customers with timely and comprehensive service. For any assistance, please contact our company headquarters:

### **Quectel Wireless Solutions Co., Ltd.**

Building 5, Shanghai Business Park Phase III (Area B), No.1016 Tianlin Road, Minhang District, Shanghai, China 200233

Tel: +86 21 5108 6236 Email: <u>info@quectel.com</u>

#### Or our local office. For more information, please visit:

http://www.quectel.com/support/sales.htm

### For technical support, or to report documentation errors, please visit:

http://www.quectel.com/support/technical.htm

Or email to: support@quectel.com

#### **GENERAL NOTES**

QUECTEL OFFERS THE INFORMATION AS A SERVICE TO ITS CUSTOMERS. THE INFORMATION PROVIDED IS BASED UPON CUSTOMERS' REQUIREMENTS. QUECTEL MAKES EVERY EFFORT TO ENSURE THE QUALITY OF THE INFORMATION IT MAKES AVAILABLE. QUECTEL DOES NOT MAKE ANY WARRANTY AS TO THE INFORMATION CONTAINED HEREIN, AND DOES NOT ACCEPT ANY LIABILITY FOR ANY INJURY, LOSS OR DAMAGE OF ANY KIND INCURRED BY USE OF OR RELIANCE UPON THE INFORMATION. ALL INFORMATION SUPPLIED HEREIN IS SUBJECT TO CHANGE WITHOUT PRIOR NOTICE.

#### **COPYRIGHT**

THE INFORMATION CONTAINED HERE IS PROPRIETARY TECHNICAL INFORMATION OF QUECTEL WIRELESS SOLUTIONS CO., LTD. TRANSMITTING, REPRODUCTION, DISSEMINATION AND EDITING OF THIS DOCUMENT AS WELL AS UTILIZATION OF THE CONTENT ARE FORBIDDEN WITHOUT PERMISSION. OFFENDERS WILL BE HELD LIABLE FOR PAYMENT OF DAMAGES. ALL RIGHTS ARE RESERVED IN THE EVENT OF A PATENT GRANT OR REGISTRATION OF A UTILITY MODEL OR DESIGN.

Copyright © Quectel Wireless Solutions Co., Ltd. 2019. All rights reserved.



### **About the Document**

### **History**

Revision	Date	Author	Description
1.0	2019-06-23	Jacobi RAO	Initial



C	ontentsAb	oout the Document	2
Со	ntents		3
Ta	ble Index		4
Fig	jure Index		5
1	Introduction	on	6
2	Recommer	nded Design	7
	2.1. Powe	er-Sensitive Scenario	7
	2.1.1.	Recommended Software Design	8
	2.1.2.	Descriptions of Power Sensitive Scenario	9
	2.2. Pow	er Non-Sensitive Scenario.	10
	2.2.1.	Recommended Software Design	10
	2.2.2.	Descriptions of Power Non-Sensitive Scenario	11
3	Appendix		13



### **Table Index**

TABLE 1: STEPS OF POWER SENSITIVE SCENARIO	9
TABLE 2: STEPS OF POWER NON-SENSITIVE SCENARIO	11
TABLE 4: REFERENCES	13
TABLE 5: TERMS AND ABBREVIATIONS	13



### Figure Index

FIGURE 1: PROCEDURE OF POWER-SENSITIVE SCENARIO	8	3
FIGURE 2: PROCEDURE OF POWER-INSENSITIVE SCENARIO	1 <sup>.</sup>	1



## 1 Introduction

This document is mainly described for easily application software design, including some typical scenarios introduction and corresponding recommended software design flow, which is applicable to following Quectel modules:

- BC66NB
- BC66-NA



# 2 Recommended Design

### 2.1. Power-Sensitive Scenario

For power-sensitive scenario, we recommend to enable PSM and eDRX mode.

### **NOTE**

- 1. PSM and eDRX are enabled in default.
- 2. The configuration for PSM and eDRX should be negotiated with network provider.



### 2.1.1. Recommended Software Design




Figure 1: Procedure of Power-Sensitive Scenario



### 2.1.2. Descriptions of Power Sensitive Scenario

**Table 1: Descriptions of Power Sensitive Scenario** 

Steps	Brief Introduction	Description
1	Power Supply	Supply the power to module.
2	Power On	Pull down power key for at least 500ms.
3	AT+IPR?	Module is in auto-baud mode in default. MCU needs to send "AT" to synchronize the communication baud rate with module or send "AT+IPR=XXX" to fixed the baudrate. In order to avoid frequently wiping the flash, please use AT command "AT+ipr?" to querry the baudrate setting currentty.
4	AT+CPIN?	Used to check the current SIM state.
5	AT+CIMI AT+QCCID	Used to query the IMSI&ICCID of SIM.
6	AT+QCGDEFCONT	Used to configure the APN and PDN TYPE for default PDN which is indicated by CID <1>. Need to reboot the module to take effect the configuration.
7	AT+QNBIOTEVENT AT+CEREG=5	Used to enable the URC presentation for PSM event &EPS network registration status.
8	AT+CGATT? AT+CEREG?	Used to query current PS attach states & EPS network registration status. Although we recommend the waithing time of network registration is 300s, it usually complete the procedure within 10s. So please query the status every 10s to ensure it can go to the next step on time.
9	AT+CGPADDR?	Used to query the IP address which is allocated by network.
10	+IP: xxx	This URC is prompted when PDP context is successfully associated with specified PDN link. MCU can't perform any data transfer before this URC.
11	AT+CPSMS	Used to set the requested extended T3412 and T3324, network provided value can be verified by <b>AT+CEREG?</b>
12	AT+CEDRXS	Used to set the requested eDRX period, network provided value can be verified by <b>AT+CEDRXRDP</b>
13	AT+CFUN=0	Used to switch off the modem when module can't register to network for a long time (> 300s).
14	AT+QCSEARFCN	Used to clear the stored EARFCN list for the Module.
15	AT+QRST=1	Used to reset the module



16 **POWER DOWN** Cut off the power supply of module

### 2.2. Power Non-Sensitive Scenario.

For power non-sensitive scenario, we recommend to disable PSM and eDRX mode for low latency.

### 2.2.1. Recommended Software Design






Figure 2: Procedure of power-insensitive scenario

### 2.2.2. Descriptions of Power Non-Sensitive Scenario

**Table 2: Descriptions of Power Non-Sensitive Scenario** 

Steps	Brief Introduction	Description
1	Power Supply	Supply the power to module.



2	Power On	Pull down power key for at least 500ms.
3	AT+IPR?	Module is in auto-baud mode in default. MCU needs to send "AT" to synchronize the communication baud rate with module or send "AT+IPR=XXX" to fixed the baudrate. In order to avoid frequently wiping the flash , please use AT command "AT+ipr?" to querry the baudrate setting currentty.
4	AT+CPIN?	Used to check the current SIM state.
5	AT+CIMI AT+QCCID	Used to query the IMSI&CCID of SIM.
6	AT+QCGDEFCONT	Used to configure the APN and PDN TYPE for default PDN which is indicated by CID <1>. Need to reboot the module to take effect the configuration.
7	AT+CGATT? AT+CEREG?	Used to query current PS attach states & EPS network registration status. Although we recommend the waithing time of network registration is 300s, it usually complete the procedure within 10s. So please query the status every 10s to ensure it can go to the next step on time.
8	AT+QNBIOTEVENT AT+CEREG=5	Used to enable the URC presentation for PSM event &EPS network registration status.
9	AT+CGPADDR?	Used to query the IP address which is allocated by network.
10	+IP: xxx	This URC is prompted when PDP context is successfully associated with specified PDN link. MCU can't perform any data transfer before this URC.
11	AT+CPSMS=0	Used to disable PSM function.
12	AT+CEDRXS=0	Used to set the disable eDRX function.
13	AT+CFUN=0	Used to switch off the modem when module can't register to network for a long time.
14	AT+QCSEARFCN	Used to clear the stored EARFCN list for the Module.
15	AT+QRST=1	Used to reset the module
16	POWER DOWN	Cut off the power supply of module



# 3 Appendix

### **Table 3: References**

SN	Document Name	
[1]	Quectel_BC66_AT_Commands_Manual	
[2]	Quectel_BC66_Network_Searching_Scheme_Introduction	

### **Table 4: Terms and Abbreviations**

Document Name
Access Point Name
E-UTRAN Absolute Radio Frequency Channel Number
Extended Discontinuous Reception
Evolved Packet System
Integrated Circuit Card Identification
International Mobile Subscriber Identity
Media Control Unit
Public Data Network
Packet Data Protocol
Packet Service/Packet Switch
Power Saving Mode
(Universal) Subscriber Identity Module
Unsolicited Result Code