

비행전후(PR/PO 또는 LSC) 점검 항목(제6조 관련)

B737 CHECK LIST

점검항목 (대분류)	점검세부항목
ARRIVAL	1. Perform an A/C check for parking and ground safety condition.
WALK AROUND	ENGINE AND NACELLE
	1. Perform an inspection of all visible areas of engine/nacelle for obvious damage, leakage, obstruction safety condition and security.
	2. Perform engine and IDG oil level check with sight gage and add oil as required.
	L/G & WHEEL WELL
	1. Perform an inspection of nose and main landing gears(including wheel/tires/doors) and wheelwell areas for obvious damage, leakage, tire wear, safety condition and security.
	2. Perform a visual check of left & right brake condition and wear pins for minimum extension.
	3. Perform a nose and main tire pressure check.
	FUSELAGE, WING & EMPENNAGE
	1. Perform an Inspection of all visible portion of the fuselage, wings, flight control surfaces and empennage for obvious damage, leakage, obstruction, ice, frost condition and security.
	2. Perform an general visual Inspection of fuselage in areas of drain masts and drains for fluid leakage.
	3. Perform a visual check of tail skid for evidence of a tail strike.
	4. Perform a Fwd & Aft cargo compartments general condition and security check.
	5. Perform an operation and illumination check of all exterior lights.
	6. Perform a visual inspection of ram air inlet/exhaust doors and cabin pressure outflow valve to ensure there are no obstructions.
	7. Perform a visual inspection for missing or damaged navigation and communication antennae.
	8. Perform a visual inspection of static ports, total air temperature probe, pitot static probes, and angle of attack vanes for obvious damage.
	9. Verify existence of green disk at the overboard pressure relief port.
	COCKPIT AND CABIN
	1. Perform a Flight & Maintenance log check and rectify all flightd effects.
	2. Perform an open defer item check, which have maintenance action to be performed each flight or periodically.
	3. Perform an APU oil level check and add oil as required.
	4. Perform a hydraulic fluid level check and add fluid as required.
	5. Perform an operational check of fire warning system (use the FIRE/OVHT test switch).
	6. Perform a crew oxygen system check for correct pressure.
	7. Perform an engine oil check and add as required.
	8. Perform a condition check of SPCU (Standby Power Control Unit).
	9. Perform an operation test of CVR (Cockpit Voice Recorder) & FDR (Flight Data Recorder).
	10. Perform a condition check of flight deck door access system.
	11. Perform a check for cockpit window and cockpit general condition.
	12. Perform a check cabin log discrepancy and defer item.
DEPARTURE	1. Certify accomplishment of inspection and maintenance in Flight & Maintenance Log.
	2. Make sure that L/G safety lock pins are removed before flight.
	3. Perform an Engine intakes check for free from F.O. material.
	4. Make sure that all access doors, service panels, cargo compartment doors, water fill & drain caps, toilet drain plugs and all engine cowl latches are safely closed & locked.

* 총 점검항목 30개 (ARRIVAL 1개, WALK AROUND 25개, DEPARTTURE 4개)

A320F CHECK LIST

점검항목 (대분류)	점검세부항목
WALK AROUND	FUSELAGE/WING/EMPENNAGE
	1. CHECK – All visible exterior areas of the fuselage, empennage and flight control surfaces from the ground level for obvious damage and leakage.
	2. CHECK – All visible exterior areas of tail section from the ground level for obvious damage and leakage.
	3. CHECK – All visible exterior areas of the wing flight control surfaces, wing lower surfaces and tip from the ground level for obvious damage and leakage.
	4. CHECK – Static ports, pitot probes, TAT/AOA sensors for missing and obvious damage
	5. CHECK – Communication & navigation antennas from the ground level for missing and obvious damage.
	6. CHECK – Vent surge tank burst disc for presence
	LANDING GEAR
	1. CHECK – Landing gear and doors for obvious damage and hydraulic leakage.
	2. CHECK – Landing gear, doors and wheel well area for obvious damage and hydraulic leakage (For wheel well area, main station Only).
	3. Perform the nose and main tire pressure check.
	4. CHECK - Main landing gear brakes for wear and hydraulic leakage
	ENGINE
	1. CHECK – Engine cowls, spinner, fan blades and exhaust area for obvious damage and leakage.
	2. CHECK - Engine oil quantity through the sight glass and add as necessary.
	NACELLE/PYLON
	1. CHECK – Nacelle/pylon and access panels for obvious damage and leakage.
	COCKPIT
	1. CHECK – Flight & Maintenance Log and maintenance messages for malfunctions.
	2. Perform a check cabin log discrepancy and defer item.
	3. CHECK – Crew oxygen pressure on ECAM DOOR/OXY page
	4. CHECK – Hydraulic fluid level on the ECAM HYD page and add as necessary
	5. CHECK – “APU LOW OIL LEVEL” message on the ECAM APU page and add as necessary.
	6. CHECK – Engine oil filter CLOG indication on the ECAM ENG page
	7. Perform an operation check of Engine/APU fire and overheat detection system LOOP/SQUIB using ENG 1 & 2 and APU Fire/Test pushbutton switches
	8. Perform an operation check of all exterior lights.
	9. Perform an operation check of dome lights.
DEPARTURE	1. Make sure if removed landing gear ground lock pins & sleeves are in the L/G Ground Lock Pin box in the cockpit before flight.
	2. CHECK – Flight & Maintenance Log and make sure all malfunctions have been cleared or deferred
	3 CHECK – All circuit breakers, switches and levers in the cockpit for normal position.
	4 CHECK – Engine cowls and doors for security, and detailed inspect fan cowl & thrust reverser latches are closed correctly. (If departure check is done within two hours after arrival check, this check is not necessary.).
	5. Perform an Engine intakes check for free from F.O. material(If departure check is done within two hours after arrival check, this check is not necessary.).
	6. Perform an operation test of CVR (Cockpit Voice Recorder) by using test switch.
	7. Check No fault-message on the ECAM/CFDS related to DFDR
	8. CHECK – Service doors including fueling station doors are closed and latches are locked

* 총 점검항목 30개(WALK AROUND 22개, DEPARTURE 8개)