

Scanner Engine API Instruction

Exported on 01/15/2026 By Neil

Version.....	4
I. Introduction.....	4
II. Field Summary	6
III. Method Summary	6
IV. Method Detail.....	9
1 barcodePrefix - set the barcode data append prefix	9
2 barcodeSuffix - set the barcode data append suffix	9
3 broadcastSetting - set the broadcast output parameters when successful decoding.....	10
4 close - close scanner engine.....	10
5 decodeSound - set the decode success audio	11
6 decodeVibration - set the vibration enable when successful decoding.....	11
7 disableScanKey - Disable scan key.....	12
8 getDecodeMode - get scanner trigger mode	12
9 getParameterInt - get scan barcode related parameter	13
10 getParameterString - get scan barcode related parameter	13
11 getScanKeyStatus - get scan key enable	14
12 getScanMode - get scanner trigger mode.....	14
13 open - open scanner engine	15
14 release - release scanner	15
15 reset - reset scanner	16
16 setDecodeCallback - set the scanner interface callback.	16
17 setDecodeMode - set barcode decode output mode.....	17
18 setParameterInt - Set scan barcode related parameter	18
19 setParameterString - Set scan barcode related parameter	18
20 setScanMode - set scanner trigger mode	19
21 startDecode - Turn on the fill light and start scanning	19
22 stopDecode - Turn off the fill light to stop scanning the code	20

V、 Appendix ScannerConstant.ParamKey Parameter Values20

Version

Version	Author	Date	Notes
A	Neil	Dec 31, 2025	init

I. Introduction

Package :

com.android.hdms.scanner

Class ScanManager

java.lang.Object

com.android.hdms.base.DeviceBaseManager

com.android.hdms.scanner.ScanManager

```
public class ScanManager extends DeviceBaseManager
```

This class provides an interface description for decoding calls to the system scanner.

To decode barcodes using this class, follow these steps:

1. Obtain an instance of ScanManager object with:

```
ScanManager mScanManager = (ScanManager)  
HDMSManager.getInstance().getModuleManager(HDMSManager.MODULE_TYPE.SCANNER);
```

2. Call `open()` to power on the bar code reader(The default is enabled unless the scanner has been turned off.).

3. If necessary, get the current settings with `getParameterInt(String, int defvalue)`.

4. If necessary, modify the returned `ScannerConstant.ParamKey` object value and call `setParameterInt(String, int)` or `setParameterString(String, String)`.

Example:

```
public void getDecodeMode() {  
    int mode =  
mScanManager.getParameterInt(ScannerConstant.ParamKey.DECODE_OUTPUT_MODE,  
ScannerConstant.DecodeMode.FOCUS);  
}
```

```

}
public void setDecodeMode() {
    int ret = mScanManager.setDecodeMode(ScannerConstant.DecodeMode.BROADCAST);
}

```

5. If necessary, set the current broadcast intent settings.

Intent mode allows the captured data to be sent as an implicit Intent. Application interested in the scan data should register default action as BROADCAST_BARCODE_ACTION broadcast receiver.

```

public void setDecodingIntent() {

    mScanManager.setParameterString(ScannerConstant.ParamKey.BROADCAST_INTENT_ACTION_NAME, "broadcast_barcode_data_action");

    mScanManager.setParameterString(ScannerConstant.ParamKey.BROADCAST_INTENT_EXTRA_NAME, "dataString");
}

```

6. To begin a decode session, call startDecode().

6.1 If the configured ScannerConstant.ParamKey.DECODE_OUTPUT_MODE is ScannerConstant.DecodeMode.BROADCAST. Your registered broadcast receiver will be called when a successful decode occurs.

In the onReceive(Context context, Intent intent) method, get the information as follow:

```

String dataStr=intent.getStringExtra(BROADCAST_BARCODE_EXTRA_DATA);
byte[] dataArray=intent.getByteArrayExtra(BROADCAST_BARCODE_EXTRA_BYTES);
int length=intent.getIntExtra(BROADCAST_BARCODE_EXTRA_LENGTH,0);
byte type=intent.getByteExtra(BROADCAST_BARCODE_EXTRA_TYPE, (byte)0);
byte[] aim=intent.getByteExtra("aimCodeId");
String symName=intent.getStringExtra("scandata_symbology");

```

The information includes barcode data, barcode data length, and barcode type (symbol system).

6.2 If DecodeCallback is used, the onDecodeComplete callback will be invoked upon successful decoding.

```

private DecodeCallback callback = new DecodeCallback.Stub() {
    @Override
    public void onDecodeComplete(Bundle bundle) throws RemoteException {
        String barcode = bundle.getString(ScanManager.BROADCAST_BARCODE_EXTRA_DATA);
        int length = bundle.getInt(ScanManager.BROADCAST_BARCODE_EXTRA_LENGTH);
        int type = bundle.getInt(ScanManager.BROADCAST_BARCODE_EXTRA_TYPE);
        Log.d(TAG, "onDecodeComplete barcode = "+ barcode+" length = "+ length + " type = "+type);
    }
};
mScanManager.setDecodeCallback(callback);

```

7. Call stopDecode() to end the decode session.

8.Call close() ()} to power off the barcode reader(Do not turn off unless absolutely necessary.).

II. Field Summary

Field

Modifier and Type	Field	Description
static java.lang.String	BROADCAST_BARCODE_ACTI ON	barcode broadcast name
static java.lang.String	BROADCAST_BARCODE_EXTR A_BYTES	extra key name.Acquired raw (unmodified) data as an array list of byte arrays
static java.lang.String	BROADCAST_BARCODE_EXTR A_DATA	barcode broadcast result key name
static java.lang.String	BROADCAST_BARCODE_EXTR A_LENGTH	barcode broadcast length key name
static java.lang.String	BROADCAST_BARCODE_EXTR A_TYPE	barcode broadcast barcode type key name

III. Method Summary

Modifier and Type	Method	Description
boolean	barcodePrefix(String prefix)	set the barcode data append prefix

Modifier and Type	Method	Description
boolean	barcodeSuffix(String suffix)	set the barcode data append suffix
boolean	broadcastSetting(String action, String extra)	set the broadcast output parameters when successful decoding
boolean	close()	close scanner engine
boolean	decodeSound(int status)	set the decode success audio
boolean	decodeVibration(boolean status)	set the vibration enable when successful decoding
boolean	disableScanKey(boolean enable)	Disable scan key
int	getDecodeMode()	get scanner trigger mode
int	getParameterInt(java.lang.String key, int defvalue)	get scan barcode related parameter
java.lang.String	getParameterString(java.lang.String key)	get scan barcode related parameter
boolean	getScanKeyStatus()	get scan key enable
int	getScanMode()	get scanner trigger mode
boolean	open()	open scanner engine

Modifier and Type	Method	Description
void	release()	release scanner
boolean	reset()	reset scanner
void	setDecodeCallback(com.android.scanner.DecodeCallback callback)	set the scanner interface callback.
int	setDecodeMode(int mode)	set barcode decode output mode
int	setParameterInt(java.lang.String key, int value)	Set scan barcode related parameter
int	setParameterString(java.lang.String key, java.lang.String value)	Set scan barcode related parameter
int	setScanMode(int mode)	set scanner trigger mode
boolean	startDecode()	Turn on the fill light and start scanning
boolean	stopDecode()	Turn off the fill light to stop scanning the code

IV. Method Detail

1 barcodePrefix - set the barcode data append prefix

Definition	public boolean barcodePrefix(java.lang.String prefix)		
Instruction	set the barcode data append prefix		
Parameters	Key	Type	Note
	prefix	String	Barcode result prefix
Return	Key	Type	Note
	result	boolean	true Success false Failure

2 barcodeSuffix - set the barcode data append suffix

Definition	public boolean barcodeSuffix(java.lang.String suffix)		
Instruction	set the barcode data append suffix		
Parameters	Key	Type	Note
	suffix	String	Barcode resultsuffix
Return	Key	Type	Note
	result	boolean	true Success false Failure

3 broadcastSetting - set the broadcast output parameters when successful decoding

Definition	public boolean broadcastSetting(java.lang.String action, java.lang.String extra)		
Instruction	set the broadcast output parameters when successful decoding		
Parameters	Key	Type	Note
	action	String	broadcast Action
	extra	String	broadcast Extra
Return	Key	Type	Note
	result	boolean	true Success false Failure

4 close - close scanner engine

Definition	public boolean close()		
Instruction	close scanner engine		
Parameters	Key	Type	Note
Return	Key	Type	Note
	result	boolean	true Success false Failure

5 decodeSound - set the decode success audio

Definition	public boolean decodeSound(int status)		
Instruction	set the decode success audio		
Parameters	Key	Type	Note
	status	int	integer[0,9] ●Audio None ●Audio 1 ●Audio 2 ●Audio 3 ●Audio 4 ●Audio 5 ●Audio 6 ●Audio 7 ●Audio 8 ●Audio 9
Return	Key	Type	Note
	result	boolean	true Success false Failure

6 decodeVibration - set the vibration enable when successful decoding

Definition	public boolean decodeVibration(boolean status)		
Instruction	set the vibration enable when successful decoding		
Parameters	Key	Type	Note
	status	boolean	true open false close

Return	Key	Type	Note
	result	boolean	true Success false Failure

7 disableScanKey - Disable scan key

Definition	public boolean disableScanKey(boolean enable)		
Instruction	Disable scan key		
Parameters	Key	Type	Note
	status	boolean	true disable false enable
Return	Key	Type	Note
	result	boolean	true Success false Failure

8 getDecodeMode - get scanner trigger mode

Definition	public int getDecodeMode()		
Instruction	get scanner trigger mode		
Parameters	Key	Type	Note
Return	Key	Type	Note

	result	int	See @ScannerConstant.DecodeMode integer[0,6] ●Intent Output ●Direct Fill ●Clipboard ●Key Event Output ●Fill And Intent ●Replace Focus ●Input Method Output
--	--------	-----	--

9 getParameterInt - get scan barcode related parameter

Definition	public int getParameterInt(java.lang.String key, int defvalue)		
Instruction	get scan barcode related parameter		
Parameters	Key	Type	Note
	key	String	See @ScannerConstant.ParamKey
	defvalue	int	Default Value
Return	Key	Type	Note
	result	int	The value associated with this parameter

10 getParameterString - get scan barcode related parameter

Definition	public int getParameterString(java.lang.String key)		
Instruction	get scan barcode related parameter		
Parameters	Key	Type	Note

	key	String	See @ScannerConstant.ParamKey
Return	Key	Type	Note
	result	String	The value associated with this parameter

11 getScanKeyStatus - get scan key enable

Definition	public boolean getScanKeyStatus()		
Instruction	get scan key enable		
Parameters	Key	Type	Note
Return	Key	Type	Note
	result	boolean	true Enable false Disable

12 getScanMode - get scanner trigger mode

Definition	public int getScanMode()		
Instruction	get scanner trigger mode		
Parameters	Key	Type	Note
Return	Key	Type	Note

	result	int	See @ScannerConstant.ScannerMode integer[0,3] ●Press scanning and release stop ●Press scanning until timeout ●Continuous scanning ●Press Continuous scanning and release stop
--	--------	-----	--

13 open - open scanner engine

Definition	public boolean open()		
Instruction	open scanner engine		
Parameters	Key	Type	Note
Return	Key	Type	Note
	result	boolean	true Open false Close

14 release - release scanner

Definition	public void release()		
Instruction	release scanner		
Parameters	Key	Type	Note
Return	Key	Type	Note

--	--	--	--

15 reset - reset scanner

Definition	public boolean reset()		
Instruction	reset scanner		
Parameters	Key	Type	Note
Return	Key	Type	Note
	result	boolean	true Open false Close

16 setDecodeCallback - set the scanner interface callback.

Definition	public void setDecodeCallback(com.android.scanner.DecodeCallback callback)		
Instruction	set the scanner interface callback.		
Parameters	Key	Type	Note

	callback	DecodeCallback	Callback Method : onDecodeComplete bundle param : <table><tr><th>Key</th><th>Type</th><th>Note</th></tr><tr><td>scandata</td><td>String</td><td>Barcode result</td></tr><tr><td>scandata_symbolology</td><td>String</td><td>Barcode symbology</td></tr></table>	Key	Type	Note	scandata	String	Barcode result	scandata_symbolology	String	Barcode symbology
Key	Type	Note										
scandata	String	Barcode result										
scandata_symbolology	String	Barcode symbology										
Return	Key	Type	Note									

17 setDecodeMode - set barcode decode output mode

Definition	public int setDecodeMode(int mode)		
Instruction	set barcode decode output mode		
Parameters	Key	Type	Note
	mode	int	See @ScannerConstant.DecodeMode integer[0,6] •Intent Output •Direct Fill •Clipboard •Key Event Output •Fill And Intent •Replace Focus •Input Method Output
Return	Key	Type	Note
	result	int	0 Success Non-zero Failure

18 setParameterInt - Set scan barcode related parameter

Definition	public int setParameterInt(java.lang.String key, int value)		
Instruction	Set scan barcode related parameter		
Parameters	Key	Type	Note
	key	String	See @ScannerConstant.ParamKey
	value	int	Set parameter values
Return	Key	Type	Note
	result	int	0 Success Non-zero Failure

19 setParameterString - Set scan barcode related parameter

Definition	public int setParameterString(java.lang.String key, java.lang.String value)		
Instruction	Set scan barcode related parameter		
Parameters	Key	Type	Note
	key	String	See @ScannerConstant.ParamKey
	value	String	Set parameter values
Return	Key	Type	Note
	result	String	0 Success Non-zero Failure

20 setScanMode - set scanner trigger mode

Definition	public int setScanMode(int mode)		
Instruction	set scanner trigger mode		
Parameters	Key	Type	Note
	mode	int	See @ScannerConstant.ScannerMode integer[0,3] •Press scanning and release stop •Press scanning until timeout •Continuous scanning •Press Continuous scanning and release stop
Return	Key	Type	Note
	result	int	0 Success Non-zero Failure

21 startDecode - Turn on the fill light and start scanning

Definition	public boolean startDecode()		
Instruction	Turn on the fill light and start scanning		
Parameters	Key	Type	Note
Return	Key	Type	Note
	result	boolean	true Open false Close

22 stopDecode - Turn off the fill light to stop scanning the code

Definition	public boolean stopDecode()		
Instruction	Turn off the fill light to stop scanning the code		
Parameters	Key	Type	Note
Return	Key	Type	Note
	result	boolean	true Open false Close

V、Appendix ScannerConstant.ParamKey Parameter Values

Refer to the parameter settings function of the Ezkit-Scanner device to locate the corresponding configuration parameters.

The parameters for ScannerConstant.ParamKey are as specified in the table below.

- Reader

Name	Parameter	Optional Parameters	Default Value
Scanner Enable	SCANNER_ENABLE	Enable 1 Disable 0	1
Virtual Button	VIRTUAL_BUTTON	Enable 1 Disable 0	0

- Scan Mode

Name	Parameter	Optional Parameters	Default Value
Scan Mode	SCANNER_MODES	integer[0,2] ●Press code scanning and release stop ●Press code scanning until timeout ●Continuous scanning	0
Continuous decoding interval setting	CONTINUOUS_DECODE_INTERVAL	integer[30,3000]	30

- Decode Mode

Name	Parameter	Optional Parameters	Default Value
Decode Mode	DECODE_OUTPUT_MODE	integer[0,5] ●Intent Output ●Direct Fill ●Clipboard ●Key Event output ●Fill And Intent ●Replace Focus	1
Broadcast Intent Action	BROADCAST_INTENT_ACTION_NAME	string	com.android.scanner.broadcast
Broadcast Intent String Extra	BROADCAST_INTENT_EXTRA_NAME	string	scandata
Broadcast Intent Bytes Extra	BROADCAST_INTENT_EXTRA_BYTES	string	scandata_array
Barcode end character	BARCODE_APPEND_ENTER	integer[0,4] ●None ●ENTER ●SPACE ●TAB ●Done	1

Name	Parameter	Optional Parameters	Default Value
Control character	CTRL_CHARACTER	string	
Filter Web URL	FILTER_URL	Enable 1 Disable 0	0
Filter SyncTool QCode	FILTER_SYNC	Enable 1 Disable 0	0
Characters delay(ms)	KEYSTOKE_CHARACTER_DELAY	integer[0,1000]	0
Key event delay(ms)	KEYSTOKE_ENTER_DELAY	integer[0,1000]	0

- Decode Reminder

Name	Parameter	Optional Parameters	Default Value
Audio	SCANNER_BEEP_ENABLE	integer[0,9] ●Audio None ●Audio 1 ●Audio 2 ●Audio 3 ●Audio 4 ●Audio 5 ●Audio 6 ●Audio 7 ●Audio 8 ●Audio 9	1
Vibration	SCANNER_VIBRATE_ENABLE	Enable 1 Disable 0	0
Indiator	SCANNER_INDICATOR_ENABLE	Enable 1 Disable 0	1

- Coding Format

Name	Parameter	Optional Parameters	Default Value
Coding Format	ENCODING_FORMAT	integer[0,12] •UTF-8 •US-ASCII •ISO-8859-15 •GBK •UTF-16 •windows-1251 •windows-1250 •KOI8R •UTF-8 & G •ISO-8859-1 •BIG5 •SHIFT-JIS •windows-1256	0

- Label Formatting

Name	Parameter	Optional Parameters	Default Value
Transmit Code ID Character	TRANSMIT_CODE_ID	integer[0,3] •None •AIM Code ID Character •Symbol Code ID Character •Symbol Character and AIM	0
Application Identifier	GS1_DATABAR_APPLICATION_IDENTIFIER	Enable 1 Disable 0	0
Delete nonprinting characters	DELETE_NONPRINT_CHARACTER	Enable 1 Disable 0	0

Name	Parameter	Optional Parameters	Default Value
Send as hex	OUTPUT_HEX_STRING_DATA	Enable 1 Disable 0	0
Barcode Append Formatting	BARCODE_FORMAT	integer[0,6] •None •Prefix •Suffix •Prefix and Suffix •Pattern •Replace •Replace,Prefix and Suffix	0
Barcode Prefix	BARCODE_PREFIX	string	
Barcode Suffix	BARCODE_SUFFIX	string	
Barcode Formatting	BARCODE_PATTERN	string	
Barcode Replace Target	BARCODE_TARGET	string	
Barcode Replace Replacement	BARCODE_REPLACEMENT	string	
Match Substring Mode	BARCODE_SUBSTRING_MODE	integer[0,5] •None •Begin Index •Match Substring •Remove The Front Characters •Remove The Back Characters •Remove The Front And Back Characters	0
Match Begin Index	BARCODE_SUBSTRING_INDEX	integer[0,1000]	0

Name	Parameter	Optional Parameters	Default Value
Substring Length	BARCDOE_SUBSTRING_LENGTH	integer[-1,1000]	-1
Match Substring	BARCDOE_SUBSTRING_MATCH_STR	string	0

- Advanced Settings

Name	Parameter	Optional Parameters	Default Value
Disable Scan Key	SCAN_LOCK	Enable 1 Disable 0	0
Decode Session Timeout	DECODE_SESSION_TIMEOUT_MS	integer[1,10000]	5000
Phone Display Mode	PHONE_DISPLAY_MODE	Enable 1 Disable 0	0
Illum And Aim Mode	DECODING_ILLUM_AIM	integer[0,3] ●ILLUM_AIM_OFF ●ILLUM_OFF ●AIM_OFF ●ILLUM_AIM_ALWAYS	3
Illumination Power Level	DECODE_ILLUM_POWER_LEVEL	integer[0,10]	3
Picklist Mode	DECODE_PICKLIST_MODE	Enable 1 Disable 0	0

- Symbology Settings

Symbology	Name	Parameter	Optional Parameters	Default Value
UPC-A	Enable	UPC-A_ENABLE	Enable 1 Disable 0	1
UPC-A	Transmit Check Digit	UPC-A_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	1
UPC-A	Preamble	UPC-A_PREAMBLE	integer(0,1,2) •None •System Character •System Character and Country Code	1
UPC-A	Convert to EAN-13	UPC-A_CONVERT_TO_EAN13	Enable 1 Disable 0	0
UPC-A	Add-On Code Required	UPC-A_ADDONREQUIRED	integer(0,1,2,3,4) •None •2-Digit •5-Digit •Autodiscriminate •Always Required	0
UPC-A	UPCA Coupon	UPC-A_A_COUPON	Enable 1 Disable 0	0
UPC-A	Coupon Required	UPC-A_REQCOUPON	Enable 1 Disable 0	0
UPC-A	Gs1 Coupon	UPC-A_GS1COUPON	Enable 1 Disable 0	0
UPC-E	Enable	UPC-E_ENABLE	Enable 1 Disable 0	0
UPC-E	Transmit Check Digit	UPC-E_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	1

Symbology	Name	Parameter	Optional Parameters	Default Value
UPC-E	Preamble	UPC-E_PREAMBLE	integer(0,1,2) ●None ●System Character ●System Character and Country Code	1
UPC-E	Convert to UPC-A	UPC-E_CONVERT_TO_UPC-A	Enable 1 Disable 0	0
UPC-E	Add-On Code Required	UPC-E_ADDONREQUIRED	integer(0,1,2,3,4) ●None ●2-Digit ●5-Digit ●Autodiscriminate ●Always Required	0
UPC-E1	Enable	UPC-E1_ENABLE	Enable 1 Disable 0	0
UPC-E1	Transmit Check Digit	UPC-E1_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	1
UPC-E1	Preamble	UPC-E1_PREAMBLE	integer(0,1,2) ●None ●System Character ●System Character and Country Code	1
UPC-E1	Convert to UPC-A	UPC-E1_CONVERT_TO_UPC-A	Enable 1 Disable 0	0

Symbology	Name	Parameter	Optional Parameters	Default Value
UPC-E1	Add-On Code Required	UPC-E1_ADDONREQUIRED	integer(0,1,2,3,4) •None •2-Digit •5-Digit •Autodiscriminate •Always Required	0
EAN-13	Enable	EAN-13_ENABLE	Enable 1 Disable 0	1
EAN-13	Transmit Check Digit	EAN-13_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	1
EAN-13	Bookland EAN	EAN-13_BOOKLAND_EAN	Enable 1 Disable 0	0
EAN-13	Bookland ISBN Format	EAN-13_BOOKLAND_ISBN_FORMAT	integer(0,1) •ISBN-10 •ISBN-13	0
EAN-13	ISSN EAN	ISSN_EAN_EN	Enable 1 Disable 0	1
EAN-13	Add-On Code Required	EAN-13_ADDONREQUIRED	integer(0,1,2,3,4) •None •2-Digit •5-Digit •Autodiscriminate •Always Required	0
EAN-8	Enable	EAN-8_ENABLE	Enable 1 Disable 0	1
EAN-8	Transmit Check Digit	EAN-8_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	1
EAN-8	Convert to EAN13	EAN-8_CONVERT_TO_EAN13	Enable 1 Disable 0	0

Symbology	Name	Parameter	Optional Parameters	Default Value
EAN-8	Add-On Code Required	EAN-8_ADDONREQUIRED	integer(0,1,2,3,4) •None •2-Digit •5-Digit •Autodiscriminate •Always Required	0
UPC/EAN/JAN	Add-On Code Required	DECODE_UPC_EAN_JAN_SUPPLEMENTALS	integer(0,1,2,3,4) •None •2-Digit •5-Digit •Autodiscriminate •Always Required	0
UPC/EAN/JAN	UPC/EAN Security Level	UPC_EAN_SECURITY_LEVEL	integer(0,1,2,3) •Level 0 •Level 1 •Level 2 •Level 3	0
UPC/EAN/JAN	Supplemental Redundancy	UCC_EAN_SUPP_Redundancy	integer[1,20]	1
UPC/EAN/JAN	UCC Coupon Extended Code	UCC_COUPON_EXTENDED_CODE	Enable 1 Disable 0	0
UPC/EAN/JAN	Coupon Report	COUPON_REPORT	integer(0,1,2) •Old •New •Both	0
UPC/EAN/JAN	UPC Reduced Quiet Zone	UPC_Reduced_Quiet_Zone	Enable 1 Disable 0	0
Code 128	Enable	CODE_128_ENABLE	Enable 1 Disable 0	1

Symbology	Name	Parameter	Optional Parameters	Default Value
Code 128	Length1	CODE_128_LENGTH_1	integer[1,80]	1
Code 128	Length2	CODE_128_LENGTH_2	integer[1,80]	80
Code 128	GS1-128 Enable	CODE_128_GS1-128	Enable 1 Disable 0	1
Code 128	GS1-128 Truncate leading 0	GS1_128_Truncate_Leading	integer(0,1,2) ●Disable ●All Leading 0 ●Only the first 0	0
Code 128	ISBT 128 Enable	CODE_128_ISBT_128	Enable 1 Disable 0	1
Code 128	Check ISBT Table	CODE_128_CHECK_ISBT_TABLE	Enable 1 Disable 0	1
Code 128	ISBT Concatenation	ISBT_Concatenation	integer(0,1,2) ●Disable ●Enable ●Autodiscriminate	0
Code 128	Reduced Quiet Zone	Code128_Reduced_Quiet_Zone	Enable 1 Disable 0	1
Code 128	Code 128 Security Level	Code128_Security_Level	integer(0,1,2,3) ●Level 0 ●Level 1 ●Level 2 ●Level 3	0
Code 128	Ignore Code 128(FNC4)	CODE128_IGNORE_FNC4	Enable 1 Disable 0	0

Symbology	Name	Parameter	Optional Parameters	Default Value
Code 128	Code 128 Out Of Spec	CODE128_OUT_OF_SPEC	integer[0,15]	7
AIM128	Enable	AIM128_ENABLE	Enable 1 Disable 0	0
AIM128	Length1	AIM128_LENGTH1	integer[1,127]	1
AIM128	Length2	AIM128_LENGTH2	integer[1,127]	127
Code 39	Enable	CODE_39_ENABLE	Enable 1 Disable 0	1
Code 39	Check Digit	CODE_39_CHECK_DIGIT_VERIFICATION	Enable 1 Disable 0	0
Code 39	Transmit Check Digit	CODE_39_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	0
Code 39	Full ASCII Conversion	CODE_39_FULL_ASCII_CONVERSION	Enable 1 Disable 0	0
Code 39	Length1	CODE_39_LENGTH1	integer[1,55]	2
Code 39	Length2	CODE_39_LENGTH2	integer[1,55]	55
Code 39	Reduced Quiet Zone	Code39_Reduced_Quiet_Zone	Enable 1 Disable 0	1
Code 39	Code 39 Security Level	CODE39_SECURITY_LEVEL	integer(0,1,2,3) ●Level 0 ●Level 1 ●Level 2 ●Level 3	0
Code 39	Trioptic Code 39	TRIOPTIC_CODE_39_ENABLE	Enable 1 Disable 0	0

Symbology	Name	Parameter	Optional Parameters	Default Value
Code 39	Convert Code 39 to Code 32	CODE_32_ENABLE	Enable 1 Disable 0	0
Code 39	Code 32 Prefix	CODE_32_PREFIX	Enable 1 Disable 0	0
Code 93	Enable	CODE_93_ENABLE	Enable 1 Disable 0	0
Code 93	Check Digit	CODE_93_CHECK	Enable 1 Disable 0	0
Code 93	Transmit Check Digit	CODE_93_TRANSMIT_CHECK	Enable 1 Disable 0	0
Code 93	Length1	CODE_93_LENGTH1	integer[1,80]	4
Code 93	Length2	CODE_93_LENGTH2	integer[1,80]	55
Interleaved 2 of 5	Enable	INTERLEAVED_2_OF_5_ENABLE	Enable 1 Disable 0	1
Interleaved 2 of 5	Check Digit	I_2_OF_5_CHECK_DIGIT_VERIFICATION	Enable 1 Disable 0	0
Interleaved 2 of 5	Transmit Check Digit	I_2_OF_5_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	0
Interleaved 2 of 5	Length1	I_2_OF_5_LENGTH1	integer[2,80]	6
Interleaved 2 of 5	Length2	I_2_OF_5_LENGTH2	integer[2,80]	55
Interleaved 2 of 5	Convert I 2 of 5 to EAN-13	I_2_OF_5_CONVERT_TO_EAN13	Enable 1 Disable 0	0
Interleaved 2 of 5	Reduced Quiet Zone	I25_Reduced_Quiet_Zone	Enable 1 Disable 0	1

Symbology	Name	Parameter	Optional Parameters	Default Value
Interleaved 2 of 5	I 2 of 5 Security Level	I_2_OF_5_Security_Level	integer(0,1,2,3) •Level 0 •Level 1 •Level 2 •Level 3	1
Discrete 2 of 5(Industrial 2 of 5)	Enable	DISCRETE_2_OF_5_ENABLE	Enable 1 Disable 0	0
Discrete 2 of 5(Industrial 2 of 5)	Check Digit	DISCRETE_2_OF_5_CHECK	Enable 1 Disable 0	0
Discrete 2 of 5(Industrial 2 of 5)	Transmit Check Digit	DISCRETE_2_OF_5_TRANSMIT_CHECK	Enable 1 Disable 0	0
Discrete 2 of 5(Industrial 2 of 5)	Length1	DISCRETE_2_OF_5_LENGTH1	integer[4,55]	4
Discrete 2 of 5(Industrial 2 of 5)	Length2	DISCRETE_2_OF_5_LENGTH2	integer[4,55]	48
Matrix 2 of 5	Enable	MATRIX_2_OF_5_ENABLE	Enable 1 Disable 0	0
Matrix 2 of 5	Check Digit	MATRIX_2_OF_5_CHECK_DIGIT_VERIFICATION	Enable 1 Disable 0	0
Matrix 2 of 5	Transmit Check Digit	MATRIX_2_OF_5_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	0
Matrix 2 of 5	Length1	MATRIX_2_OF_5_LENGTH1	integer[4,80]	4
Matrix 2 of 5	Length2	MATRIX_2_OF_5_LENGTH2	integer[4,80]	55

Symbology	Name	Parameter	Optional Parameters	Default Value
IATA25	Enable	IATA25_ENABLE	Enable 1 Disable 0	0
IATA25	Check Digit	IATA25_CHECK	Enable 1 Disable 0	0
IATA25	Transmit Check Digit	IATA25_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	0
IATA25	Length1	IATA25_LENGTH1	integer[4,80]	4
IATA25	Length2	IATA25_LENGTH2	integer[4,80]	80
Code 11	Enable	CODE_11_ENABLE	Enable 1 Disable 0	0
Code 11	Check Digit	CODE_11_CHECK_DIGIT_VERIFICATION	integer(0,1,2) ●Disable ●One Check Digit ●Two Check Digit	0
Code 11	Check Digit	CODE_11_CHECK_DIGIT_VERIFICATION	integer(0,1,2,3,4,5) ●Disable ●MOD11 ●Only MOD11/ MOD11 ●Only MOD11/ MOD9 ●Auto MOD11/ MOD11 ●Auto MOD11/ MOD11	0
Code 11	Transmit Check Digit	CODE_11_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	0
Code 11	Length1	CODE_11_LENGTH1	integer[1,80]	4

Symbology	Name	Parameter	Optional Parameters	Default Value
Code 11	Length2	CODE_11_LENGTH2	integer[1,80]	55
Codabar	Enable	CODABAR_ENABLE	Enable 1 Disable 0	1
Codabar	NOTIS Editing	CODABAR_NOTIS_EDITING	Enable 1 Disable 0	0
Codabar	CLSI Editing	CODABAR_CLSI_EDITING	Enable 1 Disable 0	0
Codabar	Length1	CODABAR_LENGTH1	integer[2,60]	6
Codabar	Length2	CODABAR_LENGTH2	integer[2,60]	55
Codabar	Codabar Security Level	Codabar_Security_Level	integer(0,1,2,3) •Level 0 •Level 1 •Level 2 •Level 3	1
China Post	Enable	CHINESE_2_OF_5_ENABLE	Enable 1 Disable 0	0
China Post	Length1	C25_LENGTH1	integer[4,80]	4
China Post	Length2	C25_LENGTH2	integer[4,80]	80
MSI Plessey	Enable	MSI_ENABLE	Enable 1 Disable 0	0
MSI Plessey	Check Digits	MSI_CHECK_DIGITS	integer(0,1,2) •None •One Check Digit •Two Check Digit	0

Symbology	Name	Parameter	Optional Parameters	Default Value
MSI Plessey	Transmit Check Digit	MSI_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	0
MSI Plessey	Check Digit Algorithm	MSI_CHECK_DIGIT_ALGORITHM	integer(0,1) ●MOD 10/MOD 11 ●MOD 10/MOD 10	0
MSI Plessey	Length1	MSI_LENGTH1	integer[4,55]	4
MSI Plessey	Length2	MSI_LENGTH2	integer[4,55]	55
GS1 DataBar Family	GS1 DataBar-14	GS1_DATABAR-14_ENABLE	Enable 1 Disable 0	0
GS1 DataBar Family	Convert to UPC/EAN	GS1_DATABAR_CONVERT_TO_UPC_EAN	Enable 1 Disable 0	0
GS1 DataBar Family	GS1 DataBar Limited	GS1_DATABAR-14_LIMITED_ENABLE	Enable 1 Disable 0	0
GS1 DataBar Family	GS1 DataBar Expanded	GS1_EXPANDED_ENABLE	Enable 1 Disable 0	0
GS1 DataBar Family	Length1	GS1_EXPANDED_LENGTH1	integer[1,80]	1
GS1 DataBar Family	Length2	GS1_EXPANDED_LENGTH2	integer[1,80]	74
GS1 DataBar Family	GS1 DataBar Limited Security Level	GS1_LIMITED_Security_Level	integer(0,1,2,3) ●Level 0 ●Level 1 ●Level 2 ●Level 3	3
GS1 DataBar Family	RSS Enable	RSS_ENABLE	Enable 1 Disable 0	1

Symbology	Name	Parameter	Optional Parameters	Default Value
GS1 DataBar Family	Transmit AI(10)	RSS_TRSMTAI	Enable 1 Disable 0	0
GS1 DataBar Family	Convert to UPC/EAN	GS1_DATABAR_CONVERT_TO_UPC_EAN	Enable 1 Disable 0	0
Composite	Composite CC-A/B	COMPOSITE_CC_AB_ENABLE	Enable 1 Disable 0	0
Composite	Composite CC-C	COMPOSITE_CC_C_ENABLE	Enable 1 Disable 0	0
Composite	Composite TLC-39	COMPOSITE_TLC-39_ENABLE	Enable 1 Disable 0	0
Composite	UPC Composite Mode	UPC_COMPOSITE	integer(0,1,2) ●Never Linked ●Always Linked ●Autodiscriminate	0
Composite	GS1-128 Emulation Mode	GS1_128_UPC_Composite_Codes	Enable 1 Disable 0	0
Composite	Composite Enable	COMPOSITE_CC_AB_ENABLE	Enable 1 Disable 0	0
Composite	UPC Composite Enable	UPC_COMPOSITE	Enable 1 Disable 0	0
PDF417	Enable	PDF417_ENABLE	Enable 1 Disable 0	1
MicroPDF417	Enable	MICROPDF417_ENABLE	Enable 1 Disable 0	0
Han Xin	Enable	HAN_XIN_ENABLE	Enable 1 Disable 0	0

Symbology	Name	Parameter	Optional Parameters	Default Value
Han Xin	Inverse	HAN_XIN_INVERSE	integer(0,1,2) ●Regular Only ●Inverse Only ●Inverse Autodetect	0
Han Xin	Mirror	HAN_XIN_MIRROR	integer(0,1,2) ●Regular Only ●Mirrored Only ●Auto-discriminate	0
Data Matrix	Enable	DATA_MATRIX_ENABLE	Enable 1 Disable 0	1
Data Matrix	Length1	DATA_MATRIX_LENGTH1	integer[1,3166]	1
Data Matrix	Length1	DATA_MATRIX_LENGTH2	integer[1,3166]	3166
Data Matrix	Inverse	DATA_MATRIX_INVERSE	integer(0,1,2) ●Regular Only ●Inverse Only ●Inverse Autodetect	0
Data Matrix	Mirror	DATA_MATRIX_MIRROR	integer(0,1,2) ●Regular Only ●Mirrored Only ●Auto-discriminate	0
Maxicode	Enable	MAXICODE_ENABLE	Enable 1 Disable 0	1
QR Code	Enable	QR_CODE_ENABLE	Enable 1 Disable 0	1

Symbology	Name	Parameter	Optional Parameters	Default Value
QR Code	Inverse	QR_CODE_INVERSE	integer(0,1,2) ●Regular Only ●Inverse Only ●Inverse Autodetect	0
QR Code	Mirror	QR_CODE_MIRROR	integer(0,1,2) ●Regular Only ●Mirrored Only ●Auto-discriminate	0
Micro QR	Enable	MICROQR_ENABLE	Enable 1 Disable 0	0
Aztec	Enable	AZTEC_ENABLE	Enable 1 Disable 0	1
Aztec	Inverse	AZTEC_INVERSE	integer(0,1,2) ●Regular Only ●Inverse Only ●Inverse Autodetect	0
Aztec	Mirror	AZTEC_MIRROR	integer(0,1,2) ●Regular Only ●Mirrored Only ●Auto-discriminate	0
Grid Matrix	Enable	GRID_MATRIX_ENABLE	Enable 1 Disable 0	0
Grid Matrix	Inverse	GRID_MATRIX_INVERSE	integer(0,1,2) ●Regular Only ●Inverse Only ●Inverse Autodetect	0

Symbology	Name	Parameter	Optional Parameters	Default Value
Grid Matrix	Mirror	GRID_MATRIX_MIRROR	integer(0,1,2) ●Regular Only ●Mirrored Only ●Auto-discriminate	0
DotCode	Enable	DOTCODE_ENABLE	Enable 1 Disable 0	0
DotCode	Inverse	DOTCODE_INVERSE	integer(0,1,2) ●Regular Only ●Inverse Only ●Inverse Autodetect	0
DotCode	Mirror	DOTCODE_MIRROR	integer(0,1,2) ●Non-Mirrored Only ●Mirrored Only ●Auto-discriminate	0
DotCode	Prioritize	DOTCODE_PRIORITIZE	Enable 1 Disable 0	0
CodablockF	Enable	CODABLOCKF_ENABLE	Enable 1 Disable 0	0
CodablockF	Length1	CODABLOCKF_LENGTH1	integer[1,2048]	1
CodablockF	Length2	CODABLOCKF_LENGTH2	integer[1,2048]	2048
Postal Codes	Korean Post	K35_ENABLE	Enable 1 Disable 0	0
Postal Codes	Postal Lists	POSTAL_GROUP_LISTS	integer(0,1,2) ●Disabled ●Australia Post ●Royal Mail	0

Symbology	Name	Parameter	Optional Parameters	Default Value
Postal Codes	US Postnet	US_POSTNET_ENABLE	Enable 1 Disable 0	0
Postal Codes	Send US POSTNET Check Digit	US_POSTNET_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	1
Postal Codes	US Planet	US_PLANET_ENABLE	Enable 1 Disable 0	0
Postal Codes	Send US Postal Check Digit	US_POSTAL_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	1
Postal Codes	UK Postal(Royal Mail)	UK_POSTAL_ENABLE	Enable 1 Disable 0	0
Postal Codes	Send UK Postal Check Digit	UK_POSTAL_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	1
Postal Codes	USPS 4CB(Intelligent Mail)	USPS_4_STATE_CUSTOM_ENABLE	Enable 1 Disable 0	0
Postal Codes	UPU FICS Postal	UPU_FICS_POSTAL_ENABLE	Enable 1 Disable 0	0
Postal Codes	Australia Post	AUSTRALIA_POSTAL_ENABLE	Enable 1 Disable 0	0
Postal Codes	Australia Post Format	AUSTRALIA_POSTAL_FORMAT	integer(0,1,2,3) ●Autodiscriminate ●Raw Format ●Alphanumeric ●Numeric	0
Postal Codes	Netherlands KIX Code	NETHERLANDS_KIX_CODE_ENABLE	Enable 1 Disable 0	0
Postal Codes	Japan Postal	JAPAN_POSTAL_ENABLE	Enable 1 Disable 0	0

Symbology	Name	Parameter	Optional Parameters	Default Value
Postal Codes	Send Japan Postal Check Digit	JAPANPOST_TRANSMIT_CHECK_DIGIT	Enable 1 Disable 0	0
Binary Code	Enable	BINARY_CODE_ENABLE	Enable 1 Disable 0	0
DPM Mode	Enable	DPM_MODE	integer(0,1,2) ●Disable ●Dotpeen ●Reflective	0
OCR Mode	Enable	OCR_MODE	Enable 1 Disable 0	0
OCR Mode	Enable	OCR_MODE	integer(0,1,2,3) ●Off ●Normal Video ●Inverse,Both	0
OCR Mode	OCR Template	OCR_TEMPLATE	integer(0,1,2,3,4) ●User Defined ●Passport ●ISBN ●Price Field ●MicrE-13 B	0