Halcyon Aurora T2 Smart Thermostat - User Manual

Thank you for choosing the Aurora T2. This manual covers installation, Wi-Fi setup, troubleshooting and warranty. Halcyon Home and the Aurora T2 are fictional products used for demonstration purposes.

In the box

Aurora T2 display unit, wall plate, trim plate, 4 screws and anchors, wire labels, and a C-wire adapter.

Installation

Before you begin, turn off power to your heating and cooling system at the circuit breaker. The Aurora T2 works with most 24V heating and cooling systems, including gas, oil, electric furnaces and heat pumps.

The Aurora T2 is not compatible with line-voltage (120V or 240V) baseboard heaters. A C-wire (common wire) is required. If your system has no C-wire, install the included C-wire adapter at the furnace control board.

Label each wire before disconnecting your old thermostat, then connect the wires to the matching terminals on the Aurora T2 wall plate.

Wi-Fi setup

The Aurora T2 connects to 2.4 GHz Wi-Fi networks only, using WPA2 or WPA3 security. 5 GHz networks are not supported.

To start pairing, press and hold the main button for 5 seconds until the LED blinks blue, then follow the steps in the Halcyon Home app.

Error codes

E1: No power on the C-wire. Check the C-wire connection or install the adapter.

E3: Temperature sensor fault. Restart the device; contact support if it persists.

E7: Wi-Fi authentication failed. Re-enter your Wi-Fi password in the app.

Features

Eco mode keeps the temperature between 16 and 26 degrees Celsius while you are away. The built-in battery keeps the clock and schedule running for up to 8 hours during a power cut.

To factory reset the thermostat, press and hold the main button for 15 seconds.

Warranty

The Aurora T2 comes with a 2-year limited warranty from the date of purchase. The warranty does not cover damage caused by incorrect wiring.