Comfort Zone 20-inch Air Circulatory Fan

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ12360

Original source file(s): CZ12360.Instruction Manual.01.pdf

Source SHA-256: 71c83edc61db194353062496c5a09d014d0c9d48ef4c365deb8de66b51b0cb16

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

CZ12360-EC Series

20 INCH AIR CIRCULATORY FAN

this fan on a table or floor. Plastoc feet are provided for required

stability, and must be installed to insure safe operation. Snap

legs to fan cradle(Fig. 1, Fig.2).

Simple assembly is required to use

210.00 mm

290.00 mm

Source page 1 - Panel 1 (top left) (OCR)

©) www.comfortzoneproducts.com

SS

CARE AND MAINTENANCE: LIMITED WARRANTY

Cleaning: CAUTION-Before cleaning the fan be sure to unplug This unit is guaranteed to the original retail purchaser

the power cord from the outlet. Clean the grille surface with against defects in quality or workmanship for a period of

aclean damp cloth. Do not use harsh chemical or abrasive one year from the date of original purchase. If this unit fails

cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN because of a manufacturing defect within 30 days of

WATER. Allow fan to dry completely before use. Periodic grille purchase, return the unit, with your receipt, to the retailer.

cleaning with a vacuum will prevent dust build up. The motor is After 30 days, but within the warranty period, if the unit

sealed and does not require any interior maintenance, cleaning was purchased within the continental United States, return

or lubrication. it, to Mr. Brands LLC for repair or replacement. If the unit

Maintenance: The Internal motor bearings are permanently was purchased outside the continental United States,

lubricated at the factory and do not require any additional return the unit to the place of purchase. This warranty

lubrication. does not cover damage caused by misuse, abuse,

. overheating or alteration. Repairs made by anyone other

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN than Mr. Brands LLC are not covered in this warranty.

PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR | Mr.Brands LLC will not be held liable for any losses due to

BECOME DAMAGED IN ANY WAY. neglectful operation. All implied warranties, including the

Storage: Keep original carton for storage of the fan. Coil and tie warranties of merchantability and of fitness of Purpose, if

the power cord to avoid damage during storage. applicable, are hereby limited in duration to the period of

one year from the date of original retail purchase. Some

sa states do not allow limitations on how long an implied

Note: Some models come with a plug where you can replace warranty lasts, so the above limitations may not apply to

a fuse. If your model has this, please read and follow the below you. Incidental or consequential damages arising from a

instructions to replace the fuse. breach of either express or implied warranties are hereby

disclaimed and excluded. Some states do not allow the

This product employs overload protection (fuse). A blown fuse exclusion of limitation of incidental or consequential

indicates an overload or short-circuit situation. If the fuse blows, damages, so this limitation or exclusion may not apply to

unplug the product from the outlet. Replace the fuse as per the you. Upon the expiration of this warranty all such liability

user servicing instructions (follow product marking for proper will terminate. No other warranties are expressed or

fuse rating) and check the product. If the replacement fuse implied. This warranty gives you specific legal rights, and

blows, a short-circuit may be present and the product should . Iso h: h hi hich ft i"

be discarded or returned to an authorized service facility for you may also have other rights which vary from state to

examination and/or repair. state. No informal dispute settlement mechanisms are

available. This limited warranty is given in lieu of all other

Fuse Replacement: warranties.

CO 1. Grasp plug and remove from the receptacle or other

outlet device. Do not unplug by pulling on cord. This warranty gives you specific legal rights, and you may

(=) 2. Open fuse cover by sliding open fuse access cover on also have other rights which vary from state to state.

. top of attachment plug towards blades. See Fig. 2 No informal dispute settlement mechanisms are available.

This limited warranty is given in lieu of all other warranties.

CO 3. Remove fuse carefully. Use a small tool to pry the end

of the fuse from holder cavity. Be careful not to break Manufactured for:

‘ glass window. Mr. Brands LLC

N 4. Replace fuse. 113 Fillmore St

WARNING: Risk of fire. Replace fuse only with identical Bristol, PA 19007

2.5 or 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure 4-877-420-7555

fuse is properly seated within its cavity. www.mrbrands.com

5. Close fuse cover by sliding it back to its original closed www.comfortzoneproducts.com

position.

Aronnne:

Fig 1 Fig 2 Fig 3 Cancer and Reproductive Harm --

‘www.P65Warnings.ca.gov

Slide Cover to Open

|r) yey - |r ips P Rev. 07/20/23

Source page 1 - Panel 2 (top right) (OCR)

CZ12360-EC Series

Feely,

Cer

pay

ESQ a ZG

ES SEN GZ

EDS aoe Ly,

BIW AESE SRN 2 ZF

BSL SSS OE ENS ZS

is BSS SES NA Ze

iS: | SSS SANE “iy,

isi MES " “Bae

eS er 450 a Et

2S ihe. gicetins See

SEStES ie eeuttr ye anbegaae®

Be Be “seas ane B=

AERIALS 5 ana SS

WG £ ST SSS

‘BZ, BRO FE FSS"

“So See Se OS

ip. SS’

OY Up nN RS

RTOS

SHEEN

Features:

¢ Rotary Switch with

3-Speed Settings

1-Low, 2-Med and

3-High

* Convenient Carry

Handle

¢ Lightweight

* Maximum Air

Movement

« Aerodynamic Shaped

Fan Blades

¢ Safety Grilles Gl

« Easy No Tool Assembly

sre

°120V A.C. / 6OHz. Intertek

www.comfortzoneproducts.com Save These Instructions

Source page 1 - Panel 3 (bottom left) (OCR)

O www.comfortzoneproducts.com

The eects ntended for indoor residential and office use only, READ & SAVE TH ESE

not for industrial or other commercial applications. Use only with | INSTRUCTIONS

electrical wiring that is in good working order and that meets.

applicable codes and ordinances. If you have any questions GAVZEGIINTe# Shock Hazard

whether your wiring is adequate, consult a qualified electrician. Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near

While using your fan, you should follow the IMPORTANT sinks, washing machines, swimming pools or other sources of

INSTRUCTIONS listed below. As part of those instructions, we water. Never locate fan where it may fall into a bathtub or other

have used the word "WARNING" to indicate the level of hazard: water receptacle. Do not use in damp environments such as

WARNING indicates a hazard which, if not avoided, could result flooded basements.

in injury or death.

IMPORTANT INSTRUCTIONS eee re unon nace

Do not touch fan motor when in use. This motor is hot when in

As with all electrical appliances, basic safety precautions should use, to avoid burns, do not let bare skin touch hot surfaces.

always be followed to reduce the risk of electric shock, fire, or

injury to persons, including the following precautions: EEVZ-GIIN ed Fire Hazard

. . . Fans have arcing or sparking parts inside. Do not use near

* Read all the instructions before using this fan. combustible materials or flammable gases or sources of heat.

+ Use this fan only as described n this manual. any other se net DO NOT USE in areas where gasoline, paint or flammable

recommended by the manufacturer may cause electrical shock, | materials are used or stored. To prevent a possible fire, do not

fire or injury to persons. ; block air intakes or exhaust in any manner. Do not insert or allow

+ Do not operate the fan with a damaged power cord or after the | foreign objects to enter any ventilation or exhaust opening as this

fan malfunctions or has been dropped in any manner. may cause an electric shock, fire, or damage the fan.

+ Use of extreme caution is necessary when any fan is used by or

near children, disabled persons or pets and whenever the fan is PRSVEGIITc# Electrical Shock Hazard

left operating unattended. Do not use with damaged cord or plug. Use with adequate

+ Do not place the fan on a small, unlevel, uneven or any surface electrical system that is up to code.

which might allow fan to tip or fall.

+ For proper operation, fan should be placed on a smooth, PRY NUTeINF to Prevent Electric Shock, this product

non-combustible, level surface. has a polarized two prong plug (one blade is wider than the

+ Always unplug fan when not in use, when moving from place other) that must be fully inserted in to a matching properly

to place, when assembling or disassembling parts, and before grounded outlet. This plug is designed to fit a polarized outlet

cleaning. only one way. If the plug does not fit fully into the outlet,

+ The use of attachments, not recommended or sold by the reverse the plug. If the plug still does not fit, contact a qualified

manufacturer, may cause hazards. electrician. Do not attempt to defeat this safety feature.

+ Do not use outdoors. . ‘ A

i - - PRVTGTINTc¥ to Reduce the Risk of Fire or Electric

+ Do not use fan in window. Rain may cause electrical hazard . i A

q Shock, do not use this product with any solid-state speed

(for non-window models). control device.

+ Do not operate the fan with blade guards or any safety device :

removed. . . DO NOT operate any fan with a damaged cord or plug or after

+ Avoid the use of extension cords due to risk of fire. If an fan malfunctions, has been dropped or damaged in any manner.

extension cord must be used, the cord must be minimum Do not operate fan with a broken blade, safety cage or any visual

14 AWG and rated not less then 1875 watts. imperfections. Disconnect power before servicing. For repairs

* Do not run power cord under carpeting. Do not cover cord with | covered under warranty, see warranty statement.

throw rugs, runners or the like. Arrange cord away from traffic

area where it will not be tripped over.

. . DO NOT run power cord under carpeting. DO NOT cover cord

* Do not insert or allow any object to enter any openings on the with throw rugs, runners or the like. Arrange cord away from

fan. Doing so may cause electric shock and/or fire hazard. gs, runne Ke. ge cord away

. , a traffic area where it will not be tripped over. Avoid the use of

Avoid contact with moving parts. " . i" .

Thi Li t intended f b includ extension cords due to risk of fire. If an extension cord must

IS appliance Is not intended for use Dy persons (inclu ing be used, the cord must be minimum 14 AWG and rated not

children) with reduced physical, sensory or mental capabilities less then 1875 watts. Do not use an extension cord unless the

or lack of experience and knowledge, unless they have ‘ 6 letaly Inserted into tt tacle. Unp

been given supervision or instruction concerning use of the one can her ali etely ‘Dor st into ite on with ite a ta

appliance by a person responsible for their safety. atructe vi notin use. Do not operate fan with its ventilation

+ Children should be supervised to ensure they do not play with obstructed.

the appliance.

Source page 1 - Panel 4 (bottom right) (OCR)

) Comfort Zone.

6) www.comfortzoneproducts.com

Usage: Care and Maintenance

Fan Operation: Always operate the fan in the upright position Cleaning: CAUTION-Before cleaning the fan be sure to

following all instructions and recommendations listed in this disconnect power cord from the plug. Clean the grille surface

manual. with a clean damp cloth. Do not use harsh chemical or abrasive

cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN

Fan Location: Place the fan in the area of the room that will WATER. Replace front grille before fan use. Allow fan to dry

provide proper fan cooling. completely before use. Periodic grille cleaning with a vacuum will

prevent dust build up. The motor is sealed and does not require

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz any interior maintenance, cleaning or lubrication.

wall outlet. Be sure plug fits tightly in outlet. A loose connection

may cause overheating and damage to the plug or fan. Maintenance: The Internal motor bearings are permanently

Note: To prevent overloading a circuit, do not plug the fan into a lubricated at the factory and do not require any additional

circuit that is servicing other electrical needs. lubrication.

Turning Fan On/Off: To start the fan, turn rotary dial on Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN

Control Panel to desired speed setting. PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR

Control Panel BECOME DAMAGED IN ANY WAY.

0- Of a

1-Low / Storage: Keep original carton for storage of the fan. Coil and tie

2 - Medium e the power cord to avoid damage during storage.

3-High

Rotate ON/OFF dial to OFF to discontinue use. Unplug fan when

not in use.

Assembly Instructions: Simple assembly is required to use

this fan on a table or floor. Plastoc feet are provided for required

stability, and must be installed to insure safe operation. Snap

legs to fan cradle(Fig. 1, Fig.2).

_<

Stabilizing Feet