Comfort Zone 32-inch Tower Fan with Oscillation

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ12386

Original source file(s): CZ12386.Instruction Manual.01.pdf

Source SHA-256: e498909604f3dba3fafcb9755ff9df471aeafdb2a4e6e451654b533f127680e9

Original PDF pages: 2 | Recovered reading units: 2

Source page 1 (embedded text)

4

Fan speed

with oscillation

Fan speed

without oscillation

Control Panel

Warranty

Care and Maintenance

Cleaning

NOT IMMERSE THE FAN OR ANY WIRES IN WATER.

Replace front grille before fan use.

Allow fan to dry completely before use.

Periodic grille cleaning with a vacuum will prevent dust build up.

The motor is sealed and does not require any interior maintenance, cleaning or lubrication.

Maintenance

The Internal motor bearings are permanently lubricated at the factory and do not require any additional

lubrication.

Repair

Storage

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the

date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your

receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States,

return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit

to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by

anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to

neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are

hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations

on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising

from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of

limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this

warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights,

and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This

limited warranty is given in lieu of all other warranties.

Manufactured for:

Mr. Brands LLC

113 Fillmore St, Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

Rev. 07/20/23

CZ12386 Series

32” Tower Fan with Oscillation

• Wide Area Oscillation

• Rotating Dial with 3 Speed Settings

• Built-in Carrying Handle

• Slim Design with Stable Base

• 120V A.C. / 60Hz

Source page 2 (embedded text)

2

3

Important Safety Instructions

As with all electrical appliances, basic safety

precautions should always be followed to reduce

the risk of electric shock, fire, or injury to

persons, including the following precautions:

Any other use not recommended by the

manufacturer may cause electrical shock, fire

or injury to persons.

power cord or after the fan malfunctions or

has been dropped in any manner.

fan is used by or near children, disabled

persons or pets and whenever the fan is left

operating unattended.

uneven or any surface which might allow fan

to tip or fall.
a smooth, non-combustible, level surface.
moving from place to place, when assembling
or disassembling parts, and before cleaning.
sold by the manufacturer, may cause hazards.
electrical hazard (for non-window models).
any safety device removed.
cord must be minimum 14 AWG and rated not
less then 1875 watts.
not cover cord with throw rugs, runners or
the like. Arrange cord away from traffic area
where it will not be tripped over.
This product is intended for indoor residential and office use only, not for industrial or other commercial ordinances. If you have any questions whether your wiring is adequate, consult a qualified electrician.
instructions, we have used the word "WARNING" to indicate the level of hazard: WARNING indicates a hazard which, if not avoided, could result in injury or death.

WARNING: SHOCK HAZARD

fan is not intended for use in a bathroom,
laundry area, or similar locations, or near
sinks, washing machines, swimming pools
or other sources of water. Never locate fan
where it may fall into a bathtub or other
environments such as flooded basements.

WARNING: HOT SURFACES

motor is hot when in use, to avoid burns,
do not let bare skin touch hot surfaces.

WARNING: FIRE HAZARD

Fans have arcing or sparking parts inside.
not use in areas where gasoline, paint or
flammable materials are used or stored. To
prevent a possible fire, do not block air
insert or allow foreign objects to enter any
cause an electric shock, fire, or damage
the fan.
persons (including children) with reduced
physical, sensory or mental capabilities or
they have been given supervision or
instruction concerning use of the appliance
by a person responsible for their safety.
do not play with the appliance.
electric shock and/or fire hazard. Avoid
contact with moving parts.

WARNING: ELECTRICAL SHOCK HAZARD

Do not use with damaged cord or plug. Use with adequate electrical system that is up to code.

CAUTION: TO PREVENT ELECTRIC SHOCK,

this product has a polarized two prong plug (one blade is wider than the other) that must be fully inserted in to a matching properly grounded outlet. This plug is designed to fit a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If the plug still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

SAVE THESE INSTRUCTIONS

WARNING: TO REDUCE THE RISK OF FIRE

OR ELECTRIC SHOCK, do not use this product with any solid-state speed control device.

DO NOT operate any fan with a damaged cord or plug or after fan malfunctions, has been dropped or damaged in any manner.

Do not operate fan with a broken blade, safety cage or any visual imperfections. Disconnect power before servicing.

DO NOT run power cord under carpeting. DO NOT cover cord with throw rugs, runners or the will not be tripped over. Avoid the use of extension cords due to risk of fire. If an extension cord must be used, the cord must be minimum 14 AWG and rated not less then 1875 watts. Do not use an extension cord unless the plug can be completely inserted into its receptacle. Unplug the fan when not in use. Do not operate fan with its ventilation obstructed.

Operating Instructions

Fan Operation

Always operate the fan in the upright position following all instructions and recommendations listed in this manual.

Fan Location

Place the fan in the area of the room that will provide proper fan cooling.

Fan Connection

Plug fan directly into 120 Volt A.C., 60 Hz wall outlet. Be sure plug fits tightly in outlet. A loose connection may cause overheating and damage to the plug or fan.

Note: To prevent overloading a circuit, do not plug the fan into a circuit that is servicing other electrical needs.

Turning Fan On/

Place fan on stable level surface. Plug fan into proper polarized outlet. To start the fan, rotate top control dial to desired fan speed (1, 2 or 3). Rotate the dial clockwise for standard use and counter-clockwise for oscillation use. See Control Panel below. Rotate top control dial again to OFF position to discontinue use. Unplug fan when not in use.

Fan Speed And Oscillation

Rotate top control dial to desired fan speed (1, 2 or 3). Rotate the dial clockwise for standard use and counter-clockwise for oscillation use. See Control Panel below.

Fan Base Assembly

Simple assembly is required to use this fan.

1. Rotate the base holder (F) o , which is at the bottom of the fan housing.
2. Place the Rear base panel (B) between the fan housing (D) and base holder(F), in the right direction.
3. Align the Rear base panel (B) and Front base panel (A) together
4. Put the base holder (F) back and tighten it to hold the base panels on the fan housing (D).

1

2

3

4