Comfort Zone 28-inch Bladeless Digital Tower Fan

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ12548

Original source file(s): CZ12548.Instruction Manual.01.pdf

Source SHA-256: 782c26deb8f72224a36dc6079ebe000e756d2053bb77995345e761ef711d9b26

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

28 Inch Bladeless DigitalTower Fan

LED display with remote control

9-Hour timer

Ultra quietbladeless design

70-Degree Oscillation

120V A.C./60Hz

3-Speed Settings

1-Low

2-Med

3-High

CZ12548-EC series

USING THE REMOTE CONTROL

The sensor of the remote control must be pointed at the fan receiver to operate properly.

The distance between the remote control and the fan should be within 20 feet and 30 degrees radius left to right of the fan. (see Fig. 1)

See the button functions as they appear on the remote control in Fig. 2

TIMER

ON/SPEED

Press the

button repeatedly to change the timer setting.

The time increases in increments of 10 minutes and 1 hours ,it has 11 time steps in total, which add up to set your desired timer setting. The maximum timer is 9 hours.

For example, to set time for 5 hours, press the TIMER button repeatedly till the indicator lights “5H” is lit .

Do not press the TIMER button if you want to keep the fan operating indefinitely.

TIMER

Press the ON/OFF button. The fan will start to operate at a medium speed and the indicator will lights “02”.

After starting the fan, the “SPEED” button is for setting the speed. Press this button repeatedly and you can choose from “01-02-03” and back to “01” speed in that sequence.

OSCILLATION

OFF

USING THE CONTROL PANEL

When you press this button, the fan oscillates at 0-70 degrees.

Press the Oscillation (SWING) button again if you want to keep the fan operating in one position. The fan will only oscillate when the Oscillation (SWING) button has been pressed.

Do not adjust the head of the fan manually or oscillation **parts could be damaged.**

Press the ON/OFF button to turn the fan off.

The button names and functions are shown on the control panel in Fig. 3.

SPEED, TIMER, SWING, ON/OFF logo are shown on the Control Panel. The function of the buttons on the control panel are the same as on the Remote Control.

The panel is controlled by touch screen, you need to touch the function logo to use it.

Fig. 3

Fig. 1

Fig. 2

Source page 1 - Panel 1 (top left) (OCR)

Comfort Zone.

©) ~omrort Zone

ES

CARE AND MAINTENANCE: LIMITED WARRANTY

Cleaning: CAUTION-Before cleaning the fan be sure to unplug the power cord from the outlet. Clean the grille surface with a clean damp cloth. Do not use harsh chemical or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN WATER. Allow fan to dry completely before use. Periodic grille cleaning with a vacuum will prevent dust build up. The motor is sealed and does not require any interior maintenance, or lubrication.

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer.

After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit

Maintenance: The Internal motor bearings are permanently was purchased outside the continental United States,

lubricated at the factory and do not require any additional return the unit to the place of purchase. This warranty

lubrication. does not cover damage caused by misuse, abuse,

overheating or alteration. Repairs made by anyone other

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN than Mr. Brands LLC are not covered in this warranty.

PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR | Mr.Brands LLC will not be held liable for any losses due to

BECOME DAMAGED IN ANY WAY. neglectful operation. All implied warranties, including the

Storage: Keep original carton for storage of the fan. Coil and tie | Warranties of merchantability and of fitness of purpose, if

the power cord to avoid damage during storage. applicable, are hereby limited in duration to the period of

one year from the date of original retail purchase. Some

-_ states do not allow limitations on how long an implied

Note: Some models come with a plug where you can replace warranty lasts, so the above limitations may not apply to

a fuse. If your model has this, please read and follow the below you. Incidental or consequential damages arising from a

instructions to replace the fuse. breach of either express or implied warranties are hereby

disclaimed and excluded. Some states do not allow the

This product employs overload protection (fuse). A blown fuse exclusion of limitation of incidental or consequential

indicates an overload or short-circuit situation. If the fuse blows, damages, so this limitation or exclusion may not apply to

unplug the product from the outlet, Replace the fuse as per the you. Upon the expiration of this warranty all such liability

user servicing instructions (follow product marking for proper will terminate. No other warranties are expressed or

fuse rating) and check the product. If the replacement fuse implied

blows, a short-circuit may be present and the product should .

be discarded or returned to an authorized service facility for . age

examination and/or repair. This warranty gives you specific legal rights, and you may

also have other rights which vary from state to state.

Fuse Replacement: No informal dispute settlement mechanisms are available.

1. Grasp plug and remove from the receptacle or other This limited warranty is given in lieu of all other warranties.

outlet device. Do not unplug by pulling on cord.

2. Open fuse cover by sliding open fuse access cover on Manufactured for:

top of attachment plug towards blades. See Fig. 2 M5 Brands ee

3. Remove fuse carefully. Use a small tool to pry the end Bristol On 19007

of the fuse from holder cavity. Be careful not to break 4-877-420-7555

4 a meen www.mrbrands.com

. Replace Tuse.

WARNING: Risk of fire. Replace fuse only with identical | “WW-comfortzoneproducts.com

2.5 or 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure A

Source page 1 - Panel 2 (top right) (OCR)

@) Comfort Zone. CZ12548-EC series

i

|]

1

\

28 Inch Bladeless DigitalTower Fan

Source page 1 - Panel 3 (bottom left) (OCR)

Tse Is properly seated WITHIN IS Cavity. heed WARNING:

Cancer and Reproductive Harm --

5. Close fuse cover by sliding it back to its original closed www. P65Warnings.ca.gov

position.

Rev. 07/20/23

Fig 1 Fig 2 Fig 3

(Slide Cover to Open

I pe | lp 4

Comfort Zone.

6) www.comfortzoneproducts.com

ES

Intended Use:

This product is intended for indoor residential and office use only, READ & SAVE THESE

not for industrial or other commercial applications. Use only with | [INSTRUCTIONS

electrical wiring that is in good working order and that meets

applicable codes and ordinances. If you have any questions Shock Hazard

whether your wiring is adequate, consult a qualified electrician. Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near

While using your fan, you should follow the IMPORTANT sinks, washing machines, swimming pools or other sources of

INSTRUCTIONS listed below. As part of those instructions, we water. Never locate fan where it may fall into a bathtub or other

have used the word "WARNING" to indicate the level of hazard: water receptacle. Do not use in damp environments such as

WARNING indicates a hazard which, if not avoided, could result flooded basements.

in injury or death.

IMPORTANT INSTRUCTIONS een

Do not touch fan motor when in use. This motor is hot when in

As with all electrical appliances, basic safety precautions should use, to avoid burns, do not let bare skin touch hot surfaces.

always be followed to reduce the risk of electric shock, fire, or

injury to persons, including the following precautions: Fire Hazard

. . . Fans have arcing or sparking parts inside. Do not use near

* Read all the instructions before using this fan. combustible rnaterals or flammable gases or sources of heat.

+ Use this fan only as described in this manual. Any other use not DO NOT USE in areas where gasoline, paint or flammable

recommended by the manufacturer may cause electrical shock, | materials are used or stored. To prevent a possible fire, do not

fire or injury to persons. block air intakes or exhaust in any manner. Do not insert or allow

+ Do not operate the fan with a damaged power cord or after the | foreign objects to enter any ventilation or exhaust opening as this

fan malfunctions or has been dropped in any manner. may cause an electric shock, fire, or damage the fan.

+ Use of extreme caution is necessary when any fan is used by or

near children, disabled persons or pets and whenever the fan is. Electrical Shock Hazard

left operating unattended. Do not use with damaged cord or plug. Use with adequate

+ Do not place the fan on a small, unlevel, uneven or any surface electrical system that is up to code.

which might allow fan to tip or fall.

+ For proper operation, fan should be placed on a smooth, to Prevent Electric Shock, this product

non-combustible, level surface. has a polarized two prong plug (one blade is wider than the

+ Always unplug fan when not in use, when moving from place other) that must be fully inserted in to a matching properly

to place, when assembling or disassembling parts, and before grounded outlet. This plug is designed to fit a polarized outlet

cleaning. only one way. If the plug does not fit fully into the outlet,

«The use of attachments, not recommended or sold by the reverse the plug. If the plug still does not fit, contact a qualified

manufacturer, may cause hazards. electrician. Do not attempt to defeat this safety feature.

Do not use outdoors. . . to Reduce the Risk of Fire or Electric

+ Do not use fan in window. Rain may cause electrical hazard Shock, do not use this product with any solid-state speed

(for non-window models). control “Uevice.

+ Do not operate the fan with blade guards or any safety device 7

removed. DO NOT operate any fan with a damaged cord or plug or after

+ Avoid the use of extension cords due to risk of fire. If an fan malfunctions, has been dropped or damaged in any manner.

extension cord must be used, the cord must be minimum Do not operate fan with a broken blade, safety cage or any visual

14 AWG and rated not less then 1875 watts. imperfections. Disconnect power before servicing. For repairs

+ Do not run power cord under carpeting. Do not cover cord with | covered under warranty, see warranty statement.

throw rugs, runners or the like. Arrange cord away from traffic

area where it will not be tripped over. .

DO NOT run power cord under carpeting. DO NOT cover cord

+ Do not insert or allow any object to enter any openings on the Pf 7

fan. Doing so may cause electric shock and/or fire hazard. with throw rugs, runners or the like. Arrange cord away from

Avoid contact with moving parts. traffic area where it will not be tripped over. Avoid the use of

A i ‘i jr i extension cords due to risk of fire. If an extension cord must

+ This appliance is not intended for use by persons (including be used, the cord must be minimum 14 AWG and rated not

children) with reduced physical, sensory or mental capabilities | ia. then 1875 watts. Do not use an extension cord unless the

or lack of experience and knowledge, unless they have

been given supervision or instruction concerning use of the plug can be completely inserted into its receptacle. Unplug

appliance by a person responsible for their safety. the fan when not in use. Do not operate fan with its ventilation

+ Children should be supervised to ensure they do not play with | OPstructed.

the appliance.

a

Source page 1 - Panel 4 (bottom right) (OCR)

3-Speed Settings

1-Low

2-Med

3-High

* 9-Hour timer

* Ultra quietbladeless design

* 70-Degree Oscillation Gi}

us

iste

°120V A.C. /60Hz ---

Intertek

www.comfortzoneproducts.com Save These Instructions

6) www.comfortzoneproducts.com -

ES

+ The sensor of the remote control must be pointed at the fan | When you press this button, the fan oscillates at 0-70 degrees.

receiver to operate properly. Press the Oscillation (SWING) button again if you want to keep

+ The distance between the remote control and the fan should | the fan operating in one position. The fan will only oscillate

be within 20 feet and 30 degrees radius left to right of the fan. _| when the Oscillation (SWING) button has been pressed

(see Fig. 1) Do not adjust the head of the fan manually or oscillation

+ See the button functions as they appear on the remote control_| parts could be damaged.

in Fig. 2 OFF

_ (Press the ON/OFF button to turn the fan off.

i USING THE CONTROL PANEL

The button names and functions are shown on the control

panel in Fig. 3.

Effective range: 12 Feet (4 Meter)

, SPEED, TIMER, SWING, ON/OFF logo are shown on the

Fig. 1 Control Panel. The function of the buttons on the control panel

are the same as on the Remote Control.

The panel is controlled by touch screen, you need to touch the

function logo to use it.

©

speed ose a P a

_ ® ® fj ® ©

© SPEED TIMER SWING ON/OFF

Fig. 2 Fig. 3

TIMER Care and Maintenance

Press the TIMER button repeatedly to change the timer setting, Cleaning: CAUTION-Before cleaning the fan be sure to

The time increases in increments of 10 minutes and 1 hours ,it| disconnect power cord from the plug. Clean the grille surface

has 11 time steps in total, which add up to set your desired with a clean came Co ee or ee narsh chemical or abrasive

ti tting. Th imum timeris 9h .

Imer setting, The maximum timer ts 9 nours WATER. Replace front grille before fan use. Allow fan to dry

completely before use. Periodic grille cleaning with a vacuum will

For example, to set time for 5 hours, press the TIMER button | Fyevent dust build up. The motor is sealed and does not require

repeatedly till the indicator lights “SH" is lit . any interior maintenance, cleaning or lubrication.

Do not press the TIMER button if you want to keep the fan | Maintenance: The Internal motor bearings are permanently

operating indefinitely. lubricated at the factory and do not require any additional

lubrication.

ON/SPEED - Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN

Press the ON/OFF button. The fan will start to operate ata_| pBLAGE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR

medium speed and the indicator will lights “02”. BECOME DAMAGED IN ANY WAY.

After starting the fan, the “SPEED” button is for setting the

speed. Press this button repeatedly and you can choose from “01-02-03” and back to “01” speed in that sequence.

| Storage: Keep original carton for storage of the fan. Coil and tie the power cord to avoid damage during storage.