# Comfort Zone Infrared Cabinet Heater with Remote

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ2062

Original source file(s): CZ2062C, CZ2062W.Instruction Manual.01.pdf; 125258.Instruction Manual.01.pdf; 125260.Instruction Manual.01.pdf

Source SHA-256: 1ccb9e3adc0086306bc38019b2e9c94bb4050ed86eaedc3e633f373d1034b4d5

Original PDF pages: 1 | Recovered reading units: 5

## Source page 1 (embedded text)

Binding edge - dimensions:420X290

290mm

210mm

Mr.Brands LLC

113 Fillmore St

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

07/20/2023

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from

the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit,

with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental

United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental

United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse,

overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC

will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability

and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail

purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to

you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed

and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or

exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are

expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

## Source page 1 - Panel 1 (top left) (OCR)

_4 He

©) Comfort Zone.

CZ2062 Series

: E S

= Model - CZ2062

-) .

ee Infrared Cabinet Heater

With Remote

**Features:**

¢ 2 heat settings & energy saving ECO mode

¢ 12-hour on/off timer

e Electronic controls

¢ Built-in USB Charging Ports

e Fan-forced for wide heat dispersion

¢ Grounded Cordset

° Safety tip-over switch

¢ Safety overheat protection system 2

**© 120V AC /60Hz/ 12.5A . %**

## Source page 1 - Panel 2 (top right) (OCR)

©) Comfort Zone ©) Comfort Zone.

**SD ---------EEEEEEEEEEEEEEEEEEEE-----**

**LIMITED WARRANTY PRODUCT DIAGRAM: 1 2 1415173**

-

Dual USB |

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from Ns Ports & I []

the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, 7 ” | ia 18

with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental # Pall | Control 8 High Low Eco vc sO) []

United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental Oooo Panel 8 1

United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, SS il @TMOOaNMEe®

overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC FBeeeoeed i Air Model - CZ2062

will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability | Outlet 1612 5 9 1013 4

and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail

purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to \ . - . ; _ .

you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed \\ 1 Signal-recelving window: for receiving remote control signal

‘ gt . narra ® 2. Digital display indicates set room temperature or time value

and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or D Wheel of the timer.

exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are or Leg 3. Power indication light: indicates when the unit is connected

expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Model - CZ2062 to power supply and rear master power switch is on.

No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties. 4. ON/OFF switch button: for power-on or off.

a 5. Mode button: for selecting the running mode.

; ; 7 ; ; ; , | === 6. High power mode indication light: the light is on when high power

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal -- mode is set.

dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties. Air Intake ‘See som ue fess er a 7. Low power mode indication light: the light is on when low power

‘Scr coc Ge Goo Ge fo a mode is set.

Manufactured for: ee 8. Energy-saving mode: the light is on when energy-saving

Mr.Brands LLC Cord Clamp 4} (S$ ECO mode is set.

113 Fillmore St External | CI ome ~ &5 9. Temp up button: to increase set temperature.

Bristol, PA 19007 Temperature 10. Temp down button: to reduce set temperature, .

1-877-420-7555 Sensor | °° 11. Timer indication light: the light is on when timer mode is set.

\ 12. Timer button: used for setting the timer and adjust time value

www.mrbrands.com Master --- for the timer.

www.comfortzoneproducts.com Power Switch W 13. °C/°F Button: (Button for alternating between Fahrenheit

and Celsius).

LA REMOTE CONTROL: 14. Celsius indicator light.

- nc Reproductive Harm 15. Fahrenheit indicator light.

www.P65Warnings.ca.gov 16. Control panel lock button.

©. 0 l Mode: Used for mode selection. 17. Control panel lock indicator.

Rev. 07/20/2023 ® | Power Button: Used for power-on or power off. 18. Dual USB Ports

Temp Up: To make temperature higher.

0) | Temp Down: To make temperature lower. PREPARATION .

| . a Place the heater on a firm, level surface and plug into a grounded

Timer Button: Used for setting timer and 120 Volt AC 60Hz power outlet and turn on the power switch in the rear

adjusting value of the timer. of the unit. You will hear a tone when master power switch is turned on.

Only operate heater in upright position.

Remove clear insulating film To replace remote control

from remote control battery battery, insert 1pc CR2025 BUILT-IN USB CHARGING PORTS

before remote control use battery

The dual USB charging port is designed

Remote Clear Insulating Remote Battery Battery as a DCP (Dedicated Charging Port) to ~~

Control Film Control Cover industry-standard protocol per the USB Ss

/ \ Battery Charging 1.2 Compliance Plan. NE ey

\ \ 7 ff -_- Early-generation or smaller consumer eel

y ! eed PusH ~ electronics typically accept one (1.0) Amp I S|

i] | Foun . of power during charging. However, newer |

electronics, such as the Apple iPad®, other eS

tablets and larger devices can accept and, ----|

in some cases, require up to 2.1 Amps xq

of power to charge and operate. As a . Ne

high power DCP, these ports can provide 5

up to 2.1 Amps of power to charge any i)

USB device, including the higher demand

products. USB ports have power when the heater is plugged in and the

master power switch is on with the unit in any mode.

Do not allow wires to dangle in front of heater output vent. Damage

to the wire, device or heater may result.

## Source page 1 - Panel 3 (bottom left) (OCR)

Reading orientation normalized by 180 degrees.

-_-_-_—-_-_-_-_-_--_-_S_--->_~7~7lES

**INTENDED USE:**

**READ & SAVE THESE**

This product is intended for indoor residential and office use only,

not for industrial or other commercial application. Use only with | N STR U CTI O N S

electrical wiring that is in good working order and that meets WARNING: SHOCK HAZARD

applicable codes and ordinances. This heater must be plugged Use your heater only in dry environments. This heater is not intended for use in

in to a 120V AC, 15 Amp (or larger) circuit. Do not plug anything a bathroom, laundry area, or similar locations, or near sinks, washing machines,

additional into the same circuit. If you have any questions swimming pools or other sources of water. Never locate heater where it may fall

whether your wiring is adequate, consult a qualified electrician. inte a batitub or other water receptacle. Do not use in damp environments such

Risk of fire, overheating, malfunction, property damage, injury :

**i WARNING: HOT SURFACES**

or even death may result if not adhered to. Do not touch body of heater when in use. This heater is hot when in use, to avoid

Use your heater only with a working smoke detector located burns, do not let bare skin touch hot surfaces. If provided, use handles when

in the vicinity of your heater. moving this heater.

## wo WARNING: FIRE HAZARD

While using your heater, you should follow the IMPORTANT Heater has hot and arcing or sparking parts inside. Do not use near combustible

INSTRUCTIONS listed below. As part of those instructions, we materials or flammable gases or sources of heat. DO NOT USE in areas where

have used the word “WARNING” to indicate the level of hazard: gasoline, paint or flammable materials are used or stored. Keep combustible

WARNING indicates a hazard which, if not avoided, could result materials such as furniture, pillows, bedding, papers, clothes and curtains at least

in injury or death 3 feet (0.9 m) from the front of the heater and keep them away from the sides and

. rear.To prevent a possible fire, do not block air intakes or exhaust in any manner.

Do not use on soft surfaces, like a bed, where openings may become blocked.

IM PORTANT INSTRUCTIONS Do not place the heater near a bed because objects such as pillows or blankets

can fall off the bed and be ignited by the heater. Do not insert or allow foreign _

When using electrical appliances, basic safety precautions should always objects to ae any ventlation or exhaust opening as this may cause an electric

be followed to reduce the risk of fire, electric shock and injury to persons, SNOCK, tire, or damage the neater.

including the following: WARNING: ELECTRICAL SHOCK HAZARD |

* Read all the instructions before using this heater. Cortona damaged cord or plug. Use with adequate electrical system that

¢ This heater is hot when in use. To avoid burns, do not let bare skin CAUTION: TO PREVENT ELECTRIC SHOCK.

: : : : 7

touch hot surfaces. Use provided handle when moving this heater. this product has a three prong grounded plug that must be inserted into a

Keep combustible materials, such as furniture, pillows, bedding, matching properly grounded outlet to reduce the risk of electrical shock. Do not

papers, clothes and curtains at least 3 feet (0.9 meters) from the front attempt to defeat this safety feature.

of the heater and keep them away from the sides and rear. DO NOT operate any heater with a damaged cord or plug or after heater

* Do not use heater unattended. Use of extreme caution is necessary malfunctions, has been dropped or damaged in any manner. Do not operate

when any heater is used by or near children, invalids, disabled persons heater with a broken heating element or ceramic cone or any visual imperfections.

or pets. Disconnect power before servicing. For repairs covered under warranty, see

if 8

* Do not operate the heater with a damaged power cord or after the Serve ty toophone or av ater repairs contact Comfort Zone Customer

heater malfunctions, has been dropped or damaged in any manner. :

Return heater to authorized service facility for examination, electrical WARNING: This heater has a voltage rating of 120 volts. The cord has a 3-prong

or mechanical adjustment or repair grounding-type plug (A) which fits the 3-slot grounded receptacle (A2). DO NOT

* Do not use heater outdoors. ; ; ; ; remove the grounding prong (A1) if only a 2-slot receptacle (B) is available.

° Use your heater only in dry environments. This heater is not intended For connecting 3-prong grounding-type plug to 2-slot receptacle, use an ADAPTER

for use in a bathroom, laundry area, or similar locations, or near sinks, (©). The grounding lug (C1) extending from the adapter must be connected to a

washing machines, swimming pools or other sources of water. Never permanent ground with a Metal Screw (D) such as a properly grounded outlet

locate heater where it may fall into a bathtub or other water container. box (E)

Do not use in damp environments such as flooded basements. : . , ,

* Do not place the heater on a small, unlevel, uneven or any surface The adapter should not be used if a 3-slot grounded receptacle is available.

which might allow heater to tip or fall. DO NOT DEFEAT THE SAFETY PURPOSE OF EITHER

**. A GROUNDED PRONG OR A GROUNDING LUG.**

¢ For proper operation, heater should be placed on a smooth,

non-combustible, level surface. Do not place on rugs, carpet, vinyl (A2) (B) (© ()

flooring or other plastic surfaces. Not for use outdoors or in wet areas. (A) () (0)

¢ This heater is not designed as a primary heat source. (1) ) Op

: . ® ® - g--so 3

¢ Always plug heaters directly into a wall outlet/receptacle. Never use Pree

with an extension cord or relocatable power tap (outlet/power strip). { (A) (11) (D) f (1) (1)

Always unplug heater when not in use. (At) (C1)

¢ Do not run power cord under carpeting. Do not cover cord with throw

rugs, runners or similar coverings. Arrange cord away from traffic area PET OWNERS NOTE:

where it will not be tripped over. The health of birds and some small pets are extremely sensitive to the fumes

* To disconnect heater, turn controls off then remove plug from outlet. given of uring the initial use of many appliances. Although these fumes are not

. . . a armful to humans, it is recommended that this heater not be used around birds

* Do not insert or allow foreign objects to enter any ventilation or exhaust and small pets during its initial use until the manufacturing corrosion coatings

opening as this may cause an electric shock or fire or damage the heater. burn off.

* To prevent a possible fire, do not block air intakes or exhaust in any .

manner. Do not use on soft surfaces like a bed, where openings may WARNING: LITHIUM BATTERY COIN CELL SAFETY

become blocked Keep lithium coin batteries out of the reach of small children; coin cell

. . ; a . batteries can be accidentally ingested. If ingested, these batteries may leak

¢ A heater has hot and arcing or sparking parts inside. Do not use it in harmful contents causing chemical burns, perforation of soft tissue, and

areas where gasoline, paint or flammable liquids are used or stored. in severe cases may cause death, Lithium coin batteries | must be removed

. ‘i wae immediately if swallowed. Seek medical attention immediately. If you or

* Use this heater only as described in this manual. Any other use not your doctor suspects that a battery has been ingested for assistance in

recommended by the manufacturer may cause fire, electric shock the US call the NATIONAL BATTERY INGESTION HOTLINE any time at

or injury to persons or property. (202) 625-3333: in Canada call 416-813-5900.

DOT

ol :

al SUO!}ONJ}SU] BSE] SACS Woo'sjonposdeuoZYOJWOo MMM

## Source page 1 - Panel 4 (bottom right) (OCR)

Reading orientation normalized by 180 degrees.

EEE eee ---------- EEE

OPERATING INSTRUCTIONS 3. Setting timer-power-off

Note: ONLY under power-on mode can you set timer-power-off function. IMPORTANT SAFETY FEATURES REPAIR: DO NOT OPERATE THE HEATER WITHOUT THE GRILLE

; Timer function not an excuse to leave heater unattended. IN PLACE. DO NOT USE THE HEATER IF IT HAS MALFUNCTIONED

1. Start and select working mode TIP-OVER SAFETY FEATURE: This heater is equipped with a OR BECOME DAMAGED IN ANY WAY. RETURN HEATER TO

After starting the unit, press the timer tip-over safety feature. Once the heater is tipped over, an internal MECHANICAL ANIUSYMENT On HEPAII ho ELECTRICAL OR

With master power switch at the rear or button on the control panel or remote switch will automatically shut the heater off. Once the heater is restored D

of the unit on, turn the heater on by control to an upright position, the heater will reset. To continue operation, STORAGE: K iginal carton for st f the heat

ressing the POWER button on the . turn on the heater using the supplied remote control or the control ’ aE; Keep original carton tor storage oF the heater.

P 9 : anel on the heater, Coil and tie the power cord to avoid damage during storage.

control panel or by pressing the Power Digital display changes from set Pi .

©) button on the supplied remote control temperature to time value for the timer OVERHEAT SAFETY FEATURE: This heater is equipped with a overheat | TROUBLESHOOTING:

Once power is off, heating elements Each press of the timer button will safety feature. When the heater’s internal components reach a certain If the heater will not operate, please check the following before

will stop working at first. Fan will 08-0 t-----i2 increase the timer length by 1 hour up temperature that could cause overheat and possible fire, the heater will seeking repair of service:

continue working for up to 2 minutes to to 12 hours. To cancel the timer, cycle automatically shut off.To reset, turn heater off and switch master power 1. Check if the power cord is plugged into an electrical outlet,

emit residual heat inside the unit. through the lengths until the value is switch on the rear of the unit to off position. Unplug the heater and let if not, plug in.

“QQ” it cool down for around 20 minutes. Plug the heater back into the wall . . . . .

Select a heat setting outlet and turn master switch and on/off switch to on. 2. Check if electricity to the main fuse is working.

Press the MODE button to toggle 3. Check if the battery in remote control is not dead and if the

between the two heat settings and The timer light is on when CARE AND MAINTENANCE insulating film is pulled out.

i timer-power-off is set. 4. Check if the main power switch at the back of the unit is on.

energy saving ECO mode. p MAINTENANCE: p

rr oo . NOTE: The heater may not operate if the thermostat is set lower

1. Turn off the power switch in the rear of the unit. than the room temperature. To begin operation, raise the thermostat

High Mode uses 1,500W; Low Mode 4, Setting timer-power-on 2. Unplug the unit and let it cool completely. ; temperature setting.

al- uses 1,000W. ECO mode is an Note: ONLY under power-off mode can you set timer-power-on function. 3. To keep the heater clean, the outer shell may be cleaned with a

oo) Economic Energy Saving Function. Main power switch must be on. Timer function not an excuse to leave soft, damp cloth. You may use a mild detergent if necessary. After

) When ECO mode is chosen, the heater heater unattended. cleaning, dry the unit with a soft cloth. CAUTION: DO NOT let liquid

High Low ECO | will set the temperature automatically enter the heater. ; : ; ;

to 68°F (20°C) under this mode. 4, DO NOT use alcohol, gasoline, abrasive powders, furniture polish,

Under power-off mode, press the timer or rough brushes to clean the heater. This may cause damage or

or button on the control panel or remote deterioration to the surface of the heater.

control. 5. DO NOT immerse the heater in water.

6. Wait until the unit is completely dry before use.

. a. aa. . 7. Air filter should be cleaned after 3 months use, when it appears dirty

2. Setting room temperature Digital pa will inca the “ or looks like it is blocking air flow. With heater unplugged, remove 2

~O0-0 12 fin ue butt ° iilin ac he tim e assembly screws as illustrated below. With filter assembly removed,

length by T hour upto 12 hours. To clean all parts of filter assembly. Allow parts to completely dry before

f : ; installing onto the heater.

Adjust the thermostat by pressing the cancel the timer, cycle through the oe .

(a) (v) arrows on the control panel or remote lengths until the value is “00” 8, Reassemble filter and then attach to heater. WARNING: Do not

control. use heater without filter assembly in place or with a filter that is not

completely dry.

The light is on when The Unit Filter Assembly Screws

59--60-------B6 Set temperature indication varies from timer-power-on is set. --

[ | 59°F to 86°F, or from 15°C to 30C°. oo _ --- oo

Once you have chosen the desired - SaaS

Or temperature, the heater will remain on SS oS ae ae ae = e22e22a/

until the room temperature increases to 5. Setting electro-lock SS SS ae ae ae (5eese=.| iN

~1$-(h---30 the temperature on the digital display. Electro-lock can avoid unwanted use by children. Electro-lock can be set in = oo oo oo et oa (See S= S| -

The heater will cycle on and off to both power-on and power-off modes. Lock function not an excuse to leave - - Air Filter

maintain the desired room temperature. heater unattended. Oo mp & io) &

Press °C/°F button on control panel Press LOCK button on control panel | \\ | | \ |

to switch between Fahrenheit value or for 3 seconds. Locking is confirmed SS _---.

Celsius value. when a tone is heard. When locked, W U W U

trol | te trol will

rot funtion, ae ‘wil be heard ‘when 9. Reassemble filter and then attach to heater. WARNING: Do not

When Fahrenheit indicating light is on, buttons are pressed but they will not use heater without filter assembly in place or with a filter that is not

© digital display indicates Fahrenheit function. completely dry.

~i. > e274 | value.

When Celsius indicating light is on, To unlock the locked control panel,

digital display indicates Celsius value. press LOCK button on control panel

for 3 seconds. Unlock is confirmed

when a tone is heard. Control panel

and remote control return to normal

functions.

DOT a 5

ow i °

|