Comfort Zone Electric Baseboard Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ600

Original source file(s): CZ600.Instruction Manual.01.pdf; 125100.Instruction Manual.01.pdf

Source SHA-256: 11b8f20d14989c28a779b6cccd683e6b9af7894d688a4d77dad20feabe38beb0

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

Binding edge - dimensions:420X290

290mm

210mm

Mr.Brands LLC

113 Fillmore St

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the **warranty period, if the unit was purchased within the continental** United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This **warranty does not cover damage caused by misuse, abuse,** overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation.

All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this

warranty all such liability will terminate. No other warranties are

expressed or implied. This warranty gives you specific legal rights,

and you may also have other rights which vary from state to state.

No informal dispute settlement mechanisms are available. This

limited warranty is given in lieu of all other warranties.

07/20/2023

Source page 1 - Panel 1 (top left) (OCR)

O) Comfort Zone.

CARE AND MAINTENANCE: LIMITED WARRANTY

WARNING: ALWAYS UNPLUG THE CORD BEFORE This unit is guaranteed to the original retail purchaser against

MOVING OR SERVICING. Do not use harsh chemical | defects in quality or workmanship for a period of one year from

or abrasive cleaners. DO NOT IMMERSE THE the date of original purchase. If this unit fails because of a

HEATER IN WATER. Allow heater to dry completely manufacturing defect within 30 days of purchase, return the unit,

before use with your receipt, to the retailer. After 30 days, but within the

. warranty period, if the unit was purchased within the continental

. United States, return it, to Mr. Brands LLC for repair or

CLEANING: IMPORTANT! DO NOT IMMERSE replacement. If the unit was purchased outside the continental

HEATER IN WATER! Clean the heater grille with the United States, return the unit to the place of purchase. This

vacuum brush attachment on your vacuum cleaner. warranty does not cover damage caused by misuse, abuse,

This will remove lint and dirt from inside the heater. overheating or alteration. Repairs made by anyone other than

DO NOT ATTEMPT TO TAKE APART THE HEATER. Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC

DO NOT REMOVE THE HEATER GRILLE. Clean the will not be held liable for any losses due to neglectful operation.

. All implied warranties, including the warranties of merchantability

body of the heater with a soft cloth. and of fitness of purpose, if applicable, are hereby limited in

. . . duration to the period of one year from the date of original retail

CAUTION: Do not use gasoline, benzene, paint purchase. Some states do not allow limitations on how long an

thinner, harsh cleaners, etc. as they will damage the implied warranty lasts, so the above limitations may not apply to

heater. NEVER USE ALCOHOL OR SOLVENTS. you. Incidental or consequential damages arising from a breach

of either express or implied warranties are hereby disclaimed

= REPAIR: DO NOT OPERATE THE HEATER WITHOUT | and excluded. Some states do not allow the exclusion of limitation

THE GRILLE IN PLACE. DO NOT USE THE HEATER of incidental or consequential damages, so this limitation or

= IF IT HAS MALFUNCTIONED OR BECOME exclusion may not apply to you. Upon the expiration of this

warranty all such liability will terminate. No other warranties are

([D) DAMAGED IN ANY WAY. expressed or implied. This warranty gives you specific legal rights,

. oa and you may also have other rights which vary from state to state.

OD) STORAGE: Keep original carton for storage of the No informal dispute settlement mechanisms are available. This

N heater. Coil and tie the power cord to avoid damage limited warranty is given in lieu of all other warranties.

during storage.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited **warranty is given in lieu of all other warranties.**

Manufactured for:

Mr.Brands LLC

113 Fillmore St

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

L\ cosnne:

Cancer and Reproductive Harm --

www.P65Warnings.ca.gov

Rev. 07/20/2023

Source page 1 - Panel 2 (top right) (OCR)

QO) Comfort Zone. zoo Sees

fT nara Os ee

Q comfort Zor®

Electric Baseboard Heater

Features:

e Adjustable Thermostat ¢ Safety Overheat Protection

¢ Two Settings: e Safety Tip-Over Protection

High: 1,500 Watts (5,120 BTU) ® Silent Operation

Low: 750 Watts ¢ Sturdy Metal Body

¢ Top Mounted Control Panel ° 120V AC /60Hz/12.5A

¢ Power Indicator Light

Source page 1 - Panel 3 (bottom left) (OCR)

Reading orientation normalized by 180 degrees.

lfe

©) Comfort Zone

EEE

U S AG E SETTING THERMOSTAT: After heater has been turned on and

the room has reached the desired temperature, slowly rotate

. the thermostat knob counter-clockwise until the heater shuts

HEATER OPERATION: . - . off (you should hear a faint “click”). By leaving the thermostat

Always operate the heater in the upright position following all at this setting it will automatically maintain this temperature. To

instructions and recommendations listed in this manual. lower temperature, rotate the knob further counter-clockwise

HEATER LOCATION: Place the heater in the area of the room (towards the LOW position). To raise the temperature, rotate the

that is coldest. Do not locate against walls or behind drapes thermostat knob clockwise (towards the HIGH position).

or furniture.

TURNING HEATER OFF: Turn the Power Control dial to the

HEATER CONNECTION: Plug heater directly into 120 Volt OFF position before unplugging or plugging in the heater.

AC, 60Hz wall outlet. Be sure plug fits tightly in outlet. A loose Heater should be unplugged when not in use.

connection may cause overheating and damage to the plug

or heater. IMPORTANT SAFETY FEATURES:

NOTE: To prevent overloading a circuit, do not plug the heater The power indicator light, located near the control panel, lights

into a circuit that is servicing other electrical needs. whenever the heater IS plugged in. The heater is equipped with

an automatic overheat protection device located inside the body

POWER INDICATOR LIGHT: This heater is equipped with a of the heater. If the heater grille is obstructed, or if the heater gets

Power Indicator Light. The power light will illuminate when the too hot for any reason, the automatic overheat protection device

unit is plugged in. will turn the heater off. To reset the heater, simply turn power off

and unplug the heater for 10 minutes until it cools down and you

TURNING HEATER ON: To start the heater, turn the Power may plug in and restart the heater. Be sure that the heater is on

Control dial from the OFF position to the LOW or HIGH setting. a smooth level surface with no obstructions. The heater is also

Then rotate the Thermostat Control clockwise to the HIGH equipped tith a safety tip-over switch. This switch will shut the

THERMOSTAT position as described below. (During the heaters heater off when the heater is tipped over. It will reset when the

initial use, you may experience a slight odor or smoking. This is heater is placed upright.

the result of the heating element lubrication “burning off”. This is

normal and will go away after a few minutes of use.)

1 \ 4

1 |

o SF

Thermostat Power Power

Control Control Dial Indicator Light

POWER CONTROL DIAL: This heater has two heat settings:

High and Low. Use the higher setting (1500 watt) to raise the

room temperature quickly. When the desired temperature is

reached use the Low setting. It is usually sufficient to maintain

a comfortable temperature.

as °

-_-_- eee PFD

|

Source page 1 - Panel 4 (bottom right) (OCR)

Reading orientation normalized by 180 degrees.

INTENDED USE: READ & SAVE THESE

This product is intended for indoor residential and office use only, not

for industrial or other commercial application. Use only with electrical I N STR U CTl O N)

wiring that is in good working order and that meets applicable codes

and ordinances. This heater must be plugged in to a 120V AC, 15 WARNING: SHOCK HAZARD

Amp (or larger) circuit. Do not plug anything additional into the same Use your heater only in dry environments. This heater is

circuit. If you have any questions whether your wiring is adequate, not intended for use in a bathroom, laundry area, or similar

consult a qualified electrician. Risk of fire, overheating, malfunction, locations, or near sinks, washing machines, swimming pools

property damage, injury or even death may result if not adhered to. or other sources of water. Never locate heater where it may fall

Use your heater only with a working smoke detector located in the into a bathtub or other water receptacle. Do not use in damp

vicinity of your heater. environments such as flooded basements.

While using your heater, you should follow the IMPORTANT .

INSTRUCTIONS listed below. As part of those instructions, we WARNING: MA or SURFACES . This heater is hot wh

have used the word “WARNING” to indicate the level of hazard: muse. to avoid bins, do not let bare skin touch hot surfaces.

WARNING indicates a hazard which, if not avoided, could result in use, to avoid burns, do not let bare skin touch hot surfaces.

in injury or death. If provided, use handles when moving this heater.

IMPORTANT INSTRUCTIONS - | ARMING: FIRE HAZARD sats is

Heater has hot and arcing or sparking parts inside. Do not use

When using electrical appliances, basic safety precautions should always near combustible materials or flammable gases or sources of

be followed to reduce the risk of fire, electric shock and injury to persons, heat. DO NOT USE in areas where gasoline, paint or flammable

including the following: materials are used or stored. Keep combustible materials such

* Read all the instructions before using this heater. as furniture, pillows, bedding, papers, clothes and curtains at

* This heater is hot when in use. To avoid burns, do not let bare skin least 3 feet (0.9 m) from the front of the heater and keep them

touch hot surfaces. Use provided handle when moving this heater. Keep away from the sides and rear. To prevent a possible fire, do not

combustible materials, such as furniture, pillows, bedding, papers, block air intakes or exhaust in any manner. Do not use on soft

clothes and curtains at least 3 feet (0.9 meters) from the front of the surfaces, like a bed, where openings may become blocked. Do

heater and keep them away from the sides and rear. not place the heater near a bed because objects such as pillows

* Do not use heater unattended. Use of extreme caution is necessary when or blankets can fall off the bed and be ignited by the heater.

any heater is used by or near children, invalids, disabled persons or pets. Do not insert or allow foreign objects to enter any ventilation or

* Do not operate the heater with a damaged power cord or after the exhaust opening as this may cause an electric shock, fire, or

heater malfunctions, has been dropped or damaged in any manner. damage the heater.

Return heater to authorized service facility for examination, electrical or

mechanical adjustment or repair. WARNING: ELECTRICAL SHOCK HAZARD

* Do not use heater outdoors. Do not use with damaged cord or plug. Use with adequate

Use your heater only in dry environments. This heater is not intended electrical system that is up to code.

for use in a bathroom, laundry area, or similar locations, or near sinks,

washing machines, swimming pools or other sources of water. Never CAUTION: TO PREVENT ELECTRIC SHOCK .

locate heater where it may fall into a bathtub or other water container. This product has a polarized two prong plug (one blade is _

Do not use in damp environments such as flooded basements. wider than the other) that must be fully inserted into a matching

* Do not place the heater on a small, unlevel, uneven or any surface which properly grounded outlet. This plug is designed to fit a polarized

might allow heater to tip or fall. outlet only one way. If the plug does not fit fully into the outlet,

* For proper operation, heater should be placed on a smooth, reverse the plug. If the plug still does not fit, contact a qualified

non-combustible, level surface. Do not place on rugs, carpet, vinyl electrician. Do not attempt to defeat this safety feature.

flooring or other plastic surfaces. Not for use outdoors or in wet areas. Do not operate any heater with a damaged cord or plug

* This heater is not designed as a primary heat source. or after heater malfunctions, has been dropped or damaged

* Always plug heaters directly into a wall outlet/receptacle. Never use with in any manner. Do not operate heater with a broken heating

an extension cord or relocatable power tap (outlet/power strip). Always element or ceramic cone or any visual imperfections. Disconnect

unplug heater when not in use. power before servicing. For repairs covered under warranty, see

* Do not run power cord under carpeting. Do not cover cord with throw warranty statement. For all other repairs contact Comfort Zone®

rugs, runners or similar coverings. Arrange cord away from traffic area Customer Service by telephone or mail for information

where it will not be tripped over. and assistance.

* To disconnect heater, turn controls off then remove plug from outlet.

© Do not insert or allow foreign objects to enter any ventilation or exhaust PET OWNERS NOTE:

opening as this may cause an electric shock or fire or damage the heater. The health of birds and some small pets are extremely

© To prevent a possible fire, do not block air intakes or exhaust in any sensitive to the fumes given off during the initial use of many

manner. Do not use on soft surfaces like a bed, where openings may appliances. Although these fumes are not harmful to humans, it

become blocked. is recommended that this heater not be used around birds and

* A heater has hot and arcing or sparking parts inside. Do not use it in small pets during its initial use until the manufacturing corrosion

areas where gasoline, paint or flammable liquids are used or stored. coatings burn off.

Use this heater only as described in this manual. Any other use not

recommended by the manufacturer may cause fire, electric shock

or injury to persons or property.

2

TI

a SUOIONAJSU] BSOU] SACS WOd's}ONpoJdauOZHOJWOO' MMM

aA