Comfort Zone Electric Utility Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ799BK

Original source file(s): CZ799BK.Instruction Manual.01.pdf; 120237.Instruction Manual.01.pdf

Source SHA-256: 63cecd935f9d62771c1da29bc93def9ad42ce99d0f95eca1ce7d3595fbc4f118

Original PDF pages: 4 | Recovered reading units: 5

Source page 1 (embedded text)

Features:

• Adjustable Thermostat with Anti-freeze Setting

• Dual Heat Settings:

1500 watts (5120 BTUs)

1300 watts

• Front Mounted Control Panel

• Power Indicator Light

• Safety Overheat Protection

• Safety Tip-Over Protection

• Convenient Carry Handle

• Sturdy Metal Frame

• 120V A.C. / 60 Hz. 12.5A

Electric Utility Heater

Model No. CZ799BK Series

Save These Instructions

Source page 2 (embedded text)

INTENDED USE:

This product is intended for indoor residential and office use only, not for industrial or other commercial application. Use only with electrical wiring that is in good working order and that meets applicable codes and ordinances. This heater must be plugged in to a 120V AC, 15 Amp. (or larger) circuit. Do not plug anything additional into the same circuit. If you have any questions whether your wiring is adequate, consult a qualified electrician. Risk of fire, overheating, malfunction, property damage, injury or even death may result if not adhered to.

Use your heater-fan only with a working smoke detector located in the vicinity of your heater/fan.

While using your heater/fan, you should follow the IMPORTANT INSTRUCTIONS listed below. As part of those instructions, we have used the word “WARNING” to indicate the level of hazard: WARNING indicates a hazard which, if not avoided, could result in injury or death.

IMPORTANT INSTRUCTIONS:

• When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

• Read all the instructions before using this heater/fan.

• This heater/fan is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use provided handle when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet (0.9 meters) from the front of the heater-fan and keep them away from the sides and rear.

• Do not use heater unattended. Use of extreme caution is necessary when any heater is used by or near children, invalids, disabled persons or pets.

• Do not operate the heater with a damaged power cord or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment or repair.

• Do not use heater outdoors.

• Use your heater only in dry environments. This heater is not intended for use in a bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water. Never locate heater where it may fall into a bathtub or other water container. Do not use in damp environments such as flooded basements.

• Do not place the heater on a small, unlevel, uneven or any surface which might allow heater to tip or fall.

• For proper operation, heater should be placed on a smooth, non-combustible surface. Do not place on rugs, carpet, vinyl flooring or other plastic surfaces. Not for use outdoors or in wet areas.

• This heater is not designed as a primary heat source.

• Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip). Always unplug heater when not in use.

• Do not run power cord under carpeting. Do not cover cord with throw rugs, runners or similar coverings. Arrange cord away from traffic area where it will not be tripped over.

• To disconnect heater, turn controls off then remove plug from outlet.

• Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire or damage the heater.

• To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces like a bed, where openings may

become blocked.

• A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint or flammable liquids are used or stored.

• Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons or property.

WARNING: SHOCK HAZARD

Use your heater only in dry environments. This heater is not intended for use in a bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water. Never locate heater where it may fall into a bathtub or other water container. Do not use heater outdoors. Do not use in damp environments such as flooded basements.

WARNING: HOT SURFACES

Do not touch body of heater when in use. This heater is hot when in use, to avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater.

WARNING: FIRE HAZARD

Heater has hot and arcing or sparking parts inside. Do not use near combustible materials or flammable gases or sources of heat. DO NOT USE in areas where gasoline, paint or flammable materials are used or stored. Keep combustible materials such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.

Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock, fire, or damage the heater.

WARNING:

ELECTRICAL SHOCK HAZARD

Do not use with damaged cord or plug. Use with adequate electrical system that is up to code.

The supply cord has a polarized plug. As a safety feature this plug will fit in a polarized outlet only one way. To prevent electric shock, match wide blade of plug to wide slot, fully insert plug. If the plug does not fit contact a qualified electrician.

Do not operate any heater with a damaged cord or plug or after heater malfunctions, has been dropped or damaged in any manner. Do not operate heater with a broken heating element or ceramic cone or any visual imperfections. For repairs covered under warranty, see warranty statement. For all other repairs

contact Comfort Zone® Customer Service by telephone or mail for information and assistance.

PET OWNERS NOTE:

The health of birds and some small pets are extremely sensitive to the fumes given off during the initial use of many appliances. Although these fumes are not harmful to humans, it is recommended that this heater not be used around birds and small pets during its initial use until the manufacturing corrosion coatings burn off.

SAVE THESE INSTRUCTIONS

Source page 3 (embedded text)

USAGE:

HEATER OPERATION: Always operate the heater in the upright position following all instructions and recommendations listed in this manual.

HEATER LOCATION: Place the heater in the area of the room that is coldest.

HEATER CONNECTION: Plug heater directly into 120 volt A.C., 60Hz wall outlet. Be sure plug fits tightly in outlet. A loose connection may cause overheating and damage to the plug or heater. NOTE: To prevent overloading a circuit, do not plug the heater into a circuit that is servicing other electrical needs.

TURNING HEATER ON: To start the heater, turn the ON/OFF Power Level/Fan Dial from the OFF position to the 1300 or 1500 watt setting. Then rotate the Thermostat Control clockwise to the HIGH THERMOSTAT position as described below. (During the heaters initial use, you may experience a slight odor or smoking. This is the result of the heating element lubrication “burning off”. This is normal and will go away after a few minutes of use.)

POWER LEVEL SWITCH: This heater has two heat settings: 1300 and 1500 watts. Use the higher setting (1500 watt) to raise the room temperature quickly. When the desired temperature is reached use the lower 1300 watt setting. It is usually sufficient to maintain a comfortable temperature.

ADJUSTABLE THERMOSTAT WITH ANTI-FREEZE SETTING:

After heater has been turned on and the room has reached the desired temperature, slowly rotate the thermostat knob counter-clockwise until the heater shuts off (you should hear a faint “click”). By leaving the thermostat at this setting it will automatically maintain this temperature. To lower temperature, rotate the knob further counter-clockwise (towards the LOW position). To raise the temperature, rotate the thermostat knob clockwise (towards the HIGH position).

When set to the Anti-Freeze setting, the Heater will turn on whenever the temperature drops below 40°F, which is helpful to economically prevent ice formation in garages and other unheated spaces.

TURNING HEATER OFF: Turn the ON/OFF Power Level/Fan Dial to the OFF position before unplugging or plugging in the heater. Heater should be unplugged when not in use. To disconnect heater, turn **controls to OFF, then remove plug from outlet.**

ASSEMBLY INSTRUCTIONS:

Before initial use some assembly is required. With a phillips screwdriver, attach handle to heater body using screws provided as shown in the photo.

IMPORTANT SAFETY FEATURES

This heater includes a visual alarm to warn that parts of the heater are getting excessively hot. If the caution light comes on, immediately turn the heater off and inspect for any objects on or adjacent to the heater that may cause high temperatures. DO NOT OPERATE THE HEATER WITH THE CAUTION LIGHT ON. The power indicator light, located near the power control, lights whenever the heater is turned on. The heater is equipped with an automatic overheat protection device located inside the body of the heater. If the heater grille is obstructed, or if the heater gets too hot for any reason, the automatic overheat protection device will turn the heater off. To reset the heater, simply turn power off and unplug the heater for 10 minutes until it cools down and then you may plug the heater in and restart. Be sure that the heater is on a smooth level surface with no obstructions. The heater is also equipped with a safety tip-over switch to turn power off to the heater when the heater tips over. To resume heater functions simply stand heater upright.

CARE AND MAINTENANCE

CLEANING: CAUTION - Before cleaning the heater be sure to disconnect power cord and allow the heater to cool completely. This heater should be cleaned at least once a year to maintain proper performance. Clean the outside surface with a clean damp cloth. Do not use harsh chemical or abrasive cleaners. DO NOT IMMERSE THE HEATER IN WATER. Allow heater to dry completely before use.

REPAIR: DO NOT OPERATE THE HEATER WITHOUT THE GRILLE IN PLACE. DO NOT USE THE HEATER IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY. RETURN HEATER TO AUTHORIZED FACILITY FOR EXAMINATION, ELECTRICAL OR MECHANICAL ADJUSTMENT OR REPAIR.

STORAGE: Keep original carton for storage of the heater. Coil and tie the power cord to avoid damage during storage.

Anti-freeze

Setting

Thermostat

Control

Power

Indicator

Light

ON/OFF

Power Level/

Fan Dial

Caution

Indicator

Light

Source page 4 (embedded text)

LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year

from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase,

return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased

within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased

outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage

caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not

covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied

warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in

duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how

long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages

arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not

allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to

you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No

informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr. Brands LLC

113 Fillmore St

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

Rev. 07/19/2023