Comfort Zone Flat Panel Halogen Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZHTV9

Original source file(s): CZHTV9.Instruction Manual.01.pdf; 125119.Instruction Manual.01.pdf

Source SHA-256: d09cd5c0faaca959196db36b2731595a1c0cf83a6fed96d5527456c9c797b843

Original PDF pages: 2 | Recovered reading units: 2

Source page 1 - OCR transcription (OCR)

. INTENDED USE: WARNING: SHOCK HAZARD

Model #CZHTV9 Series This product is intended for indoor residential and office use only, not Use your heater only in dry environments. This heater is not

for industrial or other commercial application. Use only with electrical intended for use in a bathroom, laundry area, or similar

wiring that is in good working order and that meets applicable codes -_igcations, or near sinks, washing machines, ewimming pools or

and ordinances. This heater must be plugged in to a 120V AC, 15 Amp. other sources of water. Never locate heater where it may fall

om or O ne (or larger) circuit. Do not plug anything additional into the same circuit. into a bathtub or other water container. Do not use heater

° If you have any questions whether your wiring is adequate, consult a Gutdoore. Do not use in damp environments such as flooded

wy . . . qualified electrician. Risk of fire, overheating, malfunction, property basements.

America’s Heating and Cooling Choice damage, injury or even death may result if not adhered to.

Use your heater-fan only with a working smoke detector located in the WARNING: HOT SURFACES

vicinity of your heater/fan Do not touch body of heater when in use. This heater is hot

when in use, to avoid burns, do not let bare skin touch hot

While using your heater/fan, you should follow the IMPORTANT surfaces. If provided, use handles when moving this heater.

INSTRUCTIONS listed below. As part of those instructions, we have

- used the word “WARNING” to indicate the level of hazard:

HEE WARNING indicates a hazard which, if not avoided, could result in WARNING: FIRE HAZARD

ee Ses injury or death. Heater has hot and arcing or sparking parts inside. Do not use

ee cies | ie near combustible materials or flammable gases or sources of

ea lites ie IMPORTANT INSTRUCTIONS heat. DO NOT USE in areas where gasoline, paint or

Saeed Ae hes | flammable materials are used or stored. Keep combustible

ree 24 AE ee | When using electrical appliances, basic precautions should always be materials such as furniture, pillows, bedding, papers, clothes

me 24 Bib bos followed to reduce the risk of fire, electric shock and injury to persons, and curtains at least 3 feet (0.9 m) from the front of the heater

ce a Br} 3 including the following: and keep them away from the sides and rear. To prevent a

& 1 = * Read all the instructions before using this heater/fan. possible fire, do not block air intakes or exhaust in any manner.

BR tea = * This heater/fan is hot when in use. To avoid burns, do not let bare Do not use on soft surfaces, like a bed, where openings may

z = skin touch hot surfaces. Use provided handle when moving this become blocked. Do not place the heater near a bed because

= heater. Keep combustible materials, such as furniture, pillows, objects such as pillows or blankets can fall off the bed and be

3 ‘ bedding, papers, clothes and curtains at least 3 feet (0.9 meters) ignited by the heater. Do not insert or allow foreign objects to

3 f from the front of the heater-fan and keep them away from the sides enter any ventilation or exhaust opening as this may cause an

at Pane 3 ana ret elect shock re, or damage the heat.

“ 2 * Do not use heater unattended. Use of extreme caution is necessary

ae F" when any heater is used by or near children, invalids, disabled .

Ee F persons or pets WARNING:

aiocaen eater 43 + Do not operate the heater with a damaged power cord or after tne ~~» ELECTRICAL SHOCK HAZARD

~ heater malfunctions, has been dropped or damaged in any manner. Do not use with damaged cord or plug. Use with adequate

Return heater to authorized service facility for examination, electrical electrical system that is up to code.

ee or mechanical adjustment or repair.

* Do not use heater outdoors. The supply cord has a polarized plug. As a safety feature this

‘ * Use your heater only in dry environments. This heater is not intended plug will fit in a polarized outlet only one way. To prevent

Features: for use in a bathroom, laundry area, or similar locations, or near -_-_ electric shock, match wide blade of plug to wide slot, fully

° sinks, washing machines, swimming pools or other sources of water. insert plug. If the plug does not fit contact a qualified

1 1 Never locate heater where it may fall into a bathtub or other water electrician

° 70 Oscillation container. Do not use in damp environments such as flooded

. . basements. Do not operate any heater with a damaged cord or plug or after

e Two Heat Settings: * Do not place the heater on a small, unlevel, uneven or any surface heater malfunctions, has been dropped or damaged in any

which might allow heater to tip or fall. manner. Do not operate heater with a broken heating element

800 watts ¢ For proper operation, heater should be placed on a smooth, or ceramic cone or any visual imperfections. For repairs

non-combustible surface. Do not place on rugs, carpet, vinyl flooring covered under warranty, see warranty statement. For all other

400 tt or other plastic surfaces. Not for use outdoors or in wet areas repairs contact Comfort Zone® Customer Service by telephone

wa Ss * This heater is not designed as a primary heat source. or mail for information and assistance.

* Always plug heaters directly into a wall outlet/receptacle. Never use

* Top Mounted Control Panel ser cri Se tare user OADM". PET OWNERS NOTE:

. . The health of birds and some small pets are extremely sensitive

. n r r r Sits

¢ Safety Tip-Over Switch Do not run power cord under carpeting, Do not cover cord with 15 the fumes given of during the inal use of many appliances.

. . traffic area where it will not be tripped over. Although these fumes are not harmful to humans, it is

e Quiet Operation * To disconnect heater, turn controls off then remove plug from outlet. recommended that this heater not be used around birds and

Sli . D . * Do not insert or allow foreign objects to enter any ventilation or aeciree burnoe its initial use until the manufacturing corrosion

e - exhaust opening as this may cause an electric shock or fire or

Im Twin Tube esign damage the heater.

* To prevent a possible fire, do not block air intakes or exhaust in any

e Stay Cool Body manner. Do not use on soft surfaces like a bed, where openings may

become blocked:

e 1 20V A.C. 60Hz. 6.66A 2730 BTUs ¢ A heater has hot and arcing or sparking parts inside. Do not use it in

, ; ry areas where gasoline, paint or flammable liquids are used or stored.

¢ Use this heater only as described in this manual. Any other use not

us recommended by the manufacturer may cause fire, electric shock or

tisTES! injury to persons or property.

Intertek SAVE THESE INSTRUCTIONS

Save These Instructions

Source page 2 - OCR transcription (OCR)

USAGE: CARE AND MAINTENANCE

HEATER OPERATION: Always operate the heater in CLEANING: CAUTION-Before cleaning the heater be

the upright position following all instructions and sure to disconnect power cord and allow the heater to LIMITED WARRANTY

recommendations listed in this manual. cool completely. This heater should be cleaned at least Thi iti teed to th iginal retail h inst defects i lit ki hip fi

HEATER LOCATION: Place the heater in the area of once a year to maintain proper performance. Clean Is unit is guaranteed fo the origina re al purchaser agains e ec sin quality or workmanship ora

the room that is coldest. the outside surface with a clean damp cloth. Do not period of one year from the date of original purchase. If this unit fails because of a manufacturing

HEATER CONNECTION: Plug heater directly into 120 use harsh chemical or abrasive cleaners. DO NOT defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but

volt A.C., 60 Hz wall outlet. Be sure plug fits tightly in IMMERSE THE HEATER IN WATER. Allow heater to within the warranty period, if the unit was purchased within the continental United States, return it, to

outlet. A loose connection may cause overheating and dry completely before use. Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United

damage to the plug or heater. NOTE: To prevent States, return the unit to the place of purchase. This warranty does not cover damage caused by

overloading a circuit, do not plug the heater into a REPAIR: DO NOT OPERATE THE HEATER WITHOUT misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not

circuit that is servicing other electrical needs. Make ANY OF THE SAFETY FEATURES IN PLACE. DO NOT covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation.

sure heater is at least three (3) feet away from USE THE HEATER IF IT HAS MALFUNCTIONED OR All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable,

walls, furniture, and other obstacles. BECOME DAMAGED IN ANY WAY. are hereby limited in duration to the period of one year from the date of original retail purchase. Some

; states do not allow limitations on how long an implied warranty lasts, so the above limitations may not

TURNING HEATER ON: The heater has two heat STORAGE: Keep original carton for storage of the apply to you. Incidental or consequential damages arising from a breach of either express or implied

seuings: ano ane 300 wa Rotate Control 2a heater Store the power cord to avoid damage during warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation

esired’ selting, Mise the 60) walt setting to raise the Storage. of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the

room temperature quickly. Use the 400 watt setting to expiration of this warranty all such liability will terminate. No other warranties are expressed or implied.

maintain the room temperature. To use the Oscillation BASE ASSEMBLY INSTRUCTIONS: PI y y : PI pied.

feature simply choose the OSC function on the LOW 1. Turn the heater upside down. . . ae . . .

or HIGH setting. (During the heaters initial use, you may 2. Remove two wing-nuts from base of heater and This warranty gives you specific legal rights, and you may also have other rights which vary from state

experience a slight odor or smoking. This is the result save for future reassembly. (Fig.1) to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu

of residual lubrication on the steel “burning off”. This is 3. Align tip-over switch of heater to round opening in of all other warranties.

normal and will go away after a few minutes of use.) base and align power cord of heater to slot on base.

Assemble base to heater. (Fig. 2) Mr. Brands LLC

Switch OSC: Oscillates the heater on LOW or HIGH 4. Using two wing-nuts removed in step #1, thread 113 Fillmore St

setting. onto heater as shown in Fig. 3. Bristol, PA 19007

1-877-420-7555

TO TURN HEATER OFF: Rotate Control Dial to the www.mrbrands.com

OFF position. Unplug unit when not in use Pat www.comfortzoneproducts.com

HALOGEN TUBES: Do not use if either tube is Wing-Nut raid

cracked or broken. ome fe Lv

r , WARNING:

Wing-Nut Aig Cancer and Reproductive Harm --

y www.P65Warnings.ca.gov

Fig.1 Rev. 07/19/2023

Rotary Control Dial

ack |

| 49 Opening

Tip-Over

« witch “4 \

-)j oy Wire Slot

| - j

one OD « |

Low HIGH

LOW ofr HIGH Fig. 2

Wing-Nut [mes Ls) i

Wing-Nut [ee p

Fig. 3 Rev. 012017