Comfort Zone 5,000W Ceiling Mounted Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ220

Original source file(s): 125132.Instruction Manual.01.pdf; 502060.Instruction Manual.01.pdf; CZ220, CZ220BK.Instruction Manual.01.pdf

Source SHA-256: 003993a6cdfa2eaa5fe90b4d9ecb2a6893d9ddbbc12b4958f79ecb223c456259

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

Binding edge - dimensions:420X290

290mm

210mm

Mr.Brands LLC

113 Fillmore St

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

07/20/2023

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the **warranty period, if the unit was purchased within the continental** United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This **warranty does not cover damage caused by misuse, abuse,** overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation

of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this **warranty all such liability will terminate. No other warranties are** expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr.Brands LLC 113 Fillmore St Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

Source page 1 - Panel 1 (top left) (OCR)

po Bn

4 “

©) Comfort Zone

|TINDUSTRIAL | CZ220 Series

| >

e eee .

_|

: ., Oonrt2one - (

: a

N

Ceiling Mounted Heater

HARDWIRED INSTALLATION REQUIRED

This heater must be grounded and hardwired to a properly sized current protection circuit breaker in accordance with the (US) National Electric Code and local codes.

Description

e Adjustable Heat Settings

e Fan-Forced for Wide Heat Circulation

¢ Horizontal and Vertical Air Flow with Tilt Feature

e Sturdy Heavy Gauge Steel Body

¢ High Limit Thermal Cut-Out Switch

oO

3

Source page 1 - Panel 2 (top right) (OCR)

O www.comfortzoneproducts.com ° O www.comfortzoneproducts.com :

SD rrr

ADJUSTING AIR FLOW: LIMITED WARRANTY SPECIFICATIONS:

1. Swivel the unit- If mounted on a single center lag bolt Figure | This unit is guaranteed to the original retail purchaser against

4a, turn the entire heater and bracket assembly left or right. defects in quality or workmanship for a period of one year from CZ220 SERIES HEAVY DUTY 5,000W ELECTRIC UTILITY HEATER

2. Tilt the unit- Loosen the top Small Knob-Screws and thread the date of original purchase. If this unit fails because of a [warts -s| switcHposition| --votts(vac) =| PHASE. =| AMPS) |-sBTU/HOUR |

into provided holes in heater until tight. See Figure 5. manufacturing defect within 30 days of purchase, return the unit, WATTS SWITCH POSITION VOLTS (VAC) PHASE BTU/HOUR

3. Adjust the louvers in front of the heater as desired. See with your receipt, to the retailer. After 30 days, but within the 5,000W fm 208-240V, 60Hz 17,060

Figure 5. warranty period, if the unit was purchased within the continental

NOTE:00 NO OPERATE THE HEATER WTHTHE FRONT | UNUSEIES aml MI rads LC al

LOUVERS CLOSED, DAMAGE TO THE HEATER COULD p P 3,000W Pt 208-240V, 60Hz 10,240

RESULT. United States, return the unit to the place of purchase. This

. overheating or alteration. Repairs made by anyone other than

SAFETY INSTRUCTIONS: Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC AIR THROW HORIZONTAL 18 FT (APPROXIMATE) a ee ee

1. The heater is HOT when in use. Do not let bare skin touch any | willnot be held liable for any losses dus to negleciful operation. RECOMMENDED | CIRCUIT BREAKER 30 AMP or larger, in accordance with NEC and local codes.

hot surfaces. All implied warranties, including the warranties of merchantability

2. Keep combustible materials (furniture, pillows, bedding, and of fitness of purpose, if applicable, are hereby limited in RECOMMENDED WIRE SIZE 10 AWG, COPPER ONLY or larger, hardwired in accordance with NEC and

papers, clothes, curtains, and similar items) at least 3 duration to the period of one year from the date of original retail RATED AT 167°F/75°C local codes.

feet (0.9m) from all sides and surfaces of the heater. purchase. Some states do not allow limitations on how long an RECOMMENDED LUG TORQUES IN-LBS ' ith NEC local

3. Do not use outdoors or in wet areas like bathrooms, laundry implied warranty lasts, so the above limitations may not apply to or greater, in accordance wit and local codes

areas or where it could fall into a swimming pool or other you. Incidental or consequential damages arising from a breach PRODUCT WEIGHT (APPROXIMATE) BETWEEN 25 TO 30 LBS Po

container of water. of either express or implied warranties are hereby disclaimed

4. This heater is a 240V AC rated direct wired appliance. Never orincidental or eonscqucntial damages the exclusion of imitation

tensi d locatabl taps. y

use Extension COFdS Or relocatable Power Taps exclusion may not apply to you. Upon the expiration of this FOR CZ220 SERIES

. warranty all such liability will terminate. No other warranties are

CARE AND MAINTENANCE: expressed or implied. This warranty gives you specific legal rights, Figure 1 Note: Diagram is not drawn to scale, for information purposes only.

i i CEILING SURFACE CEILING SURFACE

CLEANING THE HEATER: and you may also have other rights which vary from state to State. ;

. . No informal dispute settlement mechanisms are available. This in. nam .|

1. Do not disassemble the heater to clean it. limited warranty is given in lieu of all other warranties. Fe _ _ ql |

2. The heater should be powered OFF and disconnected from ; . A 0

the ooo at me rout breaker before attempting to clean This warranty gives you specific legal rights, and you may also on : | “fom Duchoge

any portion of tne neater. have other rights which vary from state to state. No informal l 1 U) aaain C0) bee eal

3. The exterior can be cleaned with a cloth, brush and/or dispute settlement mechanisms are available. This limited F

vacuum. warranty is given in lieu of all other warranties. i

; ; ; ip

4. The louvers, fan blade and heating element are delicate and === ke |

should not encounter hard items. They can be cleaned by Manufactured for: « 14in. >|/<-1Bin, - Bin. -> |

brush, vacuum and mild compressed air. Mr.Brands LLC ey ee Minimum

. to Wall to Wall Distance

MAINTENANCE: 113 Fillmore St ‘ ‘ ‘oer

7 | ; ; Bristol, PA 19007 °

This Industrial Heater contains no user serviceable parts. 1-877-420-7555 NOTE: Product dimensions are approximate and subject to change without notice. iL

In the unlikely event that your heater should need service, please www.mrbrands.com

contact: Mr.Brands LLC 113 Fillmore St Bristol, PA 19007 www.comfortzoneproducts.com

1-877-420-7555

www.mrbrands.com LM casnne WARNING

www.comfortzoneproducts.com Cancer and Reproductive Harm

www.P65Warnings.ca.gov FOR INDOOR USE ONLY, IN A DRY LOCATION FREE OF GASOLINE, PAINT, FLAMMABLE LIQUIDS OR COMBUSTIBLE DUST OR

: ees MATERIALS.

Rev. 07/20/2023 DO NOT USE EXTENSION CORDS

MAXIMUM MOUNTING HEIGHT USING BRACKET FOR:

HORIZONTAL/ANGLED AIR FLOW: A

The maximum recommended ceiling height for effective Ll --

vertical air flow is 8 ft. - Co .

- we

Source page 1 - Panel 3 (bottom left) (OCR)

Reading orientation normalized by 180 degrees.

©) Comfort Zone.

©) Comfort Zone

SD

INTENDED USE READ & SAVE

Electric Utility heaters are designed to meet a variety of heating

requirements. This product is intended for indoor use only. Use only TH ES E | N STR U CTI O NS

with electrical wiring that is in good working order and that meets

applicable codes and ordinances. WARNING: SHOCK HAZARD

If you have any questions whether your wiring is adequate, consult a Use your heater only in dry environments. This heater is not intended

qualified electrician. Risk of fire, overheating, malfunction, property for use in a bathroom, laundry area, or similar locations, or near sinks,

damage, injury or even death may result if not adhered to. washing machines, swimming pools or other sources of water. Never

; . . locate heater where it may fall into a bathtub or other water container.

Use your heater-fan only with a working smoke detector located in the Do not use heater outdoors. Do not use in damp environments such as

vicinity of your heater-fan. flooded basements.

While using your heater-fan, you should follow the IMPORTANT

INSTRUCTIONS listed below. As part of those instructions, we have WARNING: HOT SURFACES

used the word "WARNING" to indicate the level of hazard: WARNING Do not touch body of heater when in use. This heater is hot when in use,

indicates a hazard which, if not avoided, could result in injury or death. to avoid burns, do not let bare skin touch hot surfaces. If provided, use

handles when moving this heater.

GENERAL SAFETY INFORMATION: WARNING: FIRE HAZARD

WARNING- Read and understand installation and operation Heater has hot and arcing or sparking parts inside. Do not use near

instructions and observe all safety instructions. combustible materials or flammable gases or sources of heat. DO NOT

SAVE THESE INSTRUCTIONS USE in areas where gasoline, paint or flammable materials are used or

1. For supply connections, use only copper wire, See stored. Keep combustible materials such as furniture, pillows, bedding,

SPECIFICATIONS papers, clothes and curtains at least 3 feet (0.9 m) from the front of the

2. Heater air flow must be directed parallel to, or away from adjacent heater and keep them away from the sides and rear. Keep rear grille

wall. away from walls or drapes so as to not block air intake. To prevent a

3. Observe wall, floor, and ceiling clearance requirements, See possible fire, do not block air intakes or exhaust in any manner. Do not

Figure. 1. use on soft surfaces, like a bed, where openings may become blocked.

4. All wiring must conform to national and local electrical codes in the Do not insert or allow foreign objects to enter any ventilation or exhaust

United States and the heater must be grounded as a precaution opening as this may cause an electric shock, fire, or damage the heater.

against possible electrical shock. Heater circuit must be protected

with proper fuses or circuit breakers. WARNING: ELECTRICAL SHOCK HAZARD

5. The mounting structure and the anchoring hardware must be Do not use with damaged wiring. Use with adequate electrical system

capable of reliably supporting the weight of the heater and, if used, that is up to code.

the mounting bracket. . . . Do not operate any heater with a damaged cord or plug or after heater

6. All electrical power must be disconnected, and the main service box malfunctions, has been dropped or damaged in any manner. Do not

must be locked before inspection, cleaning or servicing the heater. operate heater with a broken heating element or ceramic cone or any

This sa precaution to prevent Serious shock. . . visual imperfections. For repairs covered under warranty, see warranty

7. This heater is not suitable for use in hazardous locations as defined statement. For all other repairs contact Comfort Zone® Customer

by the National Fire Protection Association (NFPA) in the United Service by telephone or mail for information and assistance.

States. This heater has hot and arcing (sparking) parts inside. Do

not use in areas where gasoline, paint, or flammable liquids are used PET OWNERS NOTE:

or stored. ; ; ; The health of birds and some small pets are extremely sensitive to the

8. This heater is not suitable for use in corrosive atmosphere such as fumes given off during the initial use of many appliances. Although these

marine, greenhouses or chemical storage areas. fumes are not harmful to humans, it is recommended that this heater

9. Do not install closer than 8 inches to a vertical surface. Do not not be used around birds and small pets during its initial use until the

install less than 6 feet from the floor. manufacturing corrosion coatings burn off.

10. Extreme caution is necessary when any heater is used by or near

children or invalids and whenever the heater is left operating and

unattended.

11. Use this heater only as described in this manual. Any other use not

recommended by the manufacturer may cause fire, electric shock, or

injury to persons.

WARNING- Improper installation or failure to follow the

procedures outlined in this instruction manual can result in

serious electrical shock.

QT

= _

imi _

a SUO!}ONISU] BSEU] SACS WOd's}ONpoJdauOZHOJWOO' MMM

Source page 1 - Panel 4 (bottom right) (OCR)

Reading orientation normalized by 180 degrees.

©) www.comfortzoneproducts.com , ©) www.comfortzoneproducts.com ‘

SD ee ee)

OPERATION INSTALLING THE HEATER: CONDUIT gSONDUTT

Lo tt.

LOCATING THE HEATER: If Heater is to \ J <nin.-

be turned

SERIES MODEL: CZ220 Install the heater out of traffic areas, maintaining the clearances CEILING JOIST and wire is

HEAVY DUTY 5,000W See ee mace ge enemas de condi ;

: WASHER -> C=> eD FLEXIBLE FLEXIBLE

ELECTRIC UTILITY HEATER more than one heater is used in an area, the heaters should be -_- CONDUIT SONDUIT

arranged so that the air discharge of each heater supports the Sa & CONNECTOR

. air flow of the others to provide best circulation of warm air, as a a BRACKET TT

Figure 2 indicated below in Figure 3. & é x m1 2

\7 If Heater is to

Thermostat . b ied 9

Power and lermostat Power Control A 3/8" DIAMETER e connecter

Caution Indicators Control Switch UD LAG BOLT with NM Cable. | \/

\ | | Ki y Figure 4b: Double-Screw Mounting, For Fixed Position FLEXIBLE FLEXIBLE NM CABLE

> -~ NM CABLE CONNECTOR

= <i (use per electircal codes)

Ri -_-

g 2. i - HANGING THE HEATER IN THE BRACKET 12

he 1. Lift the heater into the mounting bracket and align the lower If Heater is to Ke is

Control Panel Detail Figure 3 bracket holes with the threaded holes nearest the heater’s be connected 3 4

(Enlarged for Clarity) center. with Flexible

2. Thread a large knob-screw through the hole on each side of Conduit.

the bracket. OG

MOUNTING BRACKET INSTALLATION 3. Aim the heater horizontally or tilted by aligning the upper FLEXIBLE CONDUIT

POWER INDICATOR LIGHT: . . CONNECTOR

. . Refer to Figures 4a and 4b. bracket holes with the top threaded holes on the heater (use per electircal codes)

Once installed and the breaker is turned ON, the YELLOW Power and secure with the small knob-screws and tighten all.

Indicator Light will glow. 1. Locate a ceiling joist or other firm structural element or See Figure 5. Figure 6

This light stays on as long as power is on at the breaker, even aah to mount the heater and point at desired direction

when the heater is off. 5 0 i. Mn lot hol h forth = = = Use top slots/hole in 3. Pull enough wire into the heater and connect to wire to the

. Drill a %” pilot hole in the ceiling joist for the screws. i i

SETTING THE THERMOSTAT: Pp 9 J ' 3 bracket and small Power Block located in the electrical area of the heater See

3. Place the screws and washers as shown in the 0 knob-screws if heater Figure 7.

Press the TIMER Button continuously until the LED screen i ‘ ‘

displays "O" y Figures 4a or 4b. ; - is to be tilted down. 4. Be sure to torque all terminal screws and power block lugs

Fig. 4a: For Single Screw Mounting (center bracket hole only) tight, see SPECIFICATIONS and NEC/local codes, for

1. From “OFF” rotate the knob clockwise to a higher position. (If you want to swivel the heater, a longer Lag bolt may be {) required torque values, failure to do so can overheat the

2. Pick the desired power level (I, II or Ill) at the Control Switch. required to properly secure the heater, not included.) power blocks.

3. Once the room reaches the desired comfort level, rotate the Fig. 4b: For Double-Screw Mounting (both off-center holes in circui i

, thermostat knob counter-clockwise until it clicks off are used). om on bower at the main cree breaker pane’ Notice ye

. 4. Tighten the screws to secure the heater, () ; YELLOW Power Indicator Light on the Control Panel will glow.

CAUTION LIGHT: Adjust louvers up or

The heater has a Thermal Cutout Switch. If there is an overheat down to control air flow.

situation this switch will shut off the heater. 5 || L2 HOT

en SZZ

Once this happens the RED Caution Light will glow, indicating Li‘ 3 LOLS -

i 4 =

and overheat condition. ATELZ [--

a CEILING JOIST LES >» i

Turn off the heater. Turn off power at the circuit breaker and let Remove screws from the ey ee iN

the heater cooldown. panel to access power 1 LAso<

Determine the cause of the overheat situation and correct. Once WASHER SS block, See Figure 7. Figure 5 HOT

cool, restore power to the heater at the breaker and resume S

; an .

operation of the heater. gwasien CONNECTING THE POWER: GROUND

NOTE: Heater will cycle on and off to maintain room temperature. BRACKET 1. With the power off at the breaker, remove all screws from the _ (or bare copper)

The first time you operate the unit, it may smoke slightly. This is t bottom lid for access to the electrical section of the heater. ==

due to residual cleaning agents used to clean the element when 3/8" DIAMETER 2. Attach flexible cable through a knock-out in the side of the Figure 7

the heater is manufactured. This is normal and does not indicate LAG BOLT heater following NEC and local codes, See Figure 6 and

a problem with the unit. This condition will stop after the heater Figure 4a: Single-Screw Mounting, To Allow Swivel SPECIFICATIONS for recommended wiring and circuit

has been in operation for a few minutes. breakers. WARNING: It is advised that at the start of each heater season,

NOTE: For certain applications, conduit may be required the power should be turned off at the circuit breaker and the

(See Figure 6). Check local electrical codes. If you run the LI & L2 lug screws checked for tightness and proper torque.

wiring in conduit and wish to be able to turn the heater be sure The heater should be cleaned and checked for mechanical and

to purchase enough flexible conduit to allow the heater to be electrical integrity. See SPECIFICATIONS and NEC/local codes.

turned.

QO as 5)

ow er °

|