Comfort Zone 6,000W Digital Ceiling Mounted Heater / Comfort Zone 7,500W Digital Ceiling Mounted Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ225ER, CZ230ER

Original source file(s): 520014.Instruction Manual.02.pdf; CZ225ER.Instruction Manual.01.pdf; CZ230ER, CZ230ERBK.Instruction Manual.01.pdf; 120025.Instruction Manual.01.pdf; 120163.Instruction Manual.01.pdf

Source SHA-256: 980594b909c34bdda3f1e5e5ebb7148f831fa20773f3b1b3ef05e62b9f056ae0

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

Binding edge - dimensions:420X290

290mm

210mm

40

Mr.Brands LLC

113 Fillmore St

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the **warranty period, if the unit was purchased within the continental** United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This **warranty does not cover damage caused by misuse, abuse,** overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to

you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this **warranty all such liability will terminate. No other warranties are** expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

07/20/2023

Mr.Brands LLC 113 Fillmore St Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

Source page 1 - Panel 1 (top left) (OCR)

po “(ti ann

O www.comfortzoneproducts.com ¢ omfort Z one ®

-------- [TS

Models: CZ225ER Series

ERROR CODE TROUBLESHOOTING GUIDE: CZ230ER Series

Error Code | Possible Cause Recommended Solution Clearing Error Codes ~ 2

-~

F1 (Fan Insufficient Clearance Around Ensure Heater is Installed with Sufficient Clearance All-Around, See Figure 1. To Clear E1 Code:

Blade Not Heater *6 feet minimum mounting from floor 1. P Off H .

Spinning) *8 inches minimum from rear of heater ~ Power eater :

Overheat “13 inches minimum from side of heater 2. Switch Off Breaker (or ‘

Safety Remove Fuse) : =

Cut-Out Obstructed Vent Remove any objects on heater or adjacent to heater vents. Do not block intake -

(Resettable) or exhaust by columns, machinery, etc. Ensure 24 inches minimum distance 3. Allow Heater to Cool y - 3 .

from heater exhaust (front) to any object (~15 minutes) Wg a 5

4. Switch on Breaker and ---/ i

Fan Not Operational Disconnect power! wait 1 minute 5 aeapesesees - |

(Fan Blade Not Spinning) Inspect Fan Blade (Rear of Heater) for foreign or dislodged object(s) preventing . , Hit } |

rotation. Remove Rear Grille and clear interference, re-attach Rear Grille. 5. Power On Unit and follow . ie | y |

Instruction Manual for Sar i age

Disconnect power! Normal Operation T - hel

Open Hinged Bottom Cover by removing screws. Inspect Circuit Card ; 7 I ~ ae

Assembly (adjacent to Supply Connection Terminal Block) for loose or If E1 code persists please -- { i

detached "plug-in" electrical connector. Re-attach securely, close Bottom contact manufacturer to =, - mm} J

Cover and re-install screws. arrange product return. ; a =

Inadequate Copper Wire Gauge | Consult a licensed electrician. a -_

for Supply Connections Ensure Adequate Wire Gauge for Supply Connections y | “|

(Fan Operates at Reduced Speed Ocomfort 7,

= Due to Insufficient Power Input) ORRy ane.

t ee

Excessive Distance from Power . ee ee 16 4

Source = ‘

(Fan Operates at Reduced Speed

([D) Due to Current Loss) e

oO) Inadequate Current (Amp) Rating | Consulta licensed electrician. a a

on Breaker Ensure adequately sized Current Breaker or Fuse per National & Local]]

N Electrical Codes.

Improper Heater Shut Down Do not power off heater using circuit breaker. ane

Fan motor is designed to operate for a short period of time after heating

element shuts off to prevent an overheat condition. e] | nN g O u n e e a e r

E2 Room Detached or Loose Connection at | Disconnect power! To Clear E2 & E3 Codes:

Temp Sensor Room Temperature Sensor * Detach Fan Grille by removing screws. Locate Temp Sensor 4. Power Off Heater

Open Circuit Thermocouple on Housing (below Fan Motor Bracket). Ensure wire pair & :

thermocouple "tip" are free of damage. Re-attach Grille by re-installing screws. | 2, Switch Off Breaker HAR DWI R E D | NSTALLATI O N R EQ U I R E D

* Open Bottom Cover by removing screws. Inspect Circuit Card Assembly ‘or Remove Fuse) . .

(adjacent to Supply Connection Terminal Block) for loose or detached "plug-in" (.) This heater must be grounded and hardwired to a properly

electrical connector. Re-attach connectors securely. Close Bottom Cover and | 3. Switch on Breaker and . . . . . .

reinstall screws. wait 1 minute sized current protection circuit breaker in accordance with

4. P it foll . .

E3 Room | Moisture Entrapment in Heater | Not intended for outdoor use. Not intended for use in bathrooms, shower ener an Unt and follow the (US) National Electric Code and local codes.

Temp Sensor rooms, laundry facilities or other similar indoor locations. A

ener : Normal Operation

Short Circuit Disconnect power!

Open Bottom Cover by removing screws. Allow unit to fully dry. Re-attach . 7 +

securely, close Bottom Cover and re-install screw(s). If E2 or ES code persists Descri pti on

please contact manufacturer to

Electcal Shor-to Ground at | Disconnect power! arrange product return. ¢ Adjustable Heat Settings with Digital Thermostat

Room Temperature Sensor * Detach Fan Grille by removing screws.

Locate Temp Sensor Thermocouple on Housing (below Fan Motor Bracket). _ H H H

Ensure wire insulation is not damaged and internal conductor is not exposed. bd Fan Fo rced for Wi de H eat C Ircu lation

Re-attach Grille by re-installing screws. . . . .

¢ Fan Only Setting for Year-Round Air Circulation

No Power or | Supply Connections Improperly | Consulta licensed electrician. Re-Start Unit.

Low Power Wired Ensure Supply Connections L1, L2, L3 & Ground are secure. Torque per NEC e - i 1 -

to Heater (L3 provided on certain models). Follow Instruction Manual for 1 2 Hour Timer with Auto Shut Off

Normal Operation. * : : ‘ *

Insufficient Service Loop on Consult a licensed electrician. e Horizontal and Vertical Air Flow with Ti It Featu re

Supply Connections Ensure sufficient service loop in supply wires to maintain secure electrical

connections to swivel heater on bracket (particularly when using rigid or e oO

conrectons fou Sturdy Heavy Gauge Steel Body S

Electrical Short-to Ground Consult a licensed electrician. e Remote Control ZB

Ensure Supply Connections (L1, L2 & L3) are not contacting Housing (Ground) . to. . N

(L3 only provided on certain models). e High Limit Thermal Cut-Out Switch vt

Source page 1 - Panel 2 (top right) (OCR)

Oo www.comfortzoneproducts.com : ©) www.comfortzoneproducts.com :

rrr -rr---E-- EEE

and secure with the small knob-screws and tighten all. - oo

g | L2 HOT SPECIFICATIONS:

See Figure 5. LOZ 7

ey

CONNECTING THE POWER: _ . lf CZ225ER SERIES DIGITAL HEAVY DUTY 6,000W ELECTRIC UTILITY HEATER

1. With the power off at the breaker, remove all screws from the ey’ OO WATTS SWITCH POSITION VOLTS (VAC) | pHase | amps | BTU/HOUR

bottom lid for access to the electrical section of the heater. L1 pas

2. Attach flexible cable through a knock-out in the side of the HOT 6,000W HIGH (Default) 208-240V, 60Hz 20,470

heater following NEC and local codes, See Figure 6 and 4.500W MEDIUM 208-240V, 6OHz 18.75 15.350

SPECIFICATIONS for recommended wiring and GROUND ” , : ”

oeuit breakers -_ RA 3,000 208-240, 60He 10.240

CONDUIT

CONNECTOR

lf Heater is to \ J <_ ot _y required torque values, failure to do so can overheat the RECOMMENDED CIRCUIT BREAKER 30 AMP or larger, in accordance with NEC and local codes.

be turned power blocks. RECOMMENDED WIRE SIZE 8 AWG, COPPER ONLY _| or larger, hardwired in accordance with NEC and

and wire is 5. Turn on power at the main circuit breaker panel. Notice the RATED AT 167°F/75°C local codes.

inside conduit. Zz YELLOW Power Indicator Light on the Control Panel will glow.

RECOMMENDED LUG TORQUES 40 IN-LBS or greater, in accordance with NEC and local codes

CONDUIT CONGUE WARNING: It is advised that at the start of each heater season, 9 ' “I

CONNECTOR the power should be turned off at the circuit breaker and the PRODUCT WEIGHT (APPROXIMATE) BETWEEN 25 TO 30 LBS ee

- LI & L2 lug screws checked for tightness and proper torque.

lf Heater is to eS electrical integrity. See SPECIFICATION and NEC/local codes. CZ230ER SERIES DIGITAL HEAVY DUTY 7,500W ELECTRIC UTILITY HEATER

be connected WATTS SWITCH POSITION VOLTS (VAC | pHase | amps | BTU/HOUR

with NM Cable. | aw ADJUSTING AIR FLOW: (VAC)

FLEXIBLE FLEXIBLE NM CABLE 1. Swivel the unit- If mounted on a single center lag bolt Figure 7,500W HIGH (Default) 208-240V, 60Hz 25,590

--- 2. Tilt the unit- Loosen the top Small Knob-Screws and thread

12 into provided holes in heater until tight. See Figure 5. 6,250W 208-240V, 60Hz 21,330

co (SESE | Adust the lowers in font ofthe heater as desired. See FAN ONLY

lf Heater is to Figure 5

with Flexible 3 4 NOTE: DO NO OPERATE THE HEATER WITH THE FRONT AIR THROW HORIZONTAL 18 FT (APPROXIMATE)

Conduit. COC Ome Gok LOUVERS CLOSED, DAMAGE TO THE HEATER COULD RECOMMENDED CIRCUIT BREAKER 40 AMP or larger, in accordance with NEC and local codes.

RESULT.

FLEXIBLE CONDUIT RECOMMENDED WIRE SIZE 8 AWG, COPPER ONLY or larger, hardwired in accordance with NEC and

CONNECTOR ° ° .

(use per electrcal codes) SAFETY INSTRUCTIONS: RATED AT 167°F/75°C local codes.

Figure 6 To start the heater, turn on the circuit breaker. The Power Indicator RECOMMENDED LUG TORQUES 40 IN-LBS or greater, in accordance with NEC and local codes

light will light up to indicate there is power available. Press the PRODUCT WEIGHT (APPROXIMATE) BETWEEN 25 TO 30 LBS Po

POWER button to turn the heater on. The heater will be in HIGH

(See Figure 6). Check local electrical codes. If you run the setting by default. The heater indicator will illuminate, and the

wiring in conduit and wish to be able to turn the heater be sure LED display will show the default setting temperature 80°F. FOR CZ225ER AND CZ230ER SERIES

to purchase enough flexible conduit to allow the heater to be 1. The heater is HOT when in use. Do not let bare skin touch any

turned. hot surfaces. Figure 1 Note: Diagram is Not Drawn to Scale, for information purposes only.

3. Pull enough wire into the heater and connect the wire to the 2. Keep combustible materials (furniture, pillows, bedding, + a 1 SUN SNE

Power Block located in the electrical area of the heater, papers, clothes, curtains, and similar items) at least 3 | | 6in, | seam. |

See Figure 7. feet (0.9m) from all sides and surfaces of the heater. | - ql

4. Be sure to torque all terminal screws and power block lugs 3. Do not use outdoors or in wet areas like bathrooms, laundry ‘ I f O “Minium Distance

tight, see SPECIFICATION and NEC/local codes, for areas or where it could fall into a swimming pool or other 19in, s | fate

container of water. ! n) in O Hin,

4. This heater is a 240V AC rated direct wired appliance. Never e

use extension cords or relocatable power taps. i Ee | E Le |

|}<--._ 14in. ---->|<- 13 in. <- 8in. -}

Minimum Minimum |

Distance Distance Minimum

‘to Wall ‘to Wall Distance

‘to Floor

6ft.

NOTE: Product dimensions are approximate and subject to change without notice. i

Source page 1 - Panel 3 (bottom left) (OCR)

Reading orientation normalized by 180 degrees.

©) Comfort Zone. O) Comfort Zone.

©) Comfort Zone Comfort Zone

SD ee ee)

INTENDED USE READ & SAVE CARE AND MAINTENANCE: LIMITED WARRANTY

Electric Utility heaters are designed to meet a variety of heating CLEANING THE HEATER: ae . . .

requirements. This product is intended for indoor use only. Use only TH ESE | NSTRUCTI ONS 4. Donot di ble the heater to clean it This unit is guaranteed to the original retail purchaser against

with electrical wiring that is in good working order and that meets > BO nor alsassemble te neater to clean | . defects in quality or workmanship for a period of one year from

applicable codes and ordinances. WARNING: SHOCK HAZARD 2. The heater should be powered OFF and disconnected from the date of original purchase. If this unit fails because of a

If you have any questions whether your wiring is adequate, consult a Use your heater only in dry environments. This heater is not intended om orto i. ith heat oteaker Before atempting fo lean marvfactaring ere ae tS arenas. eit the

i ear , F ; for use in a bathroom, laundry area, or similar locations, or near sinks, 'y portion or the neater. with your receipt, to the retailer. After 30 days, but within the

quale’ electrician. Fisk one overheating, malfunction. property washing machines, swimming pools or other sources of water. Never 3. The exterior can be cleaned with a cloth, brush and/or warranty period, if the unit was purchased within the continental

amage, injury or even oa may res not aaneree 10. ; locate heater where it may fall into a bathtub or other water container. vacuum. United States, return it, to Mr. Brands LLC for repair or

Use your heater-fan only with a working smoke detector located in the | Do not use heater outdoors. Do not use in damp environments such as 4. The louvers, fan blade and heating element are delicate and replacement. If the unit was purchased outside the continental

vicinity of your heater-fan. flooded basements. should not encounter hard items. They can be cleaned by United States, return the unit to the place of purchase. This

While using your heater-fan, you should follow the IMPORTANT brush, vacuum and mild compressed air. warranty does not cover damage caused by misuse, abuse,

INSTRUCTIONS listed below. As part of those instructions, we have WARNING: HOT SURFACES . overheating or alteration. Repairs made by anyone other than

" 1 49 indi : j i i i MAINTENANCE: Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC

used the word "WARNING" to indicate the level of hazard: WARNING Do not touch body of heater when in use. This heater is hot when in use, ! . y. ;

indicates a hazard which, if not avoided, could result in injury or death. | to avoid burns, do not let bare skin touch hot surfaces. If provided, use This Industrial Heater contains no user serviceable parts. will not be held liable for any losses due to neglectful operation.

handles when moving this heater. In the unlikely event that your heater should need service, please _| /llimplied warranties, including the warranties of merchantability

GENERAL SAFETY INFORMATION: contact: Mr.Brands LLC 113 Fillmore St Bristol, PA 19007 and of fitness of purpose, if applicable, are hereby limited in

: ; : . WARNING: FIRE HAZARD 1-877-420-7555 duration to the period of one year from the date of original retail

WARNING- Read and understand installation and operation Heater has hot and arcing or sparking parts inside. Do not use near www.mrbrands.com purchase. Some states do not allow limitations on how long an

instructions and observe all safety instructions. combustible materials or flammable gases or sources of heat. DO NOT www.com fortzonepro ducts.com implied warranty lasts, so the above limitations may not apply to

SAVE THESE INSTRUCTIONS USE in areas where gasoline, paint or flammable materials are used or , ‘ you. Incidental or consequential damages arising from a breach

1. For supply connections, use only copper wire, see stored. Keep combustible materials such as furniture, pillows, bedding, of either express or implied warranties are hereby disclaimed

SPECIFICATIONS. papers, clothes and curtains at least 3 feet (0.9 m) from the front of the and excluded. Some states do not allow the exclusion of limitation

2. Heater air flow must be directed parallel to, or away from adjacent heater and keep them away from the sides and rear. Keep rear grille of incidental or consequential damages, so this limitation or

wall. away from walls or drapes so as to not block air intake. To prevent a exclusion may not apply to you. Upon the expiration of this

3. Observe wall, floor, and ceiling clearance requirements. possible fire, do not block air intakes or exhaust in any manner. Do not warranty all such liability will terminate. No other warranties are

See Figure. 1. use on soft surfaces, like a bed, where openings may become blocked. expressed or implied. This warranty gives you specific legal rights,

4. All wiring must conform to national and local electrical codes in the Do not insert or allow foreign objects to enter any ventilation or exhaust and you may also have other rights which vary from state to state.

United States and the heater must be grounded as a precaution opening as this may cause an electric shock, fire, or damage the heater. No informal dispute settlement mechanisms are available. This

against possible electrical shock. Heater circuit must be protected limited warranty is given in lieu of all other warranties.

with proper fuses or circuit breakers. WARNING: ELECTRICAL SHOCK HAZARD

5. The mounting structure and the anchoring hardware must be Do not use with damaged wiring. Use with adequate electrical system This warranty gives you specific legal rights, and you may also

capable of reliably supporting the weight of the heater and, if used, that is up to code. have other rights which vary from state to state. No informal

the mounting bracket. Do not operate any heater with a damaged cord or plug or after heater dispute settlement mechanisms are available. This limited

6. All electrical power must be disconnected, and the main service box malfunctions, has been dropped or damaged in any manner. Do not warranty is given in lieu of all other warranties.

must be locked before inspection, cleaning or servicing the heater. operate heater with a broken heating element or ceramic cone or any

This sa precaution to prevent Serious shock. . . visual imperfections. For repairs covered under warranty, see warranty Manufactured for:

7. This heater is not suitable for use in hazardous locations as defined statement. For all other repairs contact Comfort Zone® Customer Mr.Brands LLC

by the National Fire Protection Association (NFPA) in the United Service by telephone or mail for information and assistance. 113 Fillmore St

States. This heater has hot and arcing (sparking) parts inside. Do Bristol, PA 19007

not use in areas where gasoline, paint, or flammable liquids are used PET OWNERS NOTE: 1-877-420-7555

or stored. ; ; ; The health of birds and some small pets are extremely sensitive to the www.mrbrands.com

8. This heater is not suitable for use in corrosive atmosphere such as fumes given off during the initial use of many appliances. Although these www.comfortzoneproducts.com

marine, greenhouses or chemical storage areas. fumes are not harmful to humans, it is recommended that this heater

9. Do not install closer than 8 inches to a vertical surface. Do not not be used around birds and small pets during its initial use until the LA ;

install less than 6 feet from the floor. manufacturing corrosion coatings burn off. Jan NING i .

productive Harm

10. Extreme caution is necessary when any heater is used by or near www.P65Warnings.ca.gov

children or invalids and whenever the heater is left operating and

unattended. Rev. 07/20/2023

11. Use this heater only as described in this manual. Any other use not

recommended by the manufacturer may cause fire, electric shock, or

injury to persons.

WARNING- Improper installation or failure to follow the

procedures outlined in this instruction manual can result in

serious electrical shock.

2 as 7)

& _

im

a suO!]ONsJSU] BSE] @AeS WWoo'syonposdsuoZHO}WOO MMM ee :

Source page 1 - Panel 4 (bottom right) (OCR)

Reading orientation normalized by 180 degrees.

©) www.comfortzoneproducts.com : ©) www.comfortzoneproducts.com °

WARNING: TIMER FUNCTION:

FOR INDOOR USE ONLY, IN A DRY LOCATION FREE OF GASOLINE, PAINT, FLAMMABLE LIQUIDS OR COMBUSTIBLE DUST OR The Timer function allows you to set the length of operation from TT A

MATERIALS. 1 to 12 hours. Each time the TIMER button is pressed the length CEILING JOIST

DO NOT USE EXTENSION CORDS of operation will increase 1 hour. The duration the timer is set for

will be displayed on the LED screen in hour increments.

MAXIMUM MOUNTING HEIGHT USING BRACKET FOR: TO TURN THE TIMER FUNCTION OFF: Press the TIMER WASHER --> €2>

Button continuously until the LED screen displays "O". SS

HORIZONTAL/ANGLED AIR FLOW: NOTE: The timer function is not an excuse to leave the heater WASHER

The maximum recommended ceiling = unattended. &

height for effective vertical air flow is 8 ft. - Co, NOTE: Heater will cycle on and off to maintain room temperature. t BRACKET

~~ The first time you operate the unit, it may smoke slightly. This is oe eno

due to residual cleaning agents used to clean the element when

the heater is manufactured. This is normal and does not indicate Figure 4a: Single-Screw Mounting, To Allow Swivel

Series Model: CZ225ER Series Model: CZ230ER a problem with the unit. This condition will stop after the heater

has been in operation for a few minutes.

DIGITAL HEAVY DUTY 6,000W DIGITAL HEAVY DUTY 7,500W Lo

ELECTRIC UTILITY HEATER ELECTRIC UTILITY HEATER FAHRENHEIT OR CELSIUS DISPLAY:

Figure 2 Figure 2 To switch the display between Fahrenheit and Celsius, press

Power Temperature Temperature the °F/°C on either the unit or the remote.

oon Cimperature a tae Control Controls +/- Display WASHER -> C25

Switch \ Switch / INSTALLING THE HEATER: T “|

LOCATING THE HEATER: a re BRACKET

\. -_ B 8 Tle

: \ beige AB Install the heater out of traffic areas, maintaining the clearances \7

GP SSOSCO : stated in Figure 1 above. The air flow from the heater must not 3/8" DIAMETER

be restricted or obstructed by any items in the room. When LAG BOLT

Control Panel Detail Control Panel Detail more than one heater is used in an area, the heaters should be . -

(Enlarged for Clarity) (Enlarged for Clarity) arranged so that the air discharge of each heater supports the Figure 4b: Double-Screw Mounting, For Fixed Position

air flow of the others to provide best circulation of warm air, as

OPERATION AND TEMPERATURE SETTING: OPERATION AND TEMPERATURE SETTING: indicated below in Figure 3. holes are used).

1. This heater is designed to maintain a comfortable room 1. This heater is designed to maintain a comfortable room

temperature. Always operate the heater in the upright temperature. Always operate the heater in the upright j HANGING THE HEATER IN THE BRACKET

position following all instructions and recommendations position following all instructions and recommendations lit 1. Lift the heater into the mounting bracket and align the lower

listed in this manual. listed in this manual. . bracket holes with the threaded holes nearest the heater’s

; , . . i y center.

When the heater is turned on by pressing the POWER button, When the heater is turned on by pressing the POWER button, pat _~ .

it will operate on HIGH setting (6,000W) continuously. it will operate on HIGH setting (7,500W) continuously. Fj al 2. eae alarge knob-screw through the hole on each side of

The LED display panel will show the ambient temperature. The LED display panel will show the ambient temperature. 5 t re brac et. _

Press the MODE button on either the unit or remote to Press the MODE button on either the unit or remote to 3. Aim the heater horizontally or tilted by aligning the upper

change the heat setting to MEDIUM (4,500W) then, press change the heat setting to LOW (6,250W). The fan will start bracket holes with the top threaded holes on the heater

the MODE button again to LOW (3,000W). The fan will start running about 10 seconds after initial start to push the heat Figure 3 = Ss = Use top slots/hole in

running about 10 seconds after initial start to push the heat out. The sequence is HIGH-LOW-FAN-ONLY. To bracket and small

out. The sequence is HIGH-MEDIUM-LOW-FAN-ONLY. To operate the unit on FAN ONLY setting, press the MODE ° : knob-screws it heater

operate the unit on FAN ONLY setting, press the MODE button again. In FAN ONIY mode, the L&D display panel wil BRACKET INSTALLATION FOR CZ225ER AND _ is to be tilted down.

button again. In FAN ONLY mode, the LED display panel will show FA to indicate the heater is in FAN ONLY mode. CZ230ER SERIES: --- I 5

show FA to indicate the heater is in FAN ONLY mode. From FAN ONLY mode, pressing the MODE button will . () 4

From FAN ONLY mode, pressing the MODE button will make the heater operate in HIGH setting again, and the Refer to Figures 4a and 4b.

make the heater operate in HIGH setting again, and the ambient temperature will appear on the LED display. a ;

: . : 1. Locate a ceiling joist or other firm structural element or

ambient temperature will appear on the LED display. . A ar

support to mount the heater and point at desired direction ()

of air flow. Adjust louvers up or

2. The temperature setting can be adjusted between 45°F (7°C) to 95°F (35°C). To change the temperature, press the TEMP+ or 2. Drill a 4” pilot hole in the ceiling joist for the screw(s). down to control air flow.

TEMP - buttons on either the unit or the remote. (See Figure 2) 3. Place th d h h inth L |

3. The temperature display will blink while it is being adjusted. When the desired temperature is reached, it will take about 5 . lace e screw(s) and washers as shown in the z 4

seconds to accept the setting. Once the display stops flashing, the room temperature will reappear on the LED screen to Figures 4a or 4b. 3

indicate the desired temperature is set. Figure 4a: For Single-Screw Mounting (center bracket / A

4. In any temperature mode, the unit will stay in that mode, cycling on and off to maintain the set temperature. The heater will hole only).

reach the set temperature faster in HIGH setting. (If you want to swivel the heater, a longer Lag bolt may be Remove screws from the

5. The heater can be turned OFF by pressing the POWER button. Once the unit is turned off, the fan will continue to run to cool required to properly secure the heater, not included.) panel to access power

down the unit and there will be a 90 seconds countdown on the digital display. Figure 4b: For Double-Screw Mounting (both off-center block, See Figure 7. Figure 5

QO as 5)

1