Comfort Zone 16-inch Wall Mount Oscillating Fan

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ16W

Original source file(s): CZ16W.Instruction Manual.01.pdf

Source SHA-256: 9033cdfa1c8e61cb930e4ad9be2eed52d51bf9ec363ddd42c57fb2ec8d99349d

Original PDF pages: 4 | Recovered reading units: 5

Source page 1 (embedded text)

Save These Instructions

www.comfortzoneproducts.com

CZ16W Series

Features:

• 3 Speed Settings

• Adjustable Vertical Tilt

• Rotary Dial Speed

• Pull-String Speed Control

• Pull-String Oscillation Control

• All Metal Safety Grilles

• 120V A.C. / 60 Hz.

Wall Mount Oscillating Fan

Source page 2 (embedded text)

22

www.comfortzoneproducts.com

INTENDED USE:

This product is intended for indoor residential and office use only, not for industrial or other commercial applications. Use only with electrical wiring that is in good working order and that meets applicable codes and ordinances. If you have any questions whether your wiring is adequate, consult a qualified electrician. While using your fan, you should follow the IMPORTANT INSTRUCTIONS listed below. As part of those instructions, we have used the word “WARNING” to indicate the level of hazard:

WARNING indicates a hazard which, if not avoided, could result in injury or death.

IMPORTANT INSTRUCTIONS

As with all electrical appliances, basic safety precautions should always be followed to reduce the risk of electric shock, fire, or injury to persons, including the following precautions:

• Read all the instructions before using this fan.
• Use this fan only as described in this manual. Any other use not recommended by the manufacturer may cause electrical shock, fire or injury to persons.
• Do not operate the fan with a damaged power cord or after the fan malfunctions or has been dropped in any manner.
• Use of extreme caution is necessary when any fan is used by or near children, disabled persons or pets and whenever the fan is left operating unattended.
• Do not place the fan on a small, unlevel, uneven or any surface which might allow fan to tip or fall.
• For proper operation, fan should be placed on a smooth, non-combustible, level surface.
• Always unplug fan when not in use, when moving from place to place, when assembling or disassembling parts, and before **cleaning.**
• The use of attachments, not recommended or sold by the manufacturer, may cause hazards.
• Do not use outdoors.
• Do not use fan in window. Rain may cause electrical hazard (for non-window models).
• Do not operate the fan with blade guards or any safety device removed.
• Avoid the use of extension cords due to risk of fire. If an extension cord must be used, the cord must be minimum 14 AWG and rated not less then 1875 watts.
• Do not run power cord under carpeting. Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic area where it will not be tripped over.
• Do not insert or allow any object to enter any openings on the fan. Doing so may cause electric shock and/or fire hazard. Avoid contact with moving parts.
• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
• Children should be supervised to ensure they do not play with the appliance.

READ & SAVE THESE INSTRUCTIONS

WARNING: SHOCK HAZARD

Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water. Never locate fan where it may fall into a bathtub or other water receptacle. Do not use in damp environments such as flooded basements.

WARNING: HOT SURFACES

Do not touch fan motor when in use. This motor is hot when in use, to avoid burns, do not let bare skin touch hot surfaces.

WARNING: FIRE HAZARD

Fans have arcing or sparking parts inside. Do not use near combustible materials or flammable gases or sources of heat. Do not use in areas where gasoline, paint or flammable materials are used or stored. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock, fire, or damage the fan.

WARNING: ELECTRICAL SHOCK HAZARD

Do not use with damaged cord or plug. Use with adequate electrical system that is up to code.

CAUTION: TO PREVENT ELECTRIC SHOCK

This product has a polarized two prong plug (one blade is wider than the other) that must be fully inserted in to a matching properly grounded outlet. This plug is designed to fit a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If the plug still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

WARNING: ELECTRICAL SHOCK HAZARD

Do not use this product with any solid-state speed control device.

Do not operate any fan with a damaged cord or plug or after fan malfunctions, has been dropped or damaged in any manner. Do not operate fan with a broken blade, safety cage or any visual imperfections. Disconnect power before servicing. For repairs covered under warranty, see warranty statement. For all other repairs contact World and Main Customer Service by telephone or mail for information and assistance.

Do not run power cord under carpeting. Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic area where it will not be tripped over. Avoid the use of extension cords due to risk of fire. If an extension cord must be used, the cord must be minimum 14 AWG and rated not less then 1875 watts. Do not use an extension cord unless the plug can be completely inserted into its receptacle. Unplug the fan when not

in use. Do not operate fan with its ventilation obstructed.

Source page 3 (embedded text)

33

www.comfortzoneproducts.com

USAGE:

FAN OPERATION: Always operate the fan in the upright position following all instructions and recommendations listed in this manual. FAN LOCATION: Place the fan in the area of the room that will provide proper fan cooling. FAN CONNECTION: Plug fan directly into 120 Volt A.C., 60Hz wall outlet. Be sure plug fits tightly in outlet. A loose connection may cause overheating and damage to the plug or fan. NOTE: To prevent overloading a circuit, do not plug the fan into a circuit that is servicing other electrical needs.

TURNING FAN ON: With fan mounted to a stable wall surface, plug fan into properly functioning outlet. To start the fan, rotate the dial from the OFF position to the desired fan speed (1 - LOW, 2 - MEDIUM, or 3 - HIGH). This fan is equipped with additional pull-string control for easy reach. Pull the right side pull-string to turn unit ON and adjust fan speed.

TURNING FAN OFF: To turn the fan off, rotate the switch from its current fan speed setting to the OFF position. This fan is equipped with additional pull-string control for easy reach. Pull the right side pull-string to cycle past fan speeds and turn unit OFF. Remove plug from outlet.

OSCILLATION: To start fan oscillation, pull left side pull-string while operating at any fan speed. To stop oscillation function simply pull oscillation pull-string again to discontinue oscillation while operating the fan at any speed.

ADJUSTING FAN TILT: To adjust the tilt angle simply tilt the fan to desired position. Ratcheting effect should hold the fan at the desired angle.

ASSEMBLY INSTRUCTIONS:

Images may vary slightly from actual product.

ASSEMBLY INSTRUCTIONS: (cont.)

Mount
Securely
to Wall
Control Panel
Power /
Fan Speed
Rotary Dial

Oscillation

Pull-String

Power /

Fan Speed

Pull-String

STEP 2:

Assemble Rear Grille onto Motor Housing. Rear Grille should fit into pins on fan motor housing as shown.

STEP 3:

Thread Locknut onto Motor Housing to lock Rear Grille in place.

STEP 4:

Remove any protective covering over shaft before Fan Blade installation. Place Fan Blade onto Motor Shaft. Notice the pin on Motor Shaft should fit into slots of Fan Blade.

STEP 5:

Thread Blade Cap onto threaded end of Motor Shaft. NOTE: Threads are reversed. Tighten = Counter-clockwise.

STEP 6:

Attach Front Grille to Rear Grille with Hook Clip centered on the top above Wire Handle.

STEP 7:

Press remaining Grille Clips onto Rear Grille to securely attach Front Grille. Do not operate fan without Grille in place.

STEP 8:

Secure Wall Bracket to the wall in the desired location. Use proper anchors for the wall material selected, following the manufacturers instructions. Mounting bracket to wall studs

is recommended.

STEP 9:

Hang fan on wall bracket.

Place Bracket Screw through

fan and thread screw onto

bracket.

STEP 1:

Remove the Blade Cap by

twisting it CLOCKWISE while

holding the metal shaft tightly.

NOTE: Threads are reversed.

Unscrew = Clockwise.

Pin

Pin

Pin

Slot

Hook Clip

Grille

Clip

Bracket

Screw

Loosen

Blade Cap

Tighten

Locknut

Source page 4 (embedded text)

44

www.comfortzoneproducts.com

LIMITED WARRANTY

CARE AND MAINTENANCE:

CLEANING: CAUTION - Before cleaning the fan be sure to

disconnect power cord from the plug. Clean the grille surface

with a clean damp cloth. Do not use harsh chemical or

abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES

IN WATER. Allow fan to dry completely before use. Periodic grille

cleaning with a vacuum will prevent dust build up. The motor is

sealed and does not require any interior maintenance, cleaning

or lubrication.

MAINTENANCE: The internal motor bearings are permanently

lubricated at the factory and do not require any additional

lubrication.

REPAIR: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY.

STORAGE: Keep original carton for storage of the heater.

Coil and tie the power cord to avoid damage during storage.

FUSE REPLACEMENT:

This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover by sliding open fuse access cover on top of attachment plug towards blades (see Fig. 2).
3. Remove fuse carefully. Use a small tool to pry the end of the fuse from holder cavity. Be careful not to break glass window.
4. Replace fuse. WARNING: Risk of fire. Replace fuse only with identical 2.5 or 5.0 Amp, 125 Volt fuse (3.6 mm x 10 mm). Be sure fuse is properly seated within its cavity.
5. Close fuse cover by sliding it back to its original closed position.

Slide Cover to Open

Figure 1

Figure 3

Figure 2

Slide Cover to Open